

AT Commands Reference Guide










GM862-QUAD, GM862-QUAD-PY, GM862-GPS, GE863-QUAD, GE863-PY,
GE863-GPS, GE864-QUAD, GE864-PY, GC864-QUAD and GC864-PY
80000ST10025a Rev. 5 - 09/07/08



AT Commands Reference Guide

80000ST10025a Rev. 5 - 09/07/08

This document is related to the following products:

<p>GSM GPRS</p> <p>GM862-QUAD Modem</p> <p>GM862-QUAD-PY Modem</p> <p>GM862-GPS Modem</p>		<p>GSM GPRS</p> <p>GE863-QUAD Embedded</p> <p>GE863-PY Embedded</p> <p>GE863-GPS Embedded</p>		<p>GSM GPRS</p> <p>GT863-PY Terminal</p>	
<p>GM862-QUAD 3 990 250 659</p> <p>GM862-QUAD-PY 3 990 250 658</p> <p>GM862-GPS 3 990 250 657</p> <p>GM862-GPS 3 990 250 689</p>		<p>GE863-QUAD 3 990 250 662</p> <p>GE863-PY 3 990 250 661</p> <p>GE863-GPS 3 990 250 660</p> <p>GE863-GPS 3 990 250 690</p>		<p>GT863-PY 3 990 150 471</p>	
<p>GSM GPRS</p> <p>GE864-QUAD Embedded</p> <p>GE864-PY Embedded</p>		<p>GSM GPRS</p> <p>GC864-QUAD Compact</p> <p>GC864-PY Compact</p>		<p>GSM GPRS</p> <p>GT864-QUAD Terminal</p> <p>GT864-PY Terminal</p>	
<p>GE863-QUAD 3 990 250 651</p> <p>GE863-PY 3 990 250 650</p>		<p>GC864-QUAD 3 990 250 675</p> <p>GC864-PY 3 990 250 676</p> <p>GC864-QUAD with SIM Holder 3 990 250 704</p>		<p>GT864-QUAD 4 990 150 069</p> <p>GT864-PY 4 990 150 070</p>	
<p>GSM GPRS</p> <p>GE863-PRO³ Embedded</p>		<p>GSM GPRS</p> <p>GE864-AUTO Embedded</p>		<p>GSM GPRS</p> <p>GE863-SIM Embedded</p>	
<p>GE863-PRO³ 3 990 250 691</p> <p>GE864-PRO³ with Linux OS 3 990 250 698</p>		<p>GE864-AUTO 3 990 250 701</p>		<p>GE863-SIM 3 990 250 700</p>	

SW Version

7.03.00 / 7.02.05



AT Commands Reference Guide
80000ST10025a Rev. 5 - 09/07/08

3.5.6.1	General Configuration.....	233
3.5.6.2	Transmission/Reception Control.....	233
3.5.6.3	Serial Port Control.....	236
3.5.7	Custom AT Commands.....	238
3.5.7.1	General Configuration AT Commands.....	238
3.5.7.2	General Configuration AT Commands - Special Issues.....	315
3.5.7.3	Multisocket AT Commands.....	315
3.5.7.4	FTP AT Commands.....	326
3.5.7.5	Enhanced Easy GPRS® Extension AT Commands.....	332
3.5.7.6	E-mail Management AT Commands.....	363
3.5.7.7	Easy Scan® Extension AT Commands.....	375
3.5.7.8	SIM Toolkit AT Commands.....	394
3.5.7.9	Jammed Detect & Report AT Commands.....	406
3.5.7.10	Easy Script® Extension - Python Interpreter, AT Commands.....	409
3.5.7.11	GPS AT Commands Set.....	418
3.5.7.12	SAP AT Commands Set.....	428
3.5.7.13	Telefonica OpenGate M2M AT Commands Set.....	430
4	List of acronyms.....	431
5	Document Change Log.....	433



1 INTRODUCTION

1.1 Scope Of Document

To describe all AT commands implemented on the Telit wireless modules listed on the page 2.

NOTE: Telit suggests all the system developers to use always the newer AT Commands Interface Style defined by AT#SELINT=2; and in case you are starting a new design we highly recommend you to use the newer AT Commands Interface Style defined by AT#SELINT=2 which gives you a possibility to include all Telit's new features and also all future implementations.



2 APPLICABLE DOCUMENTS

- a) ETSI GSM 07.07 specification and rules
- b) ETSI GSM 07.05 specification and rules
- c) Hayes standard AT command set



3.2 AT Command Syntax

The syntax rules followed by Telit implementation of either Hayes AT commands, GSM commands and FAX commands are very similar to those of standard basic and extended AT commands. A special command (**#SELINT**, see §3.5.2.1.1) has been introduced in order to have an AT interface very close to the standard one.

There are two types of extended command:

- **Parameter type commands.** This type of commands may be “set” (to store a value or values for later use), “read” (to determine the current value or values stored), or “tested” (to determine ranges of values supported). Each of them has a test command (trailing =?) to give information about the type of its subparameters; they also have a Read command (trailing ?) to check the current values of subparameters.
- **Action type commands.** This type of command may be “executed” or “tested”.
 - “executed” to invoke a particular function of the equipment, which generally involves more than the simple storage of a value for later use
 - “tested” to determine:
 - (if the command **#SELINT=0** or **#SELINT=1** has been issued, see §3.5.2.1.1)
 - if subparameters are associated with the action, the ranges of subparameters values that are supported; if the command has no subparameters, issuing the correspondent Test command (trailing =?) raises the result code “**ERROR**”.
 - Note: issuing the Read command (trailing ?) causes the command to be executed.
 - (if the command **#SELINT=2** has been issued, see §3.5.2.1.1)
 - whether or not the equipment implements the Action Command (in this case issuing the correspondent Test command - trailing =? - returns the **OK** result code), and, if subparameters are associated with the action, the ranges of subparameters values that are supported.

Action commands don't store the values of any of their possible subparameters.

Moreover:

- (for **#SELINT=0** or **#SELINT=1** only)
An enhanced test command (trailing =??) has been introduced to maintain backward compatibility for those commands whose subparameters changed the range of possible values from version to version.
- (for **#SELINT=2** only)
The response to the Test Command (trailing =?) may be changed in the future by Telit to allow the description of new values/functionalities
- (for **#SELINT=2** only)



Numeric Format	Verbose Format
409	time-out in opening socket
410	cannot open socket
411	remote disconnected or time-out
412	connection failed
413	tx error
414	already listening
FTP related errors (only if command #SELINT=0 or #SELINT=1 has been issued - see §3.5.2.1.1):	
420	ok
421	connect
422	disconnect
423	error
424	wrong state
425	can not activate
426	can not resolve name
427	can not allocate control socket
428	can not connect control socket
429	bad or no response from server
430	not connected
431	already connected
432	context down
433	no photo available
434	can not send photo
Easy GPRS® related errors (only if command #SELINT=2 has been issued - see §3.5.2.1.1):	
550	generic undocumented error
551	wrong state
552	wrong mode
553	context already activated
554	stack already active
555	activation failed
556	context not opened
557	cannot setup socket
558	cannot resolve DN
559	time-out in opening socket
560	cannot open socket
561	remote disconnected or time-out
562	connection failed
563	tx error
564	already listening
FTP related errors (only if command #SELINT=2 has been issued - see §3.5.2.1.1):	
600	generic undocumented error
601	wrong state
602	can not activate
603	can not resolve name
604	can not allocate control socket
605	can not connect control socket
606	bad or no response from server
607	not connected
608	already connected
609	context down
610	no photo available
611	can not send photo



Numeric Format	Verbose Format
612	resource used by other instance
Network survey errors: (only if command #SELINT=2 has been issued - see §3.5.2.1.1):	
657	Network survey error (No Carrier)*
658	Network survey error (Busy)*
659	Network survey error (Wrong request)*
660	Network survey error (Aborted)*
SAP related errors: (only if command #SELINT=2 has been issued - see §3.5.2.1.1):	
731	Unspecified
732	Activation command is busy
733	Activation started with CMUX off
734	Activation started on invalid CMUX
736	Remote SIM already active
737	Invalid parameter

*(values in parentheses are GSM 04.08 cause codes)

3.2.2.2 Message Service Failure Result Code - +CMS ERROR: <err>

This is NOT a command, it is the error response to +Cxxx GSM 07.05 commands

Syntax: **+CMS ERROR: <err>**

Parameter: **<err>** - numeric error code. The **<err>** values are reported in the table:

Numeric Format	Meaning
0...127	GSM 04.11 Annex E-2 values
128...255	GSM 03.40 sub clause 9.2.3.22 values
300	ME failure
301	SMS service of ME reserved
302	operation not allowed
303	operation not supported
304	invalid PDU mode parameter
305	invalid text mode parameter
310	SIM not inserted
311	SIM PIN required
312	PH-SIM PIN required
313	SIM failure
314	SIM busy
315	SIM wrong
316	SIM PUK required
317	SIM PIN2 required
318	SIM PUK2 required
320	memory failure
321	invalid memory index
322	memory full
330	SMSC address unknown
331	no network service
332	network time-out
500	unknown error



AT Commands Reference Guide
80000ST10025a Rev. 5 - 09/07/08

Command	Estimated maximum time to get response (Seconds)
+VTS	20 (transmission of full "1234567890*#ABCD" string with no delay between tones, default duration)
+CSCA	5 (read and set commands)
+CSAS	5
+CRES	5
+CMGS	60 after CTRL-Z; 1 to get '>' prompt
+CMSS	60 after CTRL-Z; 1 to get '>' prompt
+CMGW	5 after CTRL-Z; 1 to get '>' prompt
+CMGD	5 (single SMS cancellation) 25 (cancellation of 50 SMS)
+CMGR	5
+CMGL	20 (full listing of 50 SMS)
+CGACT	5
+CGATT	10
D	30 (voice call) Timeout set with ATS7 (data call)
A	30 (voice call) Timeout set with ATS7 (data call)
H	30
+CHUP	5
+COPN	10
+CPOL	10 (set command; read command of 84 records)
+CRSM	5
+FRH	Timeout set with ATS7
+FTH	Timeout set with ATS7
+FRM	Timeout set with ATS7
+FTM	Timeout set with ATS7
+FRS	Timeout set with the command itself
+FTS	Timeout set with the command itself
#MBN	10
#TONE	5 (if no duration specified)
#ADC	5
#EMAILD	20
#EMAILACT	150
#SEMAIL	170 (context activation + DNS resolution)
#MSCCLASS	15
#SPN	5
#STSR	10
#CCID	5
#GPRS	150
#SKTD	140 (DNS resolution + timeout set with AT#SKTCT)



Command	Estimated maximum time to get response (Seconds)
	complete scan
#CSURVPC	10 to start data output; 120 seconds to complete scan
#LSCRIPT	10 (40 files, 10 Kbyte each)
#REBOOT	5
#RSCRIPT	30 seconds for a 100 Kbyte file 30 seconds timeout and ERROR message if no bytes are received on the serial line
#WSCRIPT	35 seconds for a 100 Kbyte file 30 seconds timeout and ERROR message if no bytes are sent on the serial line and the file has not been completely sent
#DSCRIPT	120
\$GPSAI	5
\$GPSPAR	5

3.2.5 Command Issuing Timing

The chain Command -> Response shall always be respected and a new command must not be issued before the module has terminated all the sending of its response result code (whatever it may be).

This applies especially to applications that “sense” the **OK** text and therefore may send the next command before the complete code **<CR><LF>OK<CR><LF>** is sent by the module.

It is advisable anyway to wait for at least 20ms between the end of the reception of the response and the issue of the next AT command.

If the response codes are disabled and therefore the module does not report any response to the command, then at least the 20ms pause time shall be respected.

During command mode, due to hardware limitations, under severe CPU load the serial port can loose some characters if placed in autobauding at high speeds. Therefore if you encounter this problem fix the baud rate with **+IPR** command.



AT Commands Reference Guide

80000ST10025a Rev. 5 - 09/07/08

+FCLASS	+ILRR	+DR
+CSCS	+CR	+CRLP
+CRC	+CSNS	+CVHU
+CREG	+CLIP	+CLIR
+CCWA	+CUSD	+CAOC
+CSSN	+CIND	+CMER
+CPBS	+CMEE	+CGREG
+GGEREP	+CMGF	+CSDH
+CNMI	#QSS	#ACAL ⁵
#TEMPMON ⁶	#ACALEXT	#ECAM
#SMOV	#MWI	#NITZ
#SKIPESC	#E2ESC	#STIA
\$GPSNMUN		

The values set by following commands are stored in the profile extended section and they don't depend on the specific CMUX instance (see **+CMUX**):

+CALM	+CRSL	+CMUT ⁵
+CLVL ⁵	+VTD	+CSCB ⁷
#CAP ⁵	#SRS ⁵	#SRP ⁵
#STM ⁵	#DVI	#E2SMSRI
#DAC	#CODEC	#SHFEC ⁵
#HFMICG ⁵	#HSMICG	#SHFSD ⁵
#SPKMUT	#NITZ	#E2SLRI
#SIMDET	#TEMPMON ⁶	#PSEL
#HFRECG	#HSRECG	#SHFAGC
#SHSAGC	#SHSEC	#SHSNR
#SHFNR	#SHSSD	#TSVOL
#CPUMODE		

The values set by following commands are automatically stored in NVM, without issuing any storing command and independently from the profile (unique values), and are automatically restored at startup:

#SELINT	+COPS ⁸	+CGCLASS
+CGDCONT	+CGQMIN	+CGQREQ
#REGMODE	#PLMNODE	#COPSMODE
#DIALMODE	#BND	#AUTOBND
#ENS	#SCFG	
#ENHSIM	#AUTOATT	#TXMONMODE
#TTY	#ICMP	#GSMCONT
#NWSCANTMR	#SMSMODE	#DNS
#TCPMAXDAT	#TCPREASS	

The values set by following commands are stored in NVM on demand, issuing specific commands and independently from the profile:

+CSCA	+CSMP	+CSCB
-------	-------	-------

stored by +CSAS⁹ command and restored by +CRES⁹ command

⁵ If **#SELINT=2** they depend on the CMUX 0 instance only

⁶ It is partially stored in NVM, moreover only a part of it can depend on the specific **CMUX** instance; see command description.

⁷ +CSCB is still stored in the profile extended section only for backward compatibility issues: its actual storing and restoring are accomplished issuing **+CSAS** and **+CRES**

⁸ It is partially stored in NVM; see command description.

⁹ Both commands **+CSAS** (see §3.x.3.2.5) and **+CRES** (see §3.x.3.2.6) deal with non-volatile memory, intending for it either the NVM and the SIM storage.



AT Commands Reference Guide
80000ST10025a Rev. 5 - 09/07/08

#SLED
stored by #SLEDSAV¹⁰ command

#VAUX
stored by #VAUXSAV¹¹ command

#USERID	#PASSW	#PKTSZ
#DSTO	#SKTTO	#SKTSET#SKTCT

stored by #SKTSAV command and automatically restored at startup; factory default values are restored by #SKTRST command

#ESMTP	#EADDR	#EUSER
#EPASSW		

stored by #ESAV command and automatically restored at startup; factory default values are restored by #ERST command.

\$GPSP	\$GPSD	\$GPSAT
\$GPSAP	\$GPSS	\$GPSCON

stored by \$GPSSAV command and automatically restored at startup; factory default values are restored by \$GPSRST command

¹⁰ Valid for #SELINT=2 only.

¹¹ Valid for #SELINT=2 only.



3.4 AT Commands Availability Table

The following table lists the AT commands set and matches the availability of every single command versus the Telit wireless module family. It deals with backward compatibility issues too, showing the availability of every single command depending on selected interface style (**#SELINT**).

COMMAND	GM862-QUAD	GM862-QUAD-PY	GM862-GPS	GE863-QUAD & GE863-PRO ³	GE863-PY & GE863-SIM	GE863-GPS	GE864-AUTO	GE864-QUAD & GC864-QUAD	GC864-PY & GE864-PY	Function	Page
Command Line General Format - Command Line Prefixes											
AT	•	•	•	•	•	•	•	•	•	Starting A Command Line	31
A/	•	•	•	•	•	•	•	•	•	Last Command Automatic Repetition Prefix	31
General Configuration Commands - AT Interface Backward Compatibility											
#SELINT	•	•	•	• ¹²	•	•	•	•	•	Select Interface Style	33
Hayes AT Commands - Generic Modem Control											
&F	•	•	•	•	•	•	•	•	•	Set To Factory-Defined Configuration	34
Z	•	•	•	•	•	•	•	•	•	Soft Reset	34
+FCLASS	•	•	•	•	•	•	•	•	•	Select Active Service Class	34
&Y	•	•	•	•	•	•	•	•	•	Designate A Default Reset Basic Profile	35
&P	•	•	•	•	•	•	•	•	•	Designate A Default Reset Full Profile	35
&W	•	•	•	•	•	•	•	•	•	Store Current Configuration	36
&Z	•	•	•	•	•	•	•	•	•	Store Telephone Number In The Module Internal Phonebook	36
&N	•	•	•	•	•	•	•	•	•	Display Internal Phonebook Stored Numbers	36
+GMI	•	•	•	•	•	•	•	•	•	Manufacturer Identification	36
+GMM	•	•	•	•	•	•	•	•	•	Model Identification	37
+GMR	•	•	•	•	•	•	•	•	•	Revision Identification	37
+GCAP	•	•	•	•	•	•	•	•	•	Capabilities List	37
+GSN	•	•	•	•	•	•	•	•	•	Serial Number	37
&V	•	•	•	•	•	•	•	•	•	Display Current Base Configuration And Profile	37
&V0	•	•	•	•	•	•	•	•	•	Display Current Configuration And Profile	38
&V1	•	•	•	•	•	•	•	•	•	S Registers Display	38
&V3	•	•	•	•	•	•	•	•	•	Extended S Registers Display	38
&V2	•	•	•	•	•	•	•	•	•	Display Last Connection Statistics	39
\V	•	•	•	•	•	•	•	•	•	Single Line Connect Message	39
+GCI	•	•	•	•	•	•	•	•	•	Country Of Installation	39
%L	•	•	•	•	•	•	•	•	•	Line Signal Level	39
%Q	•	•	•	•	•	•	•	•	•	Line Quality	40
L	•	•	•	•	•	•	•	•	•	Speaker Loudness	40
M	•	•	•	•	•	•	•	•	•	Speaker Mode	40
Hayes AT Commands - DTE-Modem Interface Control											
E	•	•	•	•	•	•	•	•	•	Command Echo	40
Q	•	•	•	•	•	•	•	•	•	Quiet Result Codes	40
V	•	•	•	•	•	•	•	•	•	Response Format	41
X	•	•	•	•	•	•	•	•	•	Extended Result Codes	42
I	•	•	•	•	•	•	•	•	•	Identification Information	43
&C	•	•	•	•	•	•	•	•	•	Data Carrier Detect (DCD) Control	43
&D	•	•	•	•	•	•	•	•	•	Data Terminal Ready (DTR) Control	43
\Q	•	•	•	•	•	•	•	•	•	Standard Flow Control	45

¹² GE863-PRO3 does not support selint command



AT Commands Reference Guide

80000ST10025a Rev. 5 - 09/07/08

COMMAND	GM862-QUAD	GM862-QUAD-PY	GM862-GPS	GE863-QUAD & GE863-PRO ²	GE863-PY & GE863-SIM	GE863-GPS	GE864-AUTO	GE864-QUAD & GC864-QUAD	GC864-PY & GE864-PY	Function	Page
&K	•	•	•	•	•	•	•	•	•	Flow Control	45
&S	•	•	•	•	•	•	•	•	•	Data Set Ready (DSR) Control	46
\R	•	•	•	•	•	•	•	•	•	Ring (RI) Control	46
+IPR	•	•	•	•	•	•	•	•	•	Fixed DTE Interface Rate	47
+IFC	•	•	•	•	•	•	•	•	•	DTE-Modem Local Flow Control	48
+ILRR	•	•	•	•	•	•	•	•	•	DTE-Modem Local Rate Reporting	49
+ICF	•	•	•	•	•	•	•	•	•	DTE-Modem Character Framing	49
Hayes AT Commands - Call Control											
D	•	•	•	•	•	•	•	•	•	Dial	50
T	•	•	•	•	•	•	•	•	•	Tone Dial	54
P	•	•	•	•	•	•	•	•	•	Pulse Dial	55
A	•	•	•	•	•	•	•	•	•	Answer	55
H	•	•	•	•	•	•	•	•	•	Disconnect	55
O	•	•	•	•	•	•	•	•	•	Return To On Line Mode	55
&G	•	•	•	•	•	•	•	•	•	Guard Tone	56
&Q	•	•	•	•	•	•	•	•	•	Sync/Async Mode	56
Hayes AT Commands - Modulation Control											
+MS	•	•	•	•	•	•	•	•	•	Modulation Selection	56
%E	•	•	•	•	•	•	•	•	•	Line Quality Monitor And Auto Retrain Or Fallback/Fallforward	57
Hayes AT Commands - Compression Control											
+DS	•	•	•	•	•	•	•	•	•	Data Compression	57
+DR	•	•	•	•	•	•	•	•	•	Data Compression Reporting	57
Hayes AT Commands - Break Control											
\B	•	•	•	•	•	•	•	•	•	Transmit Break To Remote	58
\K	•	•	•	•	•	•	•	•	•	Break Handling	58
\N	•	•	•	•	•	•	•	•	•	Operating Mode	58
Hayes AT Commands - S Parameters											
S0	•	•	•	•	•	•	•	•	•	Number Of Rings To Auto Answer	59
S1	•	•	•	•	•	•	•	•	•	Ring Counter	60
S2	•	•	•	•	•	•	•	•	•	Escape Character	60
S3	•	•	•	•	•	•	•	•	•	Command Line Termination Character	61
S4	•	•	•	•	•	•	•	•	•	Response Formatting Character	62
S5	•	•	•	•	•	•	•	•	•	Command Line Editing Character	63
S7	•	•	•	•	•	•	•	•	•	Connection Completion Time-Out	63
S12	•	•	•	•	•	•	•	•	•	Escape Prompt Delay	64
S25	•	•	•	•	•	•	•	•	•	Delay To DTR Off	65
S30	•	•	•	•	•	•	•	•	•	Disconnect Inactivity Timer	66
S38	•	•	•	•	•	•	•	•	•	Delay Before Forced Hang Up	66
ETSI GSM 07.07 - General											
+CGMI	•	•	•	•	•	•	•	•	•	Request Manufacturer Identification	68
+CGMM	•	•	•	•	•	•	•	•	•	Request Model Identification	68
+CGMR	•	•	•	•	•	•	•	•	•	Request Revision Identification	68
+CGSN	•	•	•	•	•	•	•	•	•	Request Product Serial Number Identification	69
+CSCS	•	•	•	•	•	•	•	•	•	Select TE Character Set	69
+CIMI	•	•	•	•	•	•	•	•	•	Request International Mobile Subscriber Identity (IMSI)	70
+CMUX	•	•	•	•	•	•	•	•	•	Multiplexing Mode	70
+WS46	•	•	•	•	•	•	•	•	•	PCCA STD-101 Select Wireless Network	71
ETSI GSM 07.07 - Call Control											
+CHUP	•	•	•	•	•	•	•	•	•	Hang Up Call	71
+CBST	•	•	•	•	•	•	•	•	•	Select Bearer Service Type	71
+CRLP	•	•	•	•	•	•	•	•	•	Radio Link Protocol	73
+CR	•	•	•	•	•	•	•	•	•	Service Reporting Control	74
+CEER	•	•	•	•	•	•	•	•	•	Extended Error Report	75
+CRC	•	•	•	•	•	•	•	•	•	Cellular Result Codes	76
+CSNS	•	•	•	•	•	•	•	•	•	Single Numbering Scheme	77



AT Commands Reference Guide

80000ST10025a Rev. 5 - 09/07/08

COMMAND	GM862-QUAD	GM862-QUAD-PY	GM862-GPS	GE863-QUAD & GE863-PRO ²	GE863-PY & GE863-SIM	GE863-GPS	GE864-AUTO	GE864-QUAD & GC864-QUAD	GC864-PY & GE864-PY	Function	Page
+CVHU	•	•	•	•	•	•	•	•	•	Voice Hang Up Control	77
ETSI GSM 07.07 - Network Service Handling											
+CNUM	•	•	•	•	•	•	•	•	•	Subscriber Number	78
+COPN	•	•	•	•	•	•	•	•	•	Read Operator Names	79
+CREG	•	•	•	•	•	•	•	•	•	Network Registration Report	80
+COPS	•	•	•	•	•	•	•	•	•	Operator Selection	83
+CLCK	•	•	•	•	•	•	•	•	•	Facility Lock/Unlock	87
@CLCK	•	•	•	•	•	•	•	•	•	Facility Improved Lock/Unlock	89
+CPWD	•	•	•	•	•	•	•	•	•	Change Facility Password	91
+CLIP	•	•	•	•	•	•	•	•	•	Calling Line Identification Presentation	92
+CLIR	•	•	•	•	•	•	•	•	•	Calling Line Identification Restriction	95
+CCFC	•	•	•	•	•	•	•	•	•	Call Forwarding Number And Conditions	96
+CCWA	•	•	•	•	•	•	•	•	•	Call Waiting	97
+CHLD	•	•	•	•	•	•	•	•	•	Call Holding Services	101
+CUSD	•	•	•	•	•	•	•	•	•	Unstructured Supplementary Service Data	102
+CAOC	•	•	•	•	•	•	•	•	•	Advice Of Charge	104
+CLCC	•	•	•	•	•	•	•	•	•	List Current Calls	106
+CSSN	•	•	•	•	•	•	•	•	•	SS Notification	108
+CCUG	•	•	•	•	•	•	•	•	•	Closed User Group Supplementary Service Control	110
+CPOL	•	•	•	•	•	•	•	•	•	Preferred Operator List	111
ETSI GSM 07.07 - Mobile Equipment Control											
+CPAS	•	•	•	•	•	•	•	•	•	Phone Activity Status	111
+CFUN	•	•	•	•	•	•	•	•	•	Set Phone Functionality	112
+CPIN	•	•	•	•	•	•	•	•	•	Enter PIN	114
+CSQ	•	•	•	•	•	•	•	•	•	Signal Quality	120
+CIND	•	•	•	•	•	•	•	•	•	Indicator Control	121
+CMER	•	•	•	•	•	•	•	•	•	Mobile Equipment Event Reporting	123
+CPBS	•	•	•	•	•	•	•	•	•	Select Phonebook Memory Storage	123
+CPBR	•	•	•	•	•	•	•	•	•	Read Phonebook Entries	125
+CPBF	•	•	•	•	•	•	•	•	•	Find Phonebook Entries	128
+CPBW	•	•	•	•	•	•	•	•	•	Write Phonebook Entry	129
+CCLK	•	•	•	•	•	•	•	•	•	Clock Management	131
+CALA	•	•	•	•	•	•	•	•	•	Alarm Management	133
+CRSM	•	•	•	•	•	•	•	•	•	Restricted SIM Access	137
+CALM	•	•	•	•	•	•	•	•	•	Alert Sound Mode	138
+CRSL	•	•	•	•	•	•	•	•	•	Ringer Sound Level	139
+CLVL	•	•	•	•	•	•	•	•	•	Loudspeaker Volume Level	141
+CMUT	•	•	•	•	•	•	•	•	•	Microphone Mute Control	142
+CACM	•	•	•	•	•	•	•	•	•	Accumulated Call Meter	143
+CAMM	•	•	•	•	•	•	•	•	•	Accumulated Call Meter Maximum	144
+CPUC	•	•	•	•	•	•	•	•	•	Price Per Unit And Currency Table	145
+CLAC	•	•	•	•	•	•	•	•	•	Available AT commands	146
+CALD	•	•	•	•	•	•	•	•	•	Delete Alarm	146
+CCID	•	•	•	•	•	•	•	•	•	Read ICCID (Integrated Circuit Card Identification)	147
ETSI GSM 07.07 - Mobile Equipment Errors											
+CMEE	•	•	•	•	•	•	•	•	•	Report Mobile Equipment Error	147
ETSI GSM 07.07 - Voice Control											
+VTS	•	•	•	•	•	•	•	•	•	DTMF Tones Transmission	148
+VTD	•	•	•	•	•	•	•	•	•	Tone Duration	149
ETSI GSM 07.07 - Commands For GPRS											
+CGCLASS	•	•	•	•	•	•	•	•	•	GPRS Mobile Station Class	150
+CGATT	•	•	•	•	•	•	•	•	•	GPRS Attach Or Detach	151
+CGEREP	•	•	•	•	•	•	•	•	•	GPRS Event Reporting	152
+CGREG	•	•	•	•	•	•	•	•	•	GPRS Network Registration Status	153



AT Commands Reference Guide

80000ST10025a Rev. 5 - 09/07/08

COMMAND	GM862- QUAD	GM862- QUAD- PY	GM862- GPS	GE863- QUAD &GE863- PRO ²	GE863- PY & GE863- SIM	GE863- GPS	GE864- AUTO	GE864- QUAD & GC864- QUAD	GC864- PY & GE864- PY	Function	Page
										Identification)	
#SPN	•	•	•	•	•	•	•	•	•	Service Provider Name	240
#CEER	•	•	•	•	•	•	•	•	•	Extended Numeric Error Report	240
#CAP	•	•	•	•	•	•	•	•	•	Change Audio Path	242
#SRS	•	•	•	•	•	•	•	•	•	Select Ringer Sound	243
#SRP	•	•	•	•	•	•	•	•	•	Select Ringer Path	245
#STM	•	•	•	•	•	•	•	•	•	Signaling Tones Mode	246
#TONE	•	•	•	•	•	•	•	•	•	Tone Playback	247
#TSVOL	•	•	•	•	•	•	•	•	•	Tone Classes Volume	247
#REGMODE	•	•	•	•	•	•	•	•	•	Select Registration Operation Mode	249
#SMSMODE	•	•	•	•	•	•	•	•	•	SMS Commands Operation Mode	249
#PLMNMODE	•	•	•	•	•	•	•	•	•	PLMN List Selection	250
#PCT	•	•	•	•	•	•	•	•	•	Display PIN Counter	250
#SHDN	•	•	•	•	•	•	•	•	•	Software Shut Down	251
#Z	•	•	•	•	•	•	•	•	•	Extended Reset	251
#WAKE	•	•	•	•	•	•	•	•	•	Wake From Alarm Mode	251
#QTEMP	•	•	•	•	•	•	•	•	•	Query Temperature Overflow	253
#TEMPMON	•	•	•	•	•	•	•	•	•	Temperature Monitor	254
#SGPO	•	•	•	•	•	•	•	•	•	Set General Purpose Output	256
#GGPI	•	•	•	•	•	•	•	•	•	General Purpose Input	256
#GPIO	•	•	•	•	•	•	•	•	•	General Purpose Input/Output Pin Control	257
#SLED	•	•	•	•	•	•	•	•	•	STAT_LED GPIO Setting	261
#SLEDSAV	•	•	•	•	•	•	•	•	•	Save STAT_LED GPIO Setting	261
#DVI	•	•	•	•	•	•	•	•	•	Digital Voiceband Interface	261
#E2SMSRI	•	•	•	•	•	•	•	•	•	SMS Ring Indicator	262
#ADC	•	•	•	•	•	•	•	•	•	Analog/Digital Converter Input	263
#DAC				•	•	•	•	•	•	Digital/Analog Converter Control	265
#VAUX				•	•	•	•	•	•	Auxiliary Voltage Output Control	266
#VAUXSAV				•	•	•	•	•	•	#VAUX Saving	268
#V24CFG	•	•	•	•	•	•	•	•	•	V24 Output Pins Configuration	268
#V24	•	•	•	•	•	•	•	•	•	V24 Output Pins Control	268
#AXE	•	•	•	•	•	•	•	•	•	AXE Pin Reading	269
#TXMONMODE	•	•	•	•	•	•	•	•	•	TTY-CTM-DSP Operating Mode	270
#CBC	•	•	•	•	•	•	•	•	•	Battery and Charger Status	270
#AUTOATT	•	•	•	•	•	•	•	•	•	GPRS Auto-Attach Property	271
#MSCCLASS	•	•	•	•	•	•	•	•	•	Multislot Class Control	272
#MONI	•	•	•	•	•	•	•	•	•	Cell Monitor	273
#SERVINFO	•	•	•	•	•	•	•	•	•	Serving Cell Information	278
#COPSMODE	•	•	•	•	•	•	•	•	•	+COPS Mode	279
#QSS	•	•	•	•	•	•	•	•	•	Query SIM Status	280
#DIALMODE	•	•	•	•	•	•	•	•	•	ATD Dialing Mode	281
#ACAL	•	•	•	•	•	•	•	•	•	Automatic Call	283
#ACALEXT	•	•	•	•	•	•	•	•	•	Extended Automatic Call	284
#ECAM	•	•	•	•	•	•	•	•	•	Extended Call Monitoring	284
#SMOV	•	•	•	•	•	•	•	•	•	SMS Overflow	286
#MBN	•	•	•	•	•	•	•	•	•	Mailbox Numbers	287
#MWI	•	•	•	•	•	•	•	•	•	Message Waiting Indicator	288
#CODEC	•	•	•	•	•	•	•	•	•	Audio Codec	289
#SHFEC	•	•	•	•	•	•	•	•	•	Handsfree Echo Cancellor	290
#HFMICG	•	•	•	•	•	•	•	•	•	Handsfree Microphone Gain	291
#HSMICG	•	•	•	•	•	•	•	•	•	Handset Microphone Gain	292
#SHFSD	•	•	•	•	•	•	•	•	•	Set Headset Sidetone	293
#SPKMUT	•	•	•	•	•	•	•	•	•	Speaker Mute Control	294
#HFRECG	•	•	•	•	•	•	•	•	•	Handsfree Receiver Gain	294
#HSRECG	•	•	•	•	•	•	•	•	•	Handset Receiver Gain	294
#PRST	•	•	•	•	•	•	•	•	•	Audio Profile Factory Configuration	295



AT Commands Reference Guide

80000ST10025a Rev. 5 - 09/07/08

COMMAND	GM862-QUAD	GM862-QUAD-PY	GM862-GPS	GE863-QUAD & GE863-PRO ²	GE863-PY & GE863-SIM	GE863-GPS	GE864-AUTO	GE864-QUAD & GC864-QUAD	GC864-PY & GE864-PY	Function	Page
#PSAV	•	•	•	•	•	•	•	•	•	Audio Profile Configuration Save	295
#PSEL	•	•	•	•	•	•	•	•	•	Audio Profile Selection	296
#PSET	•	•	•	•	•	•	•	•	•	Audio Profile Setting	296
#SHFAGC	•	•	•	•	•	•	•	•	•	Handsfree Automatic Gain Control	297
#SHFNR	•	•	•	•	•	•	•	•	•	Handsfree Noise Reduction	297
#SHSAGC	•	•	•	•	•	•	•	•	•	Handset Automatic Gain	298
#SHSEC	•	•	•	•	•	•	•	•	•	Handset Echo Canceller	298
#SHSNR	•	•	•	•	•	•	•	•	•	Handset Noise Reduction	299
#SHSSD	•	•	•	•	•	•	•	•	•	Set Handset Sidetone	299
#/	•	•	•	•	•	•	•	•	•	Repeat Last Command	299
#NITZ	•	•	•	•	•	•	•	•	•	Network Timezone	299
#ENS	•	•	•	•	•	•	•	•	•	Enhanced Network Selection	301
#BND	•	•	•	•	•	•	•	•	•	Select Band	302
#AUTOBND	•	•	•	•	•	•	•	•	•	Automatic Band Selection	303
#SKIPESC	•	•	•	•	•	•	•	•	•	Skip Escape Sequence	304
#E2ESC	•	•	•	•	•	•	•	•	•	Escape Sequence Guard Time	305
#GAUTH	•	•	•	•	•	•	•	•	•	PPP-GPRS Connection Authentication Type	306
#GPPPCFG	•	•	•	•	•	•	•	•	•	PPP-GPRS Parameters Configuration	307
#RTCSTAT	•	•	•	•	•	•	•	•	•	RTC Status	308
#GSMAD	•	•	•	•	•	•	•	•	•	GSM Antenna Detection	309
#SIMDET	•	•	•	•	•	•	•	•	•	SIM Detection Mode	310
#ENHSIM	•	•	•	•	•	•	•	•	•	SIM Enhanced Speed	311
#TTY	•	•	•	•	•	•	•	•	•	Teletype Writer Support	312
#CPUMODE	•	•	•	•	•	•	•	•	•	CPU Clock Mode	312
#GSMCONT	•	•	•	•	•	•	•	•	•	GSM Context Definition	312
#CGPADDR	•	•	•	•	•	•	•	•	•	Show Address	313
#NWSCANTMR	•	•	•	•	•	•	•	•	•	Network Selection Timer	314
Custom AT Commands - General Configuration - Special Issues											
#OSC32KHZ							•			External 32kHz Oscillator	315
Custom AT Commands - Multisocket											
#SS	•	•	•	•	•	•	•	•	•	Socket Status	315
#SI	•	•	•	•	•	•	•	•	•	Socket Info	316
#SGACT	•	•	•	•	•	•	•	•	•	Context Activation	317
#SH	•	•	•	•	•	•	•	•	•	Socket Shutdown	318
#SCFG	•	•	•	•	•	•	•	•	•	Socket Configuration	319
#SCFGEXT	•	•	•	•	•	•	•	•	•	Socket Configuration Extended	320
#SD	•	•	•	•	•	•	•	•	•	Socket Dial	321
#SO	•	•	•	•	•	•	•	•	•	Socket Restore	322
#SL	•	•	•	•	•	•	•	•	•	Socket Listen	323
#SA	•	•	•	•	•	•	•	•	•	Socket Accept	323
#SRECV	•	•	•	•	•	•	•	•	•	Receive Data In Command Mode	324
#SEND	•	•	•	•	•	•	•	•	•	Send Data In Command Mode	325
Custom AT Commands - FTP											
#FTPTO	•	•	•	•	•	•	•	•	•	FTP Time-Out	326
#FTPOPEN	•	•	•	•	•	•	•	•	•	FTP Open	326
#FTPCLOSE	•	•	•	•	•	•	•	•	•	FTP Close	327
#FTPPUT	•	•	•	•	•	•	•	•	•	FTP Put	327
#FTPGET	•	•	•	•	•	•	•	•	•	FTP Get	328
#FTPYPE	•	•	•	•	•	•	•	•	•	FTP Type	329
#FTPMSG	•	•	•	•	•	•	•	•	•	FTP Read Message	330
#FTPDELE	•	•	•	•	•	•	•	•	•	FTP Delete	330
#FTPPWD	•	•	•	•	•	•	•	•	•	FTP Print Working Directory	330
#FTPCHWD	•	•	•	•	•	•	•	•	•	FTP Change Working Directory	331
#FTPLIST	•	•	•	•	•	•	•	•	•	FTP List	331
Custom AT Commands - Enhanced Easy GPRS® Extension											
#USERID	•	•	•	•	•	•	•	•	•	Authentication User ID	332



AT Commands Reference Guide

80000ST10025a Rev. 5 - 09/07/08

COMMAND	GM862- QUAD	GM862- QUAD- PY	GM862- GPS	GE863- QUAD &GE863- PRO ²	GE863- PY & GE863- SIM	GE863- GPS	GE864- AUTO	GE864- QUAD & GC864- QUAD	GC864- PY & GE864- PY	Function	Page
#PASSW	•	•	•	•	•	•	•	•	•	Authentication Password	333
#PKTSZ	•	•	•	•	•	•	•	•	•	Packet Size	334
#DSTO	•	•	•	•	•	•	•	•	•	Data Sending Time-Out	335
#SKTTO	•	•	•	•	•	•	•	•	•	Socket Inactivity Time-Out	336
#SKTSET	•	•	•	•	•	•	•	•	•	Socket Definition	338
#SKTOP	•	•	•	•	•	•	•	•	•	Socket Open	340
#QDNS	•	•	•	•	•	•	•	•	•	Query DNS	341
#CACHEDNS	•	•	•	•	•	•	•	•	•	DNS Response Caching	342
#DNS	•	•	•	•	•	•	•	•	•	Manual DNS Selection	342
#SKTCT	•	•	•	•	•	•	•	•	•	Socket TCP Connection Time-Out	344
#SKTSAV	•	•	•	•	•	•	•	•	•	Socket Parameters Save	345
#SKTRST	•	•	•	•	•	•	•	•	•	Socket Parameters Reset	346
#GPRS	•	•	•	•	•	•	•	•	•	GPRS fext Activation	346
#SKTD	•	•	•	•	•	•	•	•	•	Socket Dial	349
#SKTL	•	•	•	•	•	•	•	•	•	Socket Listen	352
@SKTL	•	•	•	•	•	•	•	•	•	Socket Listen Improved	356
#E2SLRI	•	•	•	•	•	•	•	•	•	Socket Listen Ring Indicator	358
#FRWL	•	•	•	•	•	•	•	•	•	Firewall Setup	358
#GDATAVOL	•	•	•	•	•	•	•	•	•	GPRS Data Volume	360
#ICMP	•	•	•	•	•	•	•	•	•	ICMP Support	362
#TCPMAXDAT	•	•	•	•	•	•	•	•	•	Maximum TCP Payload Size	362
#TCPREASS	•	•	•	•	•	•	•	•	•	TCP Reassembly	363
Custom AT Commands - E-Mail Management											
#ESMTP	•	•	•	•	•	•	•	•	•	E-mail SMTP Server	363
#EADDR	•	•	•	•	•	•	•	•	•	E-mail Sender Address	364
#EUSER	•	•	•	•	•	•	•	•	•	E-mail Authentication User Name	365
#EPASSW	•	•	•	•	•	•	•	•	•	E-mail Authentication Password	366
#SEMAIL	•	•	•	•	•	•	•	•	•	E-mail Sending With GPRS Context Activation	367
#EMAILACT	•	•	•	•	•	•	•	•	•	E-mail GPRS Context Activation	369
#EMAILD	•	•	•	•	•	•	•	•	•	E-mail Sending	371
#ESAV	•	•	•	•	•	•	•	•	•	E-mail Parameters Save	373
#ERST	•	•	•	•	•	•	•	•	•	E-mail Parameters Reset	374
#EMAILMSG	•	•	•	•	•	•	•	•	•	SMTP Read Message	375
Custom AT Commands - Easy Scan® Extension											
#CSURV	•	•	•	•	•	•	•	•	•	Network Survey	375
#CSURVC	•	•	•	•	•	•	•	•	•	Network Survey (Numeric Format)	381
#CSURVU	•	•	•	•	•	•	•	•	•	Network Survey Of User Defined Channels	387
#CSURVUC	•	•	•	•	•	•	•	•	•	Network Survey Of User Defined Channels (Numeric Format)	388
#CSURVB	•	•	•	•	•	•	•	•	•	BCCH Network Survey	390
#CSURVBC	•	•	•	•	•	•	•	•	•	BCCH Network Survey (Numeric Format)	390
#CSURVF	•	•	•	•	•	•	•	•	•	Network Survey Format	391
#CSURVNLf	•	•	•	•	•	•	•	•	•	<CR><LF> Removing On Easy Scan® Commands Family	392
#CSURVEXT	•	•	•	•	•	•	•	•	•	Extended Network Survey	393
#CSURVP	•	•	•	•	•	•	•	•	•	PLMN Network Survey	393
#CSURVPC	•	•	•	•	•	•	•	•	•	PLMN Network Survey (Numeric Format)	394
Custom AT Commands - SIM Toolkit											
#STIA	•	•	•	•	•	•	•	•	•	SIM Toolkit Interface Activation	394
#STGI	•	•	•	•	•	•	•	•	•	SIM Toolkit Get Information	399
#STSR	•	•	•	•	•	•	•	•	•	SIM Toolkit Send Response	404
Jammed Detect & Report AT commands											



AT Commands Reference Guide

80000ST10025a Rev. 5 - 09/07/08

COMMAND	GM862- QUAD	GM862- QUAD- PY	GM862- GPS	GE863- QUAD &GE863- PRO ²	GE863- PY & GE863- SIM	GE863- GPS	GE864- AUTO	GE864- QUAD & GC864- QUAD	GC864- PY & GE864- PY	Function	Page
#JDR	•	•	•	•	•	•	•	•	•	Jammed Detect & Report	406
Custom AT Commands - Easy Script® Extension - Python Interpreter¹³											
#WSCRIPT		•	•		•	•	•		•	Write Script	409
#ESCRIP		•	•		•	•	•		•	Select Active Script	411
#STARTMODESCR		•	•		•	•	•		•	Script Execution Start Mode	412
#EXECSCR		•	•		•	•	•		•	Execute Active Script	414
#RSCRIPT		•	•		•	•	•		•	Read Script	414
#LSCRIPT		•	•		•	•	•		•	List Script Names	415
#DSCRIPT		•	•		•	•	•		•	Delete Script	416
#REBOOT		•	•		•	•	•		•	Reboot	417
#CMUXSCR		•	•		•	•	•		•	CMUX Interface Enable	417
Custom AT Commands - GPS Application											
\$GPSP			•			•				GPS Controller Power Management	418
\$GPSR			•							GPS Reset	419
\$GPSD			•			•				GPS Device Type Set	419
\$GPSSW			•			•				GPS Software Version	422
\$GPSAT			•			•				GPS Antenna Type Definition	420
\$GPSAV			•			•				GPS Antenna Supply Voltage Readout	421
\$GPSAI			•			•				GPS Antenna Current Readout	421
\$GPSAP			•			•				GPS Antenna Protection	421
\$GPSS ¹⁴			•			•				GPS NMEA Serial Port Speed	422
\$GPSNMUN			•			•				Unsolicited GPS NMEA Data Configuration	423
\$GPSACP			•			•				GPS Actual Position Information	424
\$GPSCON			•			•				Direct Access To GPS Module	425
\$GPSPRG			•			•				Set The GPS Module In Programming Mode	426
\$GPSPS			•			•				Set the GPS Module In Power Saving Mode	426
\$GPSWK			•			•				Wake Up GPS From Power Saving Mode	427
\$GPSAV			•			•				Save GPS Parameters Configuration	427
\$GPSRST			•			•				Restore Default GPS Parameters	427
\$GPSMODE			•			•				GPS Controller Disabled at Start-up With Charger Inserted	428
Custom AT Commands - SAP											
#RSEN	•	•	•	•	•	•	•	•	•	Remote SIM Enable	428
Custom AT Commands – Telefonica OpenGate M2M											
#OGCFG	•	•	•	•	•	•	•	•	•	OG Protocol Parameters Configuration	430
#OGPLATCFG	•	•	•	•	•	•	•	•	•	OG Platform Parameters Configuration	430
#OGBEGINMSG	•	•	•	•	•	•	•	•	•	OG Total Message Creation Start	430
#OGBEGINOGMSG	•	•	•	•	•	•	•	•	•	OGMessage Creation Start	430
#OGADDPAR	•	•	•	•	•	•	•	•	•	OGMessage Parameter Insertion	430
#OGBEGINARRY	•	•	•	•	•	•	•	•	•	OGMessage Array Insertion Start	430
#OGADDARRY	•	•	•	•	•	•	•	•	•	OGMessage Array Parameter Insertion	430
#OGENDARRAY	•	•	•	•	•	•	•	•	•	OGMessage Array Parameter Insertion End	430
#OGENDOGMSG	•	•	•	•	•	•	•	•	•	OGMessage Creation End	430
#OGABORTMSG	•	•	•	•	•	•	•	•	•	Message Creation Abort	430
#OGENDMSG	•	•	•	•	•	•	•	•	•	Message Creation End	430
#OGSENDMSG	•	•	•	•	•	•	•	•	•	Send OG Total Message	430
#OGMSGSTATUS	•	•	•	•	•	•	•	•	•	Get Pending OGMessage's Status	430
#OGRETOGMSG	•	•	•	•	•	•	•	•	•	Decode Received OGMessage	430
#OGERASEALL	•	•	•	•	•	•	•	•	•	Erase OGMessage's Status List	430
#OGMSG	•	•	•	•	•	•	•	•	•	OGMessage Received Indication	430
#OGMSGTOUT	•	•	•	•	•	•	•	•	•	OGMessage Sending Timeout Indication	430

¹³ Python is a registered trademark of the Python Software Foundation.

¹⁴ Available for the GPS products with the following Order-Num.: 3990250689 and 3990250690



3.5 AT Commands References

3.5.1 Command Line General Format

3.5.1.1 Command Line Prefixes

3.5.1.1.1 Starting A Command Line - AT

AT - Starting A Command Line		SELINT 0 / 1 / 2
AT	The prefix AT , or at , is a two-character abbreviation (ATtention), always used to start a command line to be sent from TE to TA	
Reference	GSM 07.07	

3.5.1.1.2 Last Command Automatic Repetition - A/

A/ - Last Command Automatic Repetition		SELINT 0 / 1 / 2
A/	<p>If the prefix A/ or a/ is issued, the MODULE immediately execute once again the body of the preceding command line. No editing is possible and no termination character is necessary. A command line may be repeated multiple times through this mechanism, if desired.</p> <p>If A/ is issued before any command line has been executed, the preceding command line is assumed to have been empty (that results in an OK result code).</p> <p>Note: this command works only at fixed IPR.</p> <p>Note: the custom command #/ has been defined: it causes the last command to be executed again too; but it doesn't need a fixed IPR.</p>	
Reference	V25ter	



V - Response Format	SELINT 0 / 1 / 2								
	<p>codes are transmitted in a numeric form or an alphanumeric form (see [§3.2.3 Information Responses And Result Codes] for the table of result codes).</p> <p>Parameter: <n></p> <p>0 - limited headers and trailers and numeric format of result codes</p> <table border="1" style="margin-left: 40px;"> <tr> <td>information responses</td> <td><text><CR><LF></td> </tr> <tr> <td>result codes</td> <td><numeric code><CR></td> </tr> </table> <p>1 - full headers and trailers and verbose format of result codes (factory default)</p> <table border="1" style="margin-left: 40px;"> <tr> <td>information responses</td> <td><CR><LF> <text><CR><LF></td> </tr> <tr> <td>result codes</td> <td><CR><LF> <verbose code><CR><LF></td> </tr> </table> <p>Note: the <text> portion of information responses is not affected by this setting.</p> <p>Note: if parameter is omitted, the command has the same behaviour of ATV0</p>	information responses	<text><CR><LF>	result codes	<numeric code><CR>	information responses	<CR><LF> <text><CR><LF>	result codes	<CR><LF> <verbose code><CR><LF>
information responses	<text><CR><LF>								
result codes	<numeric code><CR>								
information responses	<CR><LF> <text><CR><LF>								
result codes	<CR><LF> <verbose code><CR><LF>								
Reference	V25ter								

3.5.3.2.4 Extended Result Codes - X

X - Extended Result Codes	SELINT 0 / 1 / 2
ATX[<n>]	<p>Set command selects the result code messages subset used by the modem to inform the DTE of the result of the commands.</p> <p>Parameter: <n> - (factory default is 1)</p> <p>0 - on entering dial-mode CONNECT result code is given; OK, CONNECT, RING, NO CARRIER, ERROR, NO ANSWER result codes are enabled . Dial tone and busy detection (NO DIALTONE and BUSY result codes) are disabled.</p> <p>1..4 - on entering dial-mode CONNECT <text> result code is given; all the other result codes are enabled.</p> <p>Note: If parameter is omitted, the command has the same behaviour of</p>



&D - Data Terminal Ready (DTR) Control		SELINT 2
	<p>then AT&D1 has the same effect as AT&D2.</p> <p>Note: if AT&D2 has been issued and the DTR has been tied Low, autoanswering is inhibited and it is possible to answer only issuing command ATA.</p> <p>Note: if parameter is omitted, the command has the same behaviour of AT&D0</p>	
Reference	V25ter	

3.5.3.2.8 Standard Flow Control - \Q

\Q - Standard Flow Control		SELINT 0 / 1 / 2
AT\Q[<n>]	<p>Set command controls the RS232 flow control behaviour.</p> <p>Parameter: <n></p> <ul style="list-style-type: none"> 0 - no flow control 1 - software bi-directional with filtering (XON/XOFF) 2 - hardware mono-directional flow control (only CTS active) 3 - hardware bi-directional flow control (both RTS/CTS active) (factory default) <p>Note: if parameter is omitted, the command has the same behaviour as AT\Q0</p> <p>Note: Hardware flow control (AT\Q3) is not active in command mode.</p> <p>Note: \Q's settings are functionally a subset of &K's ones.</p>	
Reference	V25ter	

3.5.3.2.9 Flow Control - &K

&K - Flow Control		SELINT 0 / 1 / 2
AT&K[<n>]	<p>Set command controls the RS232 flow control behaviour.</p> <p>Parameter: <n></p> <ul style="list-style-type: none"> 0 - no flow control 1 - hardware mono-directional flow control (only CTS active) 2 - software mono-directional flow control (XON/XOFF) 3 - hardware bi-directional flow control (both RTS/CTS active) (factory default) 4 - software bi-directional with filtering (XON/XOFF) 5 - pass through: software bi-directional without filtering (XON/XOFF) 6 - both hardware bi-directional flow control (both RTS/CTS active) and 	



+IPR - Fixed DTE Interface Rate		SELINT 2
	38400 57600 115200 If <rate> is set to 0, then automatic speed detection is enabled and also character format (see +ICF) is set to auto-detect. (default) If <rate> is specified and not 0, DTE-DCE speed is fixed at that speed, hence no speed auto-detection (autobauding) is enabled. Note: While in autobauding mode the 300 baud rate is not supported.	
AT+IPR?	Read command returns the current value of +IPR parameter.	
AT+IPR=?	Test command returns the list of supported autodetectable <rate> values and the list of fixed-only <rate> values in the format: +IPR: (list of supported autodetectable <rate> values), (list of fixed-only <rate> values)	
Reference	V25ter	

3.5.3.2.13 DTE-Modem Local Flow Control - +IFC

+IFC - DTE-Modem Local Flow Control		SELINT 0 / 1 / 2
AT+IFC=<by_te>, <by_ta>	Set command selects the flow control behaviour of the serial port in both directions: from DTE to modem (<by_ta> option) and from modem to DTE (<by_te>) Parameters: <by_te> - flow control option for the data received by DTE 0 - flow control None 1 - XON/XOFF filtered 2 - C105 (RTS) (factory default) 3 - XON/XOFF not filtered <by_ta> - flow control option for the data sent by modem 0 - flow control None 1 - XON/XOFF 2 - C106 (CTS) (factory default) Note: Hardware flow control (AT+IFC=2,2) is not active in command mode. Note: This command is equivalent to &K command.	
AT+IFC?	Read command returns active flow control settings. Note: If flow control behavior has been set with AT&Kn command with the parameter that is not allowed by AT+IFC the read command AT+IFC? will return: +IFC: 0,0	



+IFC - DTE-Modem Local Flow Control		SELINT 0 / 1 / 2
AT+IFC=?	Test command returns all supported values of the parameters <by_te> and <by_ta> .	
Reference	V25ter	

3.5.3.2.14 DTE-Modem Local Rate Reporting - +ILRR

+ILRR - DTE-Modem Local Rate Reporting		SELINT 0 / 1 / 2
AT+ILRR=<n>	Set command controls whether or not the +ILRR: <rate> information text is transmitted from the modem (module) to the DTE . Parameter: <n> 0 - local port speed rate reporting disabled (factory default) 1 - local port speed rate reporting enabled Note: If AT+IPR=0 (in autobauding) local port speed reported will be 0. Note: this information if enabled is sent upon connection.	
AT+ILRR?	Read command returns active setting of <n> .	
AT+ILRR=?	Test command returns all supported values of the parameter <n>	
Reference	V25ter	

3.5.3.2.15 DTE-Modem Character Framing - +ICF

+ICF - DTE-Modem Character Framing		SELINT 0 / 1 / 2
AT+ICF=<format> [,<parity>]	Set command defines the asynchronous character framing to be used when autobauding is disabled. Parameters: <format> - determines the number of bits in the data bits, the presence of a parity bit, and the number of stop bits in the start-stop frame. 0 - autodetection 1 - 8 Data, 2 Stop 2 - 8 Data, 1 Parity, 1 Stop 3 - 8 Data, 1 Stop 5 - 7 Data, 1 Parity, 1 Stop <parity> - determines how the parity bit is generated and checked, if present; setting this subparameter is mandatory and has a meaning only if <format> subparameter is either 2 or 5. 0 - Odd 1 - Even	
AT+ICF?	Read command returns current settings for subparameters <format> and <parity> . If current setting of subparameter <format> is neither 2 nor 5, the current setting of subparameter <parity> will always be represented as 0.	
AT+ICF=?	Test command returns the ranges of values for the parameters <format> and <parity>	
Reference	V25ter	



O - Return To On Line Mode		SELINT 2
	Note: After issuing this command, if the device is in conversation, to send other commands to the device you must return to command mode by issuing the escape sequence (see register S2) or tying low DTR pin if &D1 option is active.	
Reference	V25ter.	

3.5.3.3.7 Guard Tone - &G

&G - Guard Tone		SELINT 0 / 1 / 2
AT&G	Set command has no effect is included only for backward compatibility with landline modems.	

3.5.3.3.8 Sync/Async Mode - &Q

&Q - Sync/Async Mode		SELINT 0 / 1 / 2
AT&Q	Set command has no effect is included only for backward compatibility with landline modems.	

3.5.3.4 Modulation Control

3.5.3.4.1 Modulation Selection - +MS

+MS - Modulation Selection		SELINT 0 / 1 / 2
AT+MS= <carrier> [,<automode> [,<min_rate> [,<max_rate>]]]	<p>Set command has no effect is included only for backward compatibility with landline modems.</p> <p>Parameters:</p> <p><carrier> - a string which specifies the preferred modem carrier to use in originating or answering a connection</p> <p>V21 V22 V22B V23C V32 V34</p> <p><automode> - it enables/disables automatic modulation negotiation. 0 - disabled 1 - enabled. It has effect only if it is defined for the associated modulation.</p> <p><min_rate> - it specifies the lowest value at which the DCE may establish a connection. 0 - unspecified</p> <p><max_rate> - it specifies the highest value at which the DCE may establish a connection. 0 - unspecified 300..14400 - rate in bps</p>	



+DR - Data Compression Reporting		SELINT 0 / 1 / 2
AT+DR?	Read command returns current value of <n>.	
AT+DR=?	Test command returns all supported values of the parameter <n>	
Reference	V25ter	

3.5.3.6 Break Control

3.5.3.6.1 Transmit Break To Remote - \B

\B - Transmit Break To Remote		SELINT 0 / 1 / 2
AT\b	Execution command has no effect and is included only for backward compatibility with landline modems	

3.5.3.6.2 Break Handling - \K

\K - Break Handling		SELINT 0
ATK<n>	Execution command has no effect and is included only for backward compatibility with landline modems	
	Parameter: <n> 1..5	

\K - Break Handling		SELINT 1 / 2
ATK[<n>]	Execution command has no effect and is included only for backward compatibility with landline modems	
	Parameter: <n> 0..5	

3.5.3.6.3 Operating Mode - \N

\N - Operating Mode		SELINT 0 / 1 / 2
ATN[<n>]	Set command set the connection element to be used when data calls are originated (see +CBST).	
	Parameter: <n> 0 - transparent 1..6 - non-transparent	
	Note: issuing ATN<CR> is the same as AT\N0<CR>	



3.5.3.7.6 Command Line Editing Character - S5

S5 - Command Line Editing Character		SELINT 0 / 1
ATS5=[<char>]	Set command sets the value of the character recognized by the device as a request to delete from the command line the immediately preceding character. Parameter: <char> - command line editing character (decimal ASCII) 0..127 - factory default value is 8 (ASCII BS).	
ATS5?	Read command returns the current value of S5 parameter.	
ATS5=?	Test command returns the range for <char> without command echo and parenthesis.	
Note	For either Read and Test command the format of the numbers in output is always 3 digits, left-filled with 0s	
Reference	V25ter	

S5 - Command Line Editing Character		SELINT 2
ATS5=[<char>]	Set command sets the value of the character recognized by the device as a request to delete from the command line the immediately preceding character. Parameter: <char> - command line editing character (decimal ASCII) 0..127 - factory default value is 8 (ASCII BS)	
ATS5?	Read command returns the current value of S5 parameter. Note: the format of the numbers in output is always 3 digits, left-filled with 0s	
Reference	V25ter	

3.5.3.7.7 Connection Completion Time-Out - S7

S7 - Connection Completion Time-Out		SELINT 0 / 1
ATS7=[<tout>]	Set command sets the amount of time, in seconds, that the device shall allow between either answering a call (automatically or by A command) or completion of signalling of call addressing information to network (dialling), and establishment of a connection with the remote device. Parameter: <tout> - number of seconds 1..255 - factory default value is 60.	
ATS7?	Read command returns the current value of S7 parameter.	
ATS7=?	Test command returns the range for <tout> without command echo and parenthesis.	
Note	For either Read and Test command the format of the numbers in output is always 3 digits, left-filled with 0s	
Reference	V25ter	



S12 - Escape Prompt Delay		SELINT 2
ATS12=[<time>]	<p>Set command sets:</p> <ol style="list-style-type: none"> 1) the minimum period, before receipt of the first character of the three escape character sequence, during which no other character has to be detected in order to accept it as valid first character; 2) the maximum period allowed between receipt of first or second character of the three escape character sequence and receipt of the next; 3) the minimum period, after receipt of the last character of the three escape character sequence, during which no other character has to be detected in order to accept the escape sequence as a valid one. <p>Parameter: <time> - expressed in fiftieth of a second 20..255 - factory default value is 50.</p> <p>Note: the minimum period S12 has to pass after CONNECT result code too, before a received character is accepted as valid first character of the three escape character sequence.</p>	
ATS12?	<p>Read command returns the current value of S12 parameter.</p> <p>Note: the format of the numbers in output is always 3 digits, left-filled with 0s</p>	

3.5.3.7.3 Delay To DTR Off - S25

S25 - Delay To DTR Off		SELINT 0 / 1
ATS25=[<time>]	<p>Set command defines the amount of time, in hundredths of second, that the device will ignore the DTR for taking the action specified by command &D.</p> <p>Parameter: <time> - expressed in hundredths of a second 0..255 - factory default value is 5.</p> <p>Note: the delay is effective only if its value is greater than 5.</p>	
ATS25?	<p>Read command returns the current value of S25 parameter.</p>	
ATS25=?	<p>Test command returns the range for <time> without command echo and parenthesis.</p> <p>Note: the output depends on the choice made through #SELINT command.</p>	
Note	<p>For either Read and Test command the format of the numbers in output is always 3 digits, left-filled with 0s</p>	

S25 -Delay To DTR Off		SELINT 2
ATS25=[<time>]	<p>Set command defines the amount of time, in hundredths of second, that the device will ignore the DTR for taking the action specified by command &D.</p>	



3.5.4 ETSI GSM 07.07 AT Commands

3.5.4.1 General

3.5.4.1.1 Request Manufacturer Identification - +CGMI

+CGMI - Request Manufacturer Identification		SELINT 0 / 1
AT+CGMI	Execution command returns the device manufacturer identification code without command echo. The output depends on the choice made through #SELINT command.	
AT+CGMI?	Read command has the same behaviour as Execution command	
Reference	GSM 07.07	

+CGMI - Request Manufacturer Identification		SELINT 2
AT+CGMI	Execution command returns the device manufacturer identification code without command echo. The output depends on the choice made through #SELINT command.	
AT+CGMI=?	Test command returns OK result code.	
Reference	GSM 07.07	

3.5.4.1.2 Request Model Identification - +CGMM

+CGMM - Request Model Identification		SELINT 0 / 1
AT+CGMM	Execution command returns the device model identification code without command echo.	
Reference	GSM 07.07	

+CGMM - Request Model Identification		SELINT 2
AT+CGMM	Execution command returns the device model identification code without command echo.	
AT+CGMM=?	Test command returns OK result code.	
Reference	GSM 07.07	

3.5.4.1.3 Request Revision Identification - +CGMR

+CGMR - Request Revision Identification		SELINT 0 / 1
AT+CGMR	Execution command returns device software revision number without command echo.	
AT+CGMR?	Read command has the same behaviour as Execution command	
Reference	GSM 07.07	

+CGMR - Request Revision Identification		SELINT 2
AT+CGMR	Execution command returns device software revision number without command echo.	
AT+CGMR=?	Test command returns OK result code.	



+CSCS - Select TE Character Set		SELINT 2
	Parameter: <chset> - character set "GSM" - GSM default alphabet (GSM 03.38) "IRA" - international reference alphabet (ITU-T T.50) "8859-1" - ISO 8859 Latin 1 character set "PCCP437" - PC character set Code Page 437 "UCS2" - 16-bit universal multiple-octet coded character set (ISO/IEC10646)	
AT+CSCS?	Read command returns the current value of the active character set.	
AT+CSCS=?	Test command returns the supported values for parameter <chset> .	
Reference	GSM 07.07	

3.5.4.1.6 Request International Mobile Subscriber Identity (IMSI) - +CIMI

+CIMI - Request International Mobile Subscriber Identify (IMSI)		SELINT 0 / 1
AT+CIMI	Execution command returns the value of the Internal Mobile Subscriber Identity stored in the SIM without command echo. Note: a SIM card must be present in the SIM card housing, otherwise the command returns ERROR .	
AT+CIMI?	Read command has the same behaviour as Execution command	
Reference	GSM 07.07	

+CIMI - Request International Mobile Subscriber Identify (IMSI)		SELINT 2
AT+CIMI	Execution command returns the value of the Internal Mobile Subscriber Identity stored in the SIM without command echo. Note: a SIM card must be present in the SIM card housing, otherwise the command returns ERROR .	
AT+CIMI=?	Test command returns OK result code.	
Reference	GSM 07.07	

3.5.4.1.7 Multiplexing Mode - +CMUX

+CMUX - Multiplexing Mode		SELINT 2
AT+CMUX= <mode> [,<subset>]	Set command is used to enable/disable the GSM 07.10 multiplexing protocol control channel. Parameters: <mode> multiplexer transparency mechanism 0 - basic option; it is currently the only supported value. <subset> 0 - UIH frames used only; it is currently the only supported value. Note: after entering the Multiplexed Mode an inactive timer of five seconds	



+CR - Service Reporting Control		SELINT 0 / 1 / 2
	enabled, in the format: +CR: <mode>	
AT+CR=?	Test command returns the supported range of values of parameter <mode>.	
Reference	GSM 07.07	

3.5.4.2.5 Extended Error Report - +CEER

+CEER - Extended Error Report		SELINT 0 / 1
AT+CEER	<p>Execution command returns one or more lines of information text <report> offering the TA user an extended error report, in the format:</p> <p>+CEER: <report></p> <p>This report regards some error condition that may occur:</p> <ul style="list-style-type: none"> • the failure in the last unsuccessful call setup (originating or answering) • the last call release • the last unsuccessful GPRS attach or unsuccessful PDP context activation, • the last GPRS detach or PDP context deactivation. <p>Note: if none of the previous conditions has occurred since power up then "No error" condition is reported</p>	
AT+CEER?	Read command reports a information text regarding some error condition that may occur	
AT+CEER=?	Test command returns OK result code.	
Reference	GSM 07.07, GSM 04.08	

+CEER - Extended Error Report		SELINT 2
AT+CEER	<p>Execution command returns one or more lines of information text <report> offering the TA user an extended error report, in the format:</p> <p>+CEER: <report></p> <p>This report regards some error condition that may occur:</p> <ul style="list-style-type: none"> • the failure in the last unsuccessful call setup (originating or answering) • the last call release • the last unsuccessful GPRS attach or unsuccessful PDP context activation, • the last GPRS detach or PDP context deactivation. <p>Note: if none of the previous conditions has occurred since power up then "Normal, unspecified" condition is reported</p>	



+CEER - Extended Error Report		SELINT 2
AT+CEER=?	Test command returns OK result code.	
Reference	GSM 07.07, GSM 04.08	

3.5.4.2.6 Cellular Result Codes - +CRC

+CRC - Cellular Result Codes		SELINT 0 / 1
AT+CRC=<mode>	<p>Set command controls whether or not the extended format of incoming call indication is used.</p> <p>Parameter: <mode> 0 - disables extended format reporting (factory default) 1 - enables extended format reporting</p> <p>When enabled, an incoming call is indicated to the TE with unsolicited result code:</p> <p>+CRING:<type></p> <p>instead of the normal RING.</p> <p>where <type> - call type: DATA FAX - facsimile (TS 62) VOICE - normal voice (TS 11)</p>	
AT+CRC?	Read command returns current value of the parameter <mode> .	
AT+CRC=?	Test command returns supported values of the parameter <mode> .	
Reference	GSM 07.07	

+CRC - Cellular Result Codes		SELINT 2
AT+CRC= [<mode>]	<p>Set command controls whether or not the extended format of incoming call indication is used.</p> <p>Parameter: <mode> 0 - disables extended format reporting (factory default) 1 - enables extended format reporting:</p> <p>When enabled, an incoming call is indicated to the TE with unsolicited result code</p> <p>+CRING: <type></p> <p>instead of the normal RING.</p>	



+CVHU - Voice Hang Up Control		SELINT 0 / 1
	(factory default). Note: if parameter <mode> is omitted the behaviour of Set command is the same as Read command.	
AT+CVHU?	Read command reports the current value of the <mode> parameter, +CVHU: <mode>	
AT+CVHU=?	Test command reports the range of supported values for parameter <mode>	

+CVHU - Voice Hang Up Control		SELINT 2
AT+CVHU=[<mode>]	Set command selects whether ATH or " drop DTR " shall cause a voice connection to be disconnected or not. Parameter: <mode> 0 - " Drop DTR " ignored but OK result code given. ATH disconnects. 1 - " Drop DTR " and ATH ignored but OK result code given. 2 - " Drop DTR " behaviour according to &D setting. ATH disconnects (factory default).	
AT+CVHU?	Read command reports the current value of the <mode> parameter, in the format: +CVHU: <mode>	
AT+CVHU=?	Test command reports the range of supported values for parameter <mode>	

3.5.4.3 Network Service Handling

3.5.4.3.1 Subscriber Number - **+CNUM**

+CNUM - Subscriber Number		SELINT 0 / 1
AT+CNUM	Execution command returns the MSISDN (if the phone number of the device has been stored in the SIM card) in the format: +CNUM: <number>,<type> where <number> - string containing the phone number in the format <type> <type> - type of number: 129 - national numbering scheme 145 - international numbering scheme (contains the character "+").	
Reference	GSM 07.07	

+CNUM - Subscriber Number		SELINT 2
AT+CNUM		
	If the ENS functionality has not been	



+CREG - Network Registration Report		SELINT 2
	<p>(the MODULE is in network searching state)</p> <pre>at+creg? +CREG: 0,2 OK at+creg? +CREG: 0,2 OK at+creg? +CREG: 0,2 OK at+creg? +CREG: 0,1 OK (the MODULE is registered) at+creg? +CREG: 0,1 OK</pre>	
Reference	GSM 07.07	
Note	<p>There are situations in which the presentation of the URC controlled by +CREG is slightly different from ETSI specifications: e.g. it is possible to have an excessive presentation of the URC +CREG: 4. We identified this behaviour and decided to maintain it as default for backward compatibility issues. It is indeed possible to avoid it simply issuing AT#REGMODE=1 (see #REGMODE): this puts the Operation Mode of Registration Status Commands in 'Enhanced Registration Operation Mode' which is more formal.</p>	

3.5.4.3.4 Operator Selection - +COPS

+COPS - Operator Selection		SELINT 0 / 1
AT+COPS[= <mode> [,<format> [,<oper>]]]	<p>Set command forces an attempt to select and register the GSM network operator.</p> <p><mode> parameter defines whether the operator selection is done automatically or it is forced by this command to operator <oper>. The operator <oper> shall be given in format <format>.</p> <p>The behaviour of +COPS command depends on the last #COPSMODE setting.</p> <p style="text-align: center;">(#COPSMODE=0)</p> <p>Parameters: <mode> 0 - automatic choice (the parameter <oper> will be ignored) (factory</p>	



+COPS - Operator Selection	SELINT 0 / 1
	<p>Note: issuing AT+COPS<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT+COPS=<CR> is the same as issuing the command AT+COPS=0<CR>.</p>
AT+COPS?	<p>Read command returns current value of <mode>,<format> and <oper> in format <format>; if no operator is selected, <format> and <oper> are omitted</p> <p>+COPS: <mode>[, <format>, <oper>]</p>
AT+COPS=?	<p>Test command returns a list of quadruplets, each representing an operator present in the network.</p> <p>The behaviour of Test command depends on the last #COPSMODE setting.</p> <p style="text-align: center;">(#COPSMODE=0)</p> <p>The command outputs as many rows as the number of quadruplets, each of them in the format:</p> <p>+COPS: (<stat> ,<oper (in <format>=0)> ,"" ,<oper (in <format>=2)>)</p> <p>where <stat> - operator availability 0 - unknown 1 - available 2 - current 3 - forbidden</p> <p style="text-align: center;">(#COPSMODE=1)</p> <p>The quadruplets in the list are separated by commas:</p> <p>+COPS: [list of supported (<stat> ,<oper (in <format>=0)>) ,<oper (in <format>=2)>)s][, ,(list of supported <mode>s) , (list of supported<format>s)]</p> <p>where <stat> - operator availability 0 - unknown 1 - available 2 - current 3 - forbidden</p> <p>Note: since with this command a network scan is done, this command may require some seconds before the output is given.</p> <p>Note: The value of parameter <oper> (in <format>=0) is the same as the</p>



+COPS - Operator Selection		SELINT 0 / 1
	1 - available 2 - current 3 - forbidden Note: since with this command a network scan is done, this command may require some seconds before the output is given.	
Reference	GSM 07.07	

3.5.4.3.5 Facility Lock/Unlock - +CLCK

+CLCK - Facility Lock/Unlock		SELINT 0 / 1
AT+CLCK= <fac>,<mode> [,<passwd> [,<class>]]	<p>Execution command is used to lock or unlock a ME o a network facility.</p> <p>Parameters:</p> <p><fac> - facility "SC" - SIM (PIN request) (device asks SIM password at power-up and when this lock command issued) "AO"- BAOB (Barr All Outgoing Calls) "OI" - BOIC (Barr Outgoing International Calls) "OX" - BOIC-exHC (Barr Outgoing International Calls except to Home Country) "AI" - BAIC (Barr All Incoming Calls) "IR" - BIC-Roam (Barr Incoming Calls when Roaming outside the home country) "AB" - All Barring services (applicable only for <mode>=0) "AG" - All outGoing barring services (applicable only for <mode>=0) "AC" - All inComing barring services (applicable only for <mode>=0) "FD" - SIM fixed dialling memory feature (if PIN2 authentication has not been done during the current session, PIN2 is required as <passwd>) "PN" - network Personalisation "PU" - network subset Personalisation</p> <p><mode> - defines the operation to be done on the facility 0 - unlock facility 1 - lock facility 2 - query status</p> <p><passwd> - shall be the same as password specified for the facility from the DTE user interface or with command Change Password +CPWD</p> <p><class> - sum of integers each representing a class of information (default is 7) 1- voice (telephony) 2 - data (refers to all bearer services) 4 - fax (facsimile services)</p>	



+CLCK - Facility Lock/Unlock	SELINT 2
	<p><mode> - defines the operation to be done on the facility 0 - unlock facility 1 - lock facility 2 - query status</p> <p><passwd> - shall be the same as password specified for the facility from the DTE user interface or with command Change Password +CPWD</p> <p><class> - sum of integers each representing a class of information (default is 7) 1 - voice (telephony) 2 - data (refers to all bearer services) 4 - fax (facsimile services) 8 - short message service 16 - data circuit sync 32 - data circuit async 64 - dedicated packet access 128 - dedicated PAD access</p> <p>Note: when <mode>=2 and command successful, it returns: +CLCK: <status>[,<class1>[<CR><LF>+CLCK: <status>,<class2>[...]]]</p> <p>where <status> - the current status of the facility 0 - not active 1 - active <classn> - class of information of the facility</p>
AT+CLCK=?	Test command reports all the facilities supported by the device.
Reference	GSM 07.07
Example	<p><i>Querying such a facility returns an output on three rows, the first for voice, the second for data, the third for fax:</i></p> <pre>AT+CLCK="AO",2 +CLCK: <status>,1 +CLCK: <status>,2 +CLCK: <status>,4</pre>

3.5.4.3.6 Facility Improved Lock/Unlock - @CLCK

@CLCK - Facility Improved Lock/Unlock	SELINT 0 / 1
AT@CLCK= <fac>,<mode> [,<passwd> [,<class>]]	<p>Execution command is used to lock or unlock a ME o a network facility.</p> <p>Parameters: <fac> - facility "SC" - SIM (PIN request) (device asks SIM password at power-up and when this lock command issued)</p>



+CCWA - Call Waiting	SELINT 2
	<p>Note: the response to the query command is in the format:</p> <p>+CCWA: <status>,<class1>[<CR><LF> +CCWA: <status>,<class2>[...]]</p> <p>where <status> represents the status of the service: 0 - inactive 1 - active <classn> - same as <class></p> <p>Note: the unsolicited result code enabled by parameter <n> is in the format::</p> <p>+CCWA: <number>,<type>,<class>,[<alpha>][,<cli_validity>] where: <number> - string type phone number of calling address in format specified by <type> <type> - type of address in integer format <class> - see before <alpha> - string type; alphanumeric representation of <number> corresponding to the entry found in phonebook; used character set should be the one selected with +CSCS. <cli_validity> 0 - CLI valid 1 - CLI has been withheld by the originator 2 - CLI is not available due to interworking problems or limitations of originating network</p> <p>Note: if parameter <cmd> is omitted then network is not interrogated.</p> <p>Note: in the query command the class parameter must not be issued.</p> <p>Note: the difference between call waiting report disabling (AT+CCWA = 0,1,7) and call waiting service disabling (AT+CCWA = 0,0,7) is that in the first case the call waiting indication is sent to the device by network but this last one does not report it to the DTE; instead in the second case the call waiting indication is not generated by the network. Hence the device results busy to the third party in the 2nd case while in the 1st case a ringing indication is sent to the third party.</p> <p>Note: The command AT+CCWA=1,0 has no effect a non sense and must not be issued..</p>
AT+CCWA?	Read command reports the current value of the parameter <n> .
AT+CCWA=?	Test command reports the supported values for the parameter <n> .
Reference	GSM 07.07



3.5.4.3.12 Call Holding Services - +CHLD

+CHLD - Call Holding Services		SELINT 0 / 1
AT+CHLD=<n>	<p>Execution command controls the network call hold service. With this service it is possible to disconnect temporarily a call and keep it suspended while it is retained by the network, contemporary it is possible to connect another party or make a multiparty connection.</p> <p>Parameter: <n></p> <ul style="list-style-type: none"> 0 - releases all held calls, or sets the UDUB (User Determined User Busy) indication for a waiting call. 1 - releases all active calls (if any exist), and accepts the other (held or waiting) call 1X - releases a specific active call X 2 - places all active calls (if any exist) on hold and accepts the other (held or waiting) call. 2X - places all active calls on hold except call X with which communication shall be supported 3 - adds an held call to the conversation <p>Note: "X" is the numbering (starting with 1) of the call given by the sequence of setting up or receiving the calls (active, held or waiting) as seen by the served subscriber. Calls hold their number until they are released. New calls take the lowest available number.</p> <p>Note: where both a held and a waiting call exist, the above procedures apply to the waiting call (i.e. not to the held call) in conflicting situation.</p>	
AT+CHLD=?	<p>Test command returns the list of supported <n>s.</p> <p>+CHLD: (0,1,2,3)</p> <p>Note: consider what has been written about the Set command relating the actions on a specific call (X).</p>	
Reference	GSM 07.07	
Note	ONLY for VOICE calls	

+CHLD - Call Holding Services		SELINT 2
AT+CHLD=[<n>]	<p>Execution command controls the network call hold service. With this service it is possible to disconnect temporarily a call and keep it suspended while it is retained by the network, contemporary it is possible to connect another party or make a multiparty connection.</p> <p>Parameter: <n></p> <ul style="list-style-type: none"> 0 - releases all held calls, or sets the UDUB (User Determined User Busy) indication for a waiting call. (only from version D) 	



+CAOC - Advice Of Charge		SELINT 0 / 1
	<p>+CCCM: <ccm></p> <p>where: <ccm> - current call meter in home units, string type: three bytes of the CCM value in hexadecimal format (e.g. "00001E" indicates decimal value 30)</p> <p>Note: the unsolicited result code +CCCM is sent when the CCM value changes, but not more than every 10 seconds.</p> <p>Note: issuing AT+CAOC<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT+CAOC=<CR> is the same as issuing the command AT+CAOC=0<CR>.</p>	
AT+CAOC?	<p>Read command reports the value of parameter <mode> in the format:</p> <p>+CAOC: <mode></p>	
AT+CAOC=?	<p>Test command reports the supported values for <mode> parameter.</p> <p>Note: the representation format doesn't match the v.25ter §5.7.3 "Information text formats for test commands". The output is:</p> <p>+CAOC: 0, 1, 2</p>	
Reference	GSM 07.07	
Note	+CAOC command returns an estimate of the cost of the current call only, produced by the MS and based on the information provided by either AoCI or AOCC supplementary services; it is not stored in the SIM.	

+CAOC - Advice Of Charge		SELINT 2
AT+CAOC=<mode>	<p>Set command refers to the Advice of Charge supplementary services that enable subscriber to get information about the cost of calls; the command also includes the possibility to enable an unsolicited event reporting of the Current Call Meter (CCM) information.</p> <p>Parameter: <mode> 0 - query CCM value 1 - disables unsolicited CCM reporting 2 - enables unsolicited CCM reporting</p> <p>Note: the unsolicited result code enabled by parameter <mode> is in the format:</p> <p>+CCCM: <ccm></p> <p>where: <ccm> - current call meter in home units, string type: three bytes of the</p>	



+CAOC - Advice Of Charge		SELINT 2
	CCM value in hexadecimal format (e.g. "00001E" indicates decimal value 30)	
	Note: the unsolicited result code +CCCM is sent when the CCM value changes, but not more than every 10 seconds.	
AT+CAOC?	Read command reports the value of parameter <mode> in the format: +CAOC: <mode>	
AT+CAOC=?	Test command reports the supported values for <mode> parameter.	
Reference	GSM 07.07	
Note	+CAOC command returns an estimate of the cost of the current call only, produced by the MS and based on the information provided by either AoCI or AOCC supplementary services; it is not stored in the SIM.	

3.5.4.3.15 List Current Calls - +CLCC

+CLCC - List Current Calls		SELINT 0 / 1
AT+CLCC	<p>Execution command returns the list of current calls and their characteristics in the format:</p> <p>[+CLCC:<id1>,<dir>,<stat>,<mode>,<mpty>,<number>,<type> [<CR><LF>+CLCC:<id2>,<dir>,<stat>,<mode>,<mpty>,<number>,<type> e>[...]]]</p> <p>where:</p> <p><idn> - call identification number</p> <p><dir> - call direction 0 - mobile originated call 1 - mobile terminated call</p> <p><stat> - state of the call 0 - active 1 - held 2 - dialling (MO call) 3 - alerting (MO call) 4 - incoming (MT call) 5 - waiting (MT call)</p> <p><mode> - call type 0 - voice 1 - data 2 - fax 9 - unknown</p> <p><mpty> - multiparty call flag 0 - call is not one of multiparty (conference) call parties</p>	



+CLCC - List Current Calls		SELINT 2
	Note: If no call is active then only OK message is sent. This command is useful in conjunction with command +CHLD to know the various call status for call holding.	
AT+CLCC=?	Test command returns the OK result code	
Reference	GSM 07.07	

3.5.4.3.16 SS Notification - +CSSN

+CSSN - SS Notification		SELINT 0 / 1
AT+CSSN=[<n>[,<m>]]	<p>It refers to supplementary service related network initiated notifications. Set command enables/disables the presentation of notification result codes from TA to TE.</p> <p>Parameters:</p> <p><n> - sets the +CSSI result code presentation status 0 - disable 1 - enable</p> <p><m> - sets the +CSSU result code presentation status 0 - disable 1 - enable</p> <p>When <n>=1 and a supplementary service notification is received after a mobile originated call setup, an unsolicited code:</p> <p>+CSSI: <code1></p> <p>is sent to TE before any other MO call setup result codes, where: <code1>:</p> <ul style="list-style-type: none"> 1 - some of the conditional call forwarding are active 2 - call has been forwarded 3 - call is waiting 5 - outgoing calls are barred 6 - incoming calls are barred <p>When <m>=1 and a supplementary service notification is received during a mobile terminated call setup or during a call, an unsolicited result code</p> <p>+CSSU: <code2></p> <p>is sent to TE, where: <code2>:</p> <ul style="list-style-type: none"> 0 - this is a forwarded call (MT call setup) 2 - call has been put on hold (during a voice call) 3 - call has been retrieved (during a voice call) 	



+CCUG - Closed User Group Supplementary Service Control		SELINT 2
	<p><index> 0..9 - CUG index 10 - no index (preferential CUG taken from subscriber data) (default)</p> <p><info> 0 - no information (default) 1 - suppress Outgoing Access (OA) 2 - suppress preferential CUG 3 - suppress OA and preferential CUG</p>	
AT+CCUG?	Read command reports the current value of the parameters	
AT+CCUG=?	Test command returns the OK result code	
Reference	GSM 07.07	

3.5.4.3.18 Preferred Operator List - +CPOL

+CPOL - Preferred Operator List		SELINT 2
<p>AT+CPOL= [<index>][,<format> [,<oper>]]</p>	<p>Execution command writes an entry in the SIM list of preferred operators.</p> <p>Parameters: <index> - integer type; the order number of operator in the SIM preferred operator list 1..n <format> 2 - numeric <oper> <oper> - string type</p> <p>Note: if <index> is given but <oper> is left out, entry is deleted. If <oper> is given but <index> is left out, <oper> is put in the next free location. If only <format> is given, the format of the <oper> in the read command is changed.</p>	
AT+CPOL?	Read command returns all used entries from the SIM list of preferred operators.	
AT+CPOL=?	Test command returns the whole <index> range supported by the SIM and the range for the parameter <format>	
Reference	GSM 07.07	

3.5.4.4 Mobile Equipment Control

3.5.4.4.1 Phone Activity Status - +CPAS

+CPAS - Phone Activity Status		SELINT 0 / 1
AT+CPAS	<p>Execution command reports the device status in the form:</p> <p>+CPAS: <pas></p> <p>Where:</p>	



+CPAS - Phone Activity Status		SELINT 0 / 1
	<p><pas> - phone activity status</p> <ul style="list-style-type: none"> 0 - ready (device allows commands from TA/TE) 1 - unavailable (device does not allow commands from TA/TE) 2 - unknown (device is not guaranteed to respond to instructions) 3 - ringing (device is ready for commands from TA/TE, but the ringer is active) 4 - call in progress (device is ready for commands from TA/TE, but a call is in progress) 	
AT+CPAS?	Read command has the same effect as Execution command.	
AT+CPAS=?	Test command reports the supported range of values for <pas> . Note: although +CPAS is an execution command, ETSI 07.07 requires the Test command to be defined.	
Reference	GSM 07.07	

+CPAS - Phone Activity Status		SELINT 2
AT+CPAS	Execution command reports the device status in the form: +CPAS: <pas> Where: <pas> - phone activity status <ul style="list-style-type: none"> 0 - ready (device allows commands from TA/TE) 1 - unavailable (device does not allow commands from TA/TE) 2 - unknown (device is not guaranteed to respond to instructions) 3 - ringing (device is ready for commands from TA/TE, but the ringer is active) 4 - call in progress (device is ready for commands from TA/TE, but a call is in progress) 	
AT+CPAS=?	Test command reports the supported range of values for <pas> . Note: although +CPAS is an execution command, ETSI 07.07 requires the Test command to be defined.	
Example	<pre> ATD03282131321; OK AT+CPAS +CPAS: 4 the called phone has answered to your call OK ATH OK </pre>	
Reference	GSM 07.07	

3.5.4.4.2 Set Phone Functionality - +CFUN



+CFUN - Set Phone Functionality	SELINT 2
<p>AT+CFUN= [<fun>[,<rst>]]</p>	<p>Set command selects the level of functionality in the ME.</p> <p>Parameters:</p> <p><fun> - is the power saving function mode</p> <p>0 - minimum functionality, NON-CYCLIC SLEEP mode: in this mode, the AT interface is not accessible. Consequently, once you have set <fun> level 0, do not send further characters. Otherwise these characters remain in the input buffer and may delay the output of an unsolicited result code. The first wake-up event stops power saving and takes the ME back to full functionality level <fun>=1.</p> <p>1 - mobile full functionality with power saving disabled (factory default)</p> <p>2 - disable TX</p> <p>4 - disable both TX and RX</p> <p>5 - mobile full functionality with power saving enabled</p> <p><rst> - reset flag</p> <p>0 - do not reset the ME before setting it to <fun> functionality level</p> <p>Note: issuing AT+CFUN=4[,0] actually causes the module to perform either a network deregistration and a SIM deactivation.</p> <p>Note: if power saving enabled, it reduces the power consumption during the idle time, thus allowing a longer standby time with a given battery capacity.</p> <p>Note: to place the module in power saving mode, set the <fun> parameter at value = 5 and the line DTR (RS232) must be set to OFF. Once in power saving, the CTS line switch to the OFF status to signal that the module is really in power saving condition.</p> <p>During the power saving condition, before sending any AT command on the serial line, the DTR must be enabled and it must be waited for the CTS (RS232) line to go in ON status.</p> <p>Until the DTR line is ON, the module will not return back in the power saving condition.</p> <p>Note: the power saving function does not affect the network behavior of the MODULE, even during the power save condition the module remains registered on the network and reachable for incoming calls or SMS. If a call incomes during the power save, then the module will wake up and proceed normally with the unsolicited incoming call code</p>
<p>AT+CFUN?</p>	<p>Read command reports the current setting of <fun>.</p>
<p>AT+CFUN=?</p>	<p>Test command returns the list of supported values for <fun> and <rst>.</p>
<p>Reference</p>	<p>GSM 07.07</p>

3.5.4.4.3 Enter PIN - +CPIN

+CPIN - Enter PIN	SELINT 0 / 1
<p>AT+CPIN[=<pin> [,<newpin>]]</p>	<p>Set command sends to the device a password which is necessary before it can be operated (SIM PIN, SIM PUK, PH-SIM PIN, etc.).</p>



+CPIN - Enter PIN	SELINT 2		
Note	What follows is a list of the commands which are accepted when ME is pending SIM PIN or SIM PUK		
	A	#DAC	#CSURVNL
	D	#VAUX	#CSURVEXT
	H	#VAUXSAV	#JDR
	O	#CBC	#WSCRIPT
	E	#AUTOATT	#ESCRIP
	I	#MONI	#RSCRIPT
	L	#SERVINFO	#LSCRIPT
	M	#QSS	#DSCRIPT
	P	#DIALMODE	#REBOOT
	Q	#ACAL	#CMUXSCR
	S	#ACALEXT	#STARTMODESCR
	T	#CODEC	#EXECSCR
	V	#SHFEC	#RSEN
	X	#HFMICG	#CCID
	Z	#HSMICG	
	&C	#SHFSD	#PLMNMODE
	&D	#BND	#V24CFG
	&F	#AUTOBND	#V24
	&K	#RTCSTAT	+FCLASS
	&N	#USERID	+GCAP
	&P	#PASSW	+GCI
	&S	#PKTSZ	+IPR
	&V	#DSTO	+IFC
	&W	#SKTTO	+ILRR
	&Y	#SKTSET	+ICF
	&Z	#SKTOP	+MS
	%E	#SKTCT	+DS
	%L	#SKTSAV	+DR
	%Q	#SKTRST	+CGMI
	\Q	#SPKMUT	+CGMM
	\R	#ESMTP	+CGMR
	\V	#EADDR	+GMI
	#SELINT	#EUSER	+GMM
	#CGMI	#EPASSW	+GMR
	#CGMM	#SEMAIL	+CGSN
	#CGMR	#EMAILD	+GSN
	#CGSN	#ESAV	+CMUX
	#CAP	#ERST	+CHUP
	#SRS	#EMAILMSG	+CRLP
	#SRP	#CSURV	+CR
	#STM	#CSURVC	+CRC
	#PCT	#CSURVU	+CSNS
			+CPIN
			+CSQ
			+CIND
			+CMER
			+CCLK
			+CALA
			+CALD
			+CRSM
			+CALM
			+CRSL
			+CLVL
			+CMUT
			+CLAC
			+CMEE
			+CGREG
			+CBC
			+CSDH
			+CNMI
			+FMI
			+FMM
			+FMR
			+FTS
			+FRS
			+FTM
			+FRM
			+FTH
			+FRH
			+FLO
			+FPR
			+FDD
			\$GPSP
			\$GPSPS
			\$GPSR
			\$GPSD
			\$GPSSW
			\$GPSAT
			\$GPSAV
			\$GPSAI
			\$GPSAP
			\$GPSS
			\$GPSNMUN
			\$GPSACP



+CPIN - Enter PIN				SELINT 2
	#SHDN	#CSURVUC	+CREG	\$GPSWK
	#WAKE	#CSURVB	+COPS	\$GPSSAV
	#QTEMP	#CSURVBC	+CLIP	\$GPSRST
	#GPIO	#CSURVF	+CPAS	\$GPSCON
	#ADC		+CFUN	\$GPSPRG
<p>All the above commands, but the ones in the grayed cells, can be issued even if the SIM card is not inserted yet.</p> <p>All the above commands, but +CSDH and +CNMI, can be issued even if ME is waiting for phone-To-SIM card password to be given</p>				
Reference	GSM 07.07			

3.5.4.4.4 Signal Quality - +CSQ

+CSQ - Signal Quality		SELINT 0 / 1
AT+CSQ	<p>Execution command reports received signal quality indicators in the form:</p> <p>+CSQ: <rss>,<ber> where <rss> - received signal strength indication 0 - (-113) dBm or less 1 - (-111) dBm 2..30 - (-109)dBm..(-53)dBm / 2 dBm per step 31 - (-51)dBm or greater 99 - not known or not detectable</p> <p><ber> - bit error rate (in percent) 0 - less than 0.2% 1 - 0.2% to 0.4% 2 - 0.4% to 0.8% 3 - 0.8% to 1.6% 4 - 1.6% to 3.2% 5 - 3.2% to 6.4% 6 - 6.4% to 12.8% 7 - more than 12.8% 99 - not known or not detectable</p> <p>Note: this command should be used instead of the %Q and %L commands, since GSM relevant parameters are the radio link ones and no line is present, hence %Q %L and have no meaning.</p>	
AT+CSQ?	Read command has the same effect as Execution command.	
AT+CSQ=?	Test command returns the supported range of values of the parameters <rss> and <ber> .	



+CSQ - Signal Quality		SELINT 0 / 1
	Note: although +CSQ is an execution command without parameters, ETSI 07.07 requires the Test command to be defined.	
Reference	GSM 07.07	
		SELINT 2
AT+CSQ	<p>Execution command reports received signal quality indicators in the form:</p> <p>+CSQ: <rssi>,<ber> where <rssi> - received signal strength indication 0 - (-113) dBm or less 1 - (-111) dBm 2..30 - (-109)dBm..(-53)dBm / 2 dBm per step 31 - (-51)dBm or greater 99 - not known or not detectable <ber> - bit error rate (in percent) 0 - less than 0.2% 1 - 0.2% to 0.4% 2 - 0.4% to 0.8% 3 - 0.8% to 1.6% 4 - 1.6% to 3.2% 5 - 3.2% to 6.4% 6 - 6.4% to 12.8% 7 - more than 12.8% 99 - not known or not detectable</p> <p>Note: this command should be used instead of the %Q and %L commands, since GSM relevant parameters are the radio link ones and no line is present, hence %Q and %L have no meaning.</p>	
AT+CSQ=?	<p>Test command returns the supported range of values of the parameters <rssi> and <ber>.</p> <p>Note: although +CSQ is an execution command without parameters, ETSI 07.07 requires the Test command to be defined.</p>	
Reference	GSM 07.07	

3.5.4.4.5 Indicator Control - +CIND

+CIND - Indicator Control		SELINT 2
AT+CIND= [<state> [,<state>[,...]]]	<p>Set command is used to control the registration state of ME indicators, in order to automatically send the +CIEV URC, whenever the value of the associated indicator changes. The supported indicators (<descr>) and their order appear from test command AT+CIND=?</p> <p>Parameter: <state> - registration state 0 - the indicator is deregistered; there's no unsolicited result code (+CIEV</p>	



+CIND - Indicator Control	SELINT 2
	<p>URC) automatically sent by the ME to the application, whenever the value of the associated indicator changes; the value can be directly queried with +CIND?</p> <p>1 - the indicator is registered: an unsolicited result code (+CIEV URC) is automatically sent by the ME to the application, whenever the value of the associated indicator changes; it is still possible to query the value through +CIND? (default)</p>
AT+CIND?	<p>Read command returns the current value of ME indicators, in the format: +CIND: <ind>[,<ind>[,...]]¹⁶</p> <p>Note: the order of the values <ind>s is the same as that in which the associated indicators appear from test command AT+CIND=?</p>
AT+CIND=?	<p>Test command returns pairs, where string value <descr> is a description (max. 16 chars) of the indicator and compound value is the supported values for the indicator, in the format:</p> <p>+CIND: ((<descr>, (list of supported <ind>s)),(<descr>, (list of supported <ind>s)),[,...])</p> <p>where:</p> <p><descr> - indicator names as follows (along with their <ind> ranges)</p> <ul style="list-style-type: none"> “battchg” - battery charge level <ul style="list-style-type: none"> <ind> - battery charge level indicator range 0..5 99 - not measurable “signal” - signal quality <ul style="list-style-type: none"> <ind> - signal quality indicator range 0..7 99 - not measurable “service” - service availability <ul style="list-style-type: none"> <ind> - service availability indicator range 0 - not registered to any network 1 - registered “sounder” - sounder activity <ul style="list-style-type: none"> <ind> - sounder activity indicator range 0 - there’s no any sound activity 1 - there’s some sound activity “message” - message received <ul style="list-style-type: none"> <ind> - message received indicator range 0 - there is no unread short message at memory location “SM” 1 - unread short message at memory location “SM” “call” - call in progress <ul style="list-style-type: none"> <ind> - call in progress indicator range 0 - there’s no calls in progress 1 - at least a call has been established “roam” - roaming

¹⁶ In present SW release AT+CIND? does not return current value in case of SmsFull, UnreadMessage and SoundActivity also only Rssi and Roam URC indicators are implemented. All other indicators will be fully implemented in the future SW releases.



+CPBS - Select Phonebook Memory Storage		SELINT 0 / 1
	the same number the read command will return only the last call	
AT+CPBS=?	Test command returns the supported range of values for the parameters <storage> . Note: the presentation format of the Test command output is the set of available values for <storage> , each of them enclosed in parenthesis: +CPBS: ("SM"),("FD"),("LD"),("MC"),("RC")	
Reference	GSM 07.07	

+CPBS - Select Phonebook Memory Storage		SELINT 2
AT+CPBS= <storage>	Set command selects phonebook memory storage <storage> , which will be used by other phonebook commands. Parameter: <storage> "SM" - SIM phonebook "FD" - SIM fixed dialling-phonebook (only phase 2/2+ SIM) "LD" - SIM last-dialling-phonebook (+CPBF is not applicable for this storage) "MC" - device missed (unanswered received) calls list (+CPBF is not applicable for this storage) "RC" - ME received calls list (+CPBF is not applicable for this storage). "MB" - mailbox numbers stored on SIM; it is possible to select this storage only if the mailbox service is provided by the SIM (see #MBN).	
AT+CPBS?	Read command returns the actual values of the parameter <storage> , the number of occupied records <used> and the maximum index number <total> , in the format: +CPBS: <storage>,<used>,<total> Note: For <storage>="MC" : if there are more than one missed calls from the same number the read command will return only the last call	
AT+CPBS=?	Test command returns the supported range of values for the parameters <storage> .	
Reference	GSM 07.07	

3.5.4.4.8 Read Phonebook Entries - +CPBR

+CPBR - Read Phonebook Entries		SELINT 0 / 1
AT+CPBR= <index1> [,<index2>]	Execution command returns phonebook entries in location number range <index1>..<index2> from the current phonebook memory storage selected with +CPBS . If <index2> is omitted, only location <index1> is returned. Parameters: <index1> - integer type value in the range of location numbers of	



+CCLK - Clock Management		SELINT 2
	returned by +CCLK? only if the #NITZ URC 'extended' format has been enabled (see #NITZ).	
AT+CCLK=?	Test command returns the OK result code.	
Example	<pre>AT+CCLK="02/09/07,22:30:00+00" OK AT+CCLK? +CCLK: 02/09/07,22:30:25 OK</pre>	
Reference	GSM 07.07	

3.5.4.4.12 Alarm Management - **+CALA**

+CALA - Alarm Management		SELINT 0 / 1
AT+CALA[= <time>[,<n>[,<type> [,<text>[,<recurr> [,<silent>]]]]]	<p>Set command stores in the internal Real Time Clock an alarm time with respective settings. It is possible to set up a recurrent alarm for one or more days in the week. Currently just one alarm can be set.</p> <p>When the RTC time reaches the alarm time then the alarm starts, the behaviour of the MODULE depends upon the setting <type> and if the device was already ON at the moment when the alarm time had come.</p> <p>Parameters:</p> <p><time> - current alarm time as quoted string "" - (empty string) deletes the current alarm and resets all the +CALA parameters to the "factory default" configuration "hh:mm:ss±zz" - format to be used only when issuing +CALA with parameter <recurr> too. "yy/MM/dd, hh:mm:ss±zz" - generic format: it's the same as defined for +CCLK (see)</p> <p><n> - index of the alarm 0 - The only value supported is 0.</p> <p><type> - alarm behaviour type 0 - reserved for other equipment use. 1 - the MODULE simply wakes up fully operative as if the ON/OFF button had been pressed. If the device is already ON at the alarm time, then it does nothing (default). 2 - the MODULE wakes up in "alarm mode" if at the alarm time it was off, otherwise it remains fully operative. In both cases the MODULE issues an unsolicited code every 3s:</p> <p>+CALA: <text></p> <p>where <text> is the +CALA optional parameter previously set.</p> <p>The device keeps on sending the unsolicited code every 3s until a</p>	



+CALA - Alarm Management		SELINT 0 / 1
	Note: if no alarm is present a <CR><LF> is issued.	
AT+CALA=?	<p>Test command returns the list of supported index values (currently just 0), alarm types and maximum length of the text to be displayed, in the format:</p> <p>+CALA: (list of supported <n>s),(list of supported <type>s),<tlength></p> <p>where: <n> and <type> as before <tlength> - maximum <text> field length, integer type</p> <p>Note: an enhanced version of Test command has been defined, AT+CALA=??, providing the range of available values for <rlenght> and <silent> too.</p>	
AT+CALA=??	<p>Test command returns the list of supported index values (currently just 0), alarm types, maximum length of the text to be displayed, maximum length of <recurr> and supported <silent>s, in the format:</p> <p>+CALA: (list of supported <n>s),(list of supported <type>s),<tlength>, <rlength>,(list of supported <silent>s)</p> <p>where: <n>, <type>, <tlength> and <silent> as before <rlenght> - maximum <recurr> field length, integer type</p>	
Example	AT+CALA="02/09/07,23:30:00+00" OK	
Reference	ETSI 07.07, ETSI 27.007	

+CALA - Alarm Management		SELINT 2
AT+CALA= <time>[,<n>[,<type> [,<text>[,<recurr> [,<silent>]]]]]	<p>Set command stores in the internal Real Time Clock an alarm time with respective settings. It is possible to set up a recurrent alarm for one or more days in the week. Currently just one alarm can be set.</p> <p>When the RTC time reaches the alarm time then the alarm starts, the behaviour of the MODULE depends upon the setting <type> and if the device was already ON at the moment when the alarm time had come.</p> <p>Parameters: <time> - current alarm time as quoted string "" - (empty string) deletes the current alarm and resets all the +CALA parameters to the "factory default" configuration "hh:mm:ss±zz" - format to be used only when issuing +CALA with parameter <recurr> too. "yy/MM/dd,hh:mm:ss±zz" - generic format: it's the same as defined for +CCLK (see) <n> - index of the alarm</p>	



+CLVL - Loudspeaker Volume Level		SELINT 0 / 1
	+CLVL: (0-max)	
Reference	GSM 07.07	

+CLVL - Loudspeaker Volume Level		SELINT 2
AT+CLVL=<level>	Set command is used to select the volume of the internal loudspeaker audio output of the device. Parameter: <level> - loudspeaker volume 0..max - the value of max can be read by issuing the Test command AT+CLVL=?	
AT+CLVL?	Read command reports the current <level> setting of the loudspeaker volume in the format: +CLVL: <level>	
AT+CLVL=?	Test command reports <level> supported values range in the format: +CLVL: (0-max)	
Reference	GSM 07.07	

3.5.4.4.17 Microphone Mute Control - +CMUT

+CMUT - Microphone Mute Control		SELINT 0 / 1
AT+CMUT[=[<n>]]	Set command enables/disables the muting of the microphone audio line during a voice call. Parameter: <n> 0 - mute off, microphone active (factory default) 1 - mute on, microphone muted. Note: this command mutes/activates both microphone audio paths, internal mic and external mic. Note: issuing AT+CMUT<CR> is the same as issuing the Read command. Note: issuing AT+CMUT=<CR> is the same as issuing the command AT+CMUT=0<CR> .	
AT+CMUT?	Read command reports whether the muting of the microphone audio line during a voice call is enabled or not, in the format: +CMUT: <n>	
AT+CMUT=?	Test command reports the supported values for <n> parameter.	
Reference	GSM 07.07	

+CMUT - Microphone Mute Control		SELINT 2
AT+CMUT=<n>	Set command enables/disables the muting of the microphone audio line	



+CAMM - Accumulated Call Meter Maximum		SELINT 2
AT+CAMM= [<acmmax> [,<pwd>]]	<p>Set command sets the Advice of Charge related Accumulated Call Meter Maximum Value stored in SIM (ACMmax). This value represents the maximum number of home units allowed to be consumed by the subscriber. When ACM reaches <acmmax> value further calls are prohibited.</p> <p>Parameter: <acmmax> - ACMmax value, integer type: it is the maximum number of home units allowed to be consumed by the subscriber. <pwd> - PIN2; if PIN2 has been already input once after startup, it is required no more</p> <p>Note: <acmmax> = 0 value disables the feature.</p>	
AT+CAMM?	<p>Read command reports the ACMmax value stored in SIM in the format:</p> <p>+CAMM : <acmm></p> <p>where: <acmm> - ACMmax value in home units, string type: three bytes of the ACMmax value in hexadecimal format (e.g. "00001E" indicates decimal value 30)</p>	
AT+CAMM=?	Test command returns the OK result code	
Reference	GSM 07.07	

3.5.4.4.20 Price per Unit and Currency Table - +CPUC

+CPUC - Price Per Unit And Currency Table		SELINT 0 / 1
AT+CPUC[= <currency> <ppu>[,<pwd>]]	<p>Set command sets the values of Advice of Charge related Price per Unit and Currency Table stored in SIM (PUCT). The PUCT information can be used to convert the home units (as used in commands +CAOC, +CACM and +CAMM) into currency units.</p> <p>Parameters: <currency> - string type; three-character currency code (e.g. LIT, USD, DEM etc.); used character set should be the one selected with command +CSCS. <ppu> - price per unit, string type (dot is used as decimal separator) e.g. "1989.27" <pwd> - SIM PIN2; if PIN2 has been already input once after startup, it is required no more</p> <p>Note: if the parameters are omitted the behavior of Set command is the same as Read command.</p>	
AT+CPUC?	<p>Read command reports the current values of <currency> and <ppu> parameters in the format:</p> <p>+CACM : <currency>,<ppu></p>	
Reference	GSM 07.07	



3.5.4.4.23 Read ICCID (Integrated Circuit Card Identification) - +CCID

+CCID - Read ICCID (Integrated Circuit Card Identification)		SELINT 0 / 1
AT+CCID	Execution command reads on SIM the ICCID (card identification number that provides a unique identification number for the SIM)	
AT+ CCID?	Read command has the same effect as Execution command.	
AT+CCID=?	Test command reports OK .	

3.5.4.5 Mobile Equipment Errors

3.5.4.5.1 Report Mobile Equipment Error - +CMEE

+CMEE - Report Mobile Equipment Error		SELINT 0 / 1
AT+CMEE=[<n>]	<p>Set command enables/disables the report of result code:</p> <p>+CME ERROR: <err></p> <p>as an indication of an error relating to the +Cxxx commands issued. When enabled, device related errors cause the +CME ERROR: <err> final result code instead of the default ERROR final result code. ERROR is anyway returned normally when the error message is related to syntax, invalid parameters, or DTE functionality.</p> <p>Parameter: <n> - enable flag 0 - disable +CME ERROR:<err> reports, use only ERROR report. 1 - enable +CME ERROR:<err> reports, with <err> in numeric format 2 - enable +CME ERROR: <err> reports, with <err> in verbose format</p> <p>Note: issuing AT+CMEE<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT+CMEE=<CR> is the same as issuing the command AT+CMEE=0<CR>.</p>	
AT+CMEE?	<p>Read command returns the current value of subparameter <n></p> <p>+CMEE: <n></p>	
AT+CMEE=?	<p>Test command returns the range of values for subparameter <n> in the format:</p> <p>+CMEE: 0, 1, 2</p> <p>Note: the representation format of the Test command output is not included in parenthesis.</p>	
Note	+CMEE has no effect on the final result code +CMS	
Reference	GSM 07.07	



+CGQREQ - Quality Of Service Profile (Requested)		SELINT 0 / 1
	OK AT+CGQREQ=1,0,0,3,0,0 OK AT+CGQREQ=? +CGQREQ: "IP", (0-3), (0-4), (0-5), (0-9), (0-19,31) OK	
Reference	GSM 07.07; GSM 03.60	

+CGQREQ - Quality Of Service Profile (Requested)		SELINT 2
AT+CGQREQ= [<cid> [,<precedence> [,<delay> [,<reliability> [,<peak> [,<mean>]]]]]	<p>Set command allows to specify a Quality of Service Profile that is used when the terminal sends an Activate PDP Context Request message to the network. It specifies a profile for the context identified by the (local) context identification parameter, <cid>.</p> <p>Parameters: <cid> - PDP context identification (see +CGDCONT command). <precedence> - precedence class <delay> - delay class <reliability> - reliability class <peak> - peak throughput class <mean> - mean throughput class</p> <p>If a value is omitted for a particular class then this class is not checked.</p> <p>Note: a special form of the Set command, +CGQREQ=<cid> causes the requested profile for context number <cid> to become undefined.</p>	
AT+CGQREQ?	<p>Read command returns the current settings for each defined context in the format:</p> <p>+CGQREQ: <cid>,<precedence>,<delay>,<reliability>,<peak>,<mean>[<CR><LF>+CGQREQ: <cid>,<precedence>,<delay>,<reliability>,<peak>,<mean>[...]]</p> <p>If no PDP context has been defined, it has no effect and OK result code is returned.</p>	
AT+CGQREQ=?	<p>Test command returns as a compound value the type of the current PDP context and the supported values for the subparameters in the format:</p> <p>+CGQREQ: <PDP_Type>,(list of supported <precedence>s), (list of supported <delay>s),(list of supported <reliability>s), (list of supported <peak>s),(list of supported <mean>s)</p> <p>Note: only the "IP" PDP_Type is currently supported.</p>	
Example	AT+CGQREQ? +CGQREQ: 1,0,0,3,0,0	



+CGPADDR - Show PDP Address		SELINT 0 / 1
	referred to by <cid> ; if no address is available the empty string ("") is represented as <PDP_addr>	
AT+CGPADDR=?	Test command returns a list of defined <cid> s.	
Example	<pre>AT#GPRS=1 +IP: xxx.yyy.zzz.www OK AT+CGPADDR=1 +CGPADDR: 1, "xxx.yyy.zzz.www" OK AT+CGPADDR=? +CGPADDR: (1) OK</pre>	
Reference	GSM 07.07	

+CGPADDR - Show PDP Address		SELINT 2
AT+CGPADDR= [<cid>,<cid> [,...]]]	<p>Execution command returns a list of PDP addresses for the specified context identifiers in the format:</p> <p>+CGPADDR: <cid>,<PDP_addr>[<CR><LF>+CGPADDR: <cid>,<PDP_addr>[...]]</p> <p>Parameters:</p> <p><cid> - a numeric parameter which specifies a particular PDP context definition (see +CGDCONT command). If no <cid> is specified, the addresses for all defined contexts are returned.</p> <p><PDP_addr> - a string that identifies the terminal in the address space applicable to the PDP. The address may be static or dynamic. For a static address, it will be the one set by the +CGDCONT command when the context was defined. For a dynamic address it will be the one assigned during the last PDP context activation that used the context definition referred to by <cid>; if no address is available the empty string ("") is represented as <PDP_addr></p>	
AT+CGPADDR=?	Test command returns a list of defined <cid> s.	
Example	<pre>AT#GPRS=1 +IP: xxx.yyy.zzz.www OK AT+CGPADDR=1 +CGPADDR: 1, "xxx.yyy.zzz.www" OK</pre>	



+CGPADDR - Show PDP Address		SELINT 2
	AT+CGPADDR=? +CGPADDR: (1) OK	
Reference	GSM 07.07	

3.5.4.7.10 Enter Data State - +CGDATA

+CGDATA - Enter Data State		SELINT 0 / 1
AT+CGDATA= [<L2P>,<cid> [,<cid>[,...]]]	Execution command causes to perform whatever actions are necessary to establish a communication with the network using one or more GPRS PDP types. Parameters: <L2P> - string parameter that indicates the layer 2 protocol to be used "PPP" - PPP Point-to-point protocol <cid> - numeric parameter which specifies a particular PDP context definition (see +CGDCONT command). Note: if parameter <L2P> is omitted, the layer 2 protocol is unspecified	
AT+CGDATA=?	Test command reports information on the supported layer 2 protocols. Note: the representation format of the Test command output is not included in parenthesis	
Example	AT+CGDATA=? +CGDATA: "PPP" OK AT+CGDATA="PPP",1 OK	
Reference	GSM 07.07	

+CGDATA - Enter Data State		SELINT 2
AT+CGDATA= [<L2P>,<cid> [,<cid>[,...]]]	Execution command causes to perform whatever actions are necessary to establish a communication with the network using one or more GPRS PDP types. Parameters: <L2P> - string parameter that indicates the layer 2 protocol to be used "PPP" - PPP Point-to-point protocol <cid> - numeric parameter which specifies a particular PDP context definition (see +CGDCONT command). Note: if parameter <L2P> is omitted, the layer 2 protocol is unspecified	
AT+CGDATA=?	Test command reports information on the supported layer 2 protocols.	



+ CBC - Battery Charge		SELINT 2
	Test command to be defined.	
Example	AT+CBC +CBC: 0,75 OK	
Note	The ME does not make differences between being powered by a battery or by a power supply on the VBATT pins, so it is not possible to distinguish between these two cases.	
Reference	GSM 07.07	



+CSAS - Save Settings		SELINT 2
	are always saved to NVM, regardless the value of <profile> . Note: If parameter is omitted the settings are saved in the non volatile memory.	
AT+CSAS=?	Test command returns the possible range of values for the parameter <profile> .	
Reference	GSM 07.05	

3.5.5.2.6 Restore Settings - +CRES

+CRES - Restore Settings		SELINT 0 / 1
AT+CRES [=<profile>]	Execution command restores message service settings saved by +CSCA command from either NVM or SIM. Parameter: <profile> 0 - it restores message service settings from NVM. 1..n - it restores message service settings from SIM. The value of n depends on the SIM and its max is 3. Note: certain settings may not be supported by the SIM and therefore they are always restored from NVM, regardless the value of <profile> . Note: If parameter is omitted the command restores message service settings from NVM.	
AT+CRES?	Read command has the same effect as Execution command with parameter omitted.	
AT+CRES=?	Test command returns the possible range of values for the parameter <profile> .	
Reference	GSM 07.05	

+CRES - Restore Settings		SELINT 2
AT+CRES [=<profile>]	Execution command restores message service settings saved by +CSAS command from either NVM or SIM. Parameter: <profile> 0 - it restores message service settings from NVM. 1..n - it restores message service settings from SIM. The value of n depends on the SIM and its max is 3. Note: certain settings may not be supported by the SIM and therefore they are always restored from NVM, regardless the value of <profile> . Note: If parameter is omitted the command restores message service	



+CNMI - New Message Indications To Terminal Equipment	SELINT 0 / 1
	<p><data> - CBM Content of Message</p> <p><ds> - SMS-STATUS-REPORTs reporting option 0 - status report receiving is not reported to the DTE 1 - the status report is sent to the DTE with the following unsolicited result code:</p> <p style="text-align: center;">(PDU Mode)</p> <p>+CDS: <length><CR><LF><PDU> where: <length> - PDU length <PDU> - message PDU</p> <p style="text-align: center;">(TEXT Mode)</p> <p>+CDS: <fo>,<mr>,,,<scts>,<dt>,<st> where: <fo> - first octet of the message PDU <mr> - message reference number <scts> - arrival time of the message to the SC <dt> - sending time of the message <st> - message status as coded in the PDU</p> <p>2 - if a status report is stored, then the following unsolicited result code is sent: +CDSI: <memr>,<index> where: <memr> - memory storage where the new message is stored "SM" <index> - location on the memory where SM is stored</p> <p><bfr> - buffered result codes handling method: 0 - TA buffer of unsolicited result codes defined within this command is flushed to the TE when <mode>=1..3 is entered (OK response shall be given before flushing the codes) 1 - TA buffer of unsolicited result codes defined within this command is cleared when <mode>=1..3 is entered.</p> <p>Note: issuing AT+CNMI<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT+CNMI=<CR> is the same as issuing the command AT+CNMI=0<CR>.</p>
AT+CNMI?	Read command returns the current parameter settings for +CNMI command in the form: +CNMI: <mode>,<mt>,<bm>,<ds>,<bfr>
AT+CNMI=?	Test command reports the supported range of values for the +CNMI command parameters.



3.5.5.3.2 List Messages - +CMGL

+CMGL - List Messages	SELINT 0 / 1
<p>AT+CMGL [=<stat>]</p>	<p>Execution command reports the list of all the messages with status value <stat> stored into <memr> message storage (<memr> is the message storage for read and delete SMS as last settings of command +CPMS).</p> <p>The parameter type and the command output depend on the last settings of command +CMGF (message format to be used)</p> <p style="text-align: center;">(PDU Mode)</p> <p>Parameter: <stat> 0 - new message 1 - read message 2 - stored message not yet sent 3 - stored message already sent 4 - all messages.</p> <p>Each message to be listed is represented in the format:</p> <p>+CMGL: <index>,<stat>,<length><CR><LF><pdu></p> <p>where <index> - message position in the memory storage list. <stat> - status of the message <length> - length of the PDU in bytes <pdu> - message in PDU format according to GSM 3.40</p> <p style="text-align: center;">(Text Mode)</p> <p>Parameter: <stat> "REC UNREAD" - new message "REC READ" - read message "STO UNSENT" - stored message not yet sent "STO SENT" - stored message already sent "ALL" - all messages.</p> <p>Each message to be listed is represented in the format (the information written in italics will be present depending on +CSDH last setting):</p> <p>+CMGL: <index>,<stat>,<oa/da>,,[,<toa/toda>,<length>] <CR><LF> <data></p> <p>where <index> - message position in the storage <stat> - message status <oa/da> - originator/destination address, string type, represented in the currently selected character set (see +CSCS)</p>



+CMGL - List Messages		SELINT 2
M S M O D E = 0 # S M S M O D E = 0 # S M S M O D E = 0 # S M S M O D E = 0	<p> <index> - message position in the storage <stat> - message status <oa/da> - originator/destination address, string type , represented in the currently selected character set (see +CSCS) <alpha> - string type alphanumeric representation of <da> or <oa>, corresponding to an entry found in the phonebook; used character set is the one selected with command +CSCS. <scts> - TP-Service Centre Time Stamp in Time String Format <toa/oda> - type of number <oa/da> 129 - number in national format 145 - number in international format (contains the "+") <length> - text length <data> - TP-User-Data <ul style="list-style-type: none"> • If <dcs> indicates that GSM03.38 default alphabet is used , each character of GSM alphabet will be converted into current TE character set (see +CSCS) • If <dcs> indicates that 8-bit or UCS2 data coding scheme is used, each 8-bit octet will be converted into two IRA character long hexadecimal number (e.g. octet 0x2A will be converted as two characters 0x32 0x41) </p> <p>If there is at least one message delivery confirm to be listed the representation format is:</p> <p> +CMGL: <index>,<stat>,<fo>,<mr>,,,<scts>,<dt>,<st>[<CR><LF> +CMGL: <index>,<stat>,<fo>,<mr>,<ra>,<tora>,<scts>,<dt>,<st> [...] </p> <p>where</p> <p> <index> - message position in the storage <stat> - message status <fo> - first octet of the message PDU <mr> - message reference number; GSM 03.40 TP-Message-Reference in integer format <scts> - arrival time of the message to the SC <dt> - sending time of the message <st> - message status as coded in the PDU </p> <p>Note: If parameter is omitted the command returns the list of sms with "REC UNREAD" status.</p> <p>Note: the order in which the messages are reported by +CMGL is the same order in which these messages have been processed by the module</p>	
	AT+CMGL=?	Test command returns a list of supported <stat> s
	Reference	GSM 07.05, GSM 03.40



+CMGL - List Messages		SELINT 2
(#SMSMODE=1)		
# S M S M O D E = 1 # S M S M O D E = 1 # S M S M O D E = 1 # S M S M	AT+CMGL [=<stat>]	<p>Execution command reports the list of all the messages with status value <stat> stored into <memr> message storage (<memr> is the message storage for read and delete SMS as last settings of command +CPMS).</p> <p>The parameter type and the command output depend on the last settings of command +CMGF (message format to be used)</p> <p style="text-align: center;">(PDU Mode)</p> <p>Parameter: <stat> 0 - new message 1 - read message 2 - stored message not yet sent 3 - stored message already sent 4 - all messages.</p> <p>If there is at least one message to be listed the representation format is:</p> <p>+CMGL: <index>,<stat>,<alpha>,<length><CR><LF><pdu>[<CR><LF> +CMGL: <index>,<stat>,<alpha>,<length><CR><LF><pdu>[...]]</p> <p>where: <index> - message position in the memory storage list. <stat> - status of the message <alpha> - string type alphanumeric representation of <da> or <oa>, corresponding to an entry found in the phonebook; used character set is the one selected with command +CSCS. <length> - length of the PDU in bytes <pdu> - message in PDU format according to GSM 3.40</p> <p style="text-align: center;">(Text Mode)</p> <p>Parameter: <stat> "REC UNREAD" - new message "REC READ" - read message "STO UNSENT" - stored message not yet sent "STO SENT" - stored message already sent "ALL" - all messages.</p> <p>The representation format for stored messages (either sent or unsent) or received messages (either read or unread, not message delivery</p>



@CMGL - List Messages Improved		SELINT 1
	<p><CR><LF> <data></p> <p>where <index> - message position in the storage <stat> - message status <oa/da> - originator/destination address, string type, represented in the currently selected character set (see +CSCS) <tooa/toda> - type of number <oa/da> 129 - number in national format 145 - number in international format (contains the "+") <length> - text length <data> - TP-User-Data</p> <p>Each message delivery confirm is represented in the format:</p> <p>@CMGL: <index>,<stat>,<fo>,<mr>,,,<scts>,<dt>,<st></p> <p>where <index> - message position in the storage <stat> - message status <fo> - first octet of the message PDU <mr> - message reference number <scts> - arrival time of the message to the SC <dt> - sending time of the message <st> - message status as coded in the PDU</p> <p>Note: The command differs from the +CMGL because at the end of the listing a <CR><LF> is put before the OK result code.</p> <p>Note: If parameter is omitted the command returns the list of sms with "REC UNREAD" status.</p>	
AT@CMGL?	Read command has the same effect as Execution command with parameter omitted	
AT@CMGL=?	Test command returns a list of supported <stat>s	
Note	<p>If Text Mode (+CMGF=1) the Test command output is not included in parenthesis</p> <p>AT@CMGL=? @CMGL: "REC UNREAD","REC READ","STO UNSENT", "STO SENT","ALL"</p>	
Reference	GSM 07.05	

3.5.5.3.4 Read Message - +CMGR

+CMGR - Read Message		SELINT 0 / 1
AT+CMGR= <index>	Execution command reports the message with location value <index> from <memr> message storage (<memr> is the message storage for read and	



+CMGR - Read Message	SELINT 0 / 1
<p>delete SMs as last settings of command +CPMS).</p> <p>Parameter: <index> - message index.</p> <p>The output depends on the last settings of command +CMGF (message format to be used)</p> <p style="text-align: center;">(PDU Mode)</p> <p>The output has the following format:</p> <p>+CMGR: <stat>,<length><CR><LF><pdu></p> <p>where <stat> - status of the message 0 - new message 1 - read message 2 - stored message not yet sent 3 - stored message already sent <length> - length of the PDU in bytes. <pdu> - message in PDU format according to GSM 3.40.</p> <p>The status of the message and entire message data unit <pdu> is returned.</p> <p style="text-align: center;">(Text Mode)</p> <p>Output format for received messages (the information written in <i>italics</i> will be present depending on +CSDH last setting):</p> <p>+CMGR: <stat>,<oa>,,<scts> [<i>,<tooa>,<fo>,<pid>,<dcs>,<sca>,<tosca>,<length></i>]<i><CR><LF><data></i></p> <p>Output format for either sent or unsent messages: +CMGR: <stat>,<da>,[<i><toda>,<fo>,<pid>,<dcs>,<sca>,<tosca>,<length></i>]<i><CR><LF><data></i></p> <p>Output format for message delivery confirm: +CMGR: <stat>,<fo>,<mr>,,,<scts>,<dt>,<st></p> <p>where: <stat> - status of the message "REC UNREAD" - new received message unread "REC READ" - received message read "STO UNSENT" - message stored not yet sent "STO SENT" - message stored already sent <fo> - first octet of the message PDU <mr> - message reference number</p>	



+CMGR - Read Message		SELINT 2
M O D E = 0 # S M S M O D E = 0 # S M S M O D E = 0 # S M S M O D E = 0		<p><stat> - status of the message 0 - new message 1 - read message 2 - stored message not yet sent 3 - stored message already sent</p> <p><alpha> - string type alphanumeric representation of <da> or <oa>, corresponding to an entry found in the phonebook; used character set is the one selected with command +CSCS.</p> <p><length> - length of the PDU in bytes. <pdu> - message in PDU format according to GSM 3.40.</p> <p>The status of the message and entire message data unit <pdu> is returned.</p> <p style="text-align: center;">(Text Mode)</p> <p>If there is a Received message in location <index> the output format is (the information written in <i>italics</i> will be present depending on +CSDH last setting): +CMGR: <stat>,<oa>,<alpha>,<scts>[,<tooa>,<fo>,<pid>,<dcs>,<sca>,<tosca>,<length>]<CR><LF><data></p> <p>If there is either a Sent or an Unsent message in location <index> the output format is: +CMGR: <stat>,<da>,<alpha>[,<toda>,<fo>,<pid>,<dcs>,<vp>,<sca>,<tosca>,<length>]<CR><LF><data></p> <p>If there is a Message Delivery Confirm in location <index> the output format is: +CMGR: <stat>,<fo>,<mr>,,,<scts>,<dt>,<st></p> <p>where:</p> <p><stat> - status of the message "REC UNREAD" - new received message unread "REC READ" - received message read "STO UNSENT" - message stored not yet sent "STO SENT" - message stored already sent</p> <p><fo> - first octet of the message PDU <mr> - message reference number; GSM 03.40 TP-Message-Reference in integer format <scts> - arrival time of the message to the SC <dt> - sending time of the message <st> - message status as coded in the PDU <pid> - Protocol Identifier <dcs> - Data Coding Scheme <vp> - Validity period; only the integer format is supported <oa> - Originator address, string type represented in the currently selected character set (see +CSCS)</p>



+CMGS - Send Message		SELINT 2
# S M S M O D E = 0		<p>Note: the DCD signal shall be in ON state while text is entered.</p> <p>Note: the echoing of entered characters back from the TA is controlled by echo command E</p> <p>To send the message issue Ctrl-Z char (0x1A hex). To exit without sending the message issue ESC char (0x1B hex).</p> <p>If message is successfully sent to the network, then the result is sent in the format:</p> <p>+CMGS: <mr></p> <p>where <mr> - message reference number; GSM 03.40 TP-Message-Reference in integer format.</p> <p>Note: if message sending fails for some reason, an error code is reported.</p> <p>Note: care must be taken to ensure that during the command execution, which may take several seconds, no other SIM interacting commands are issued.</p> <p>Note: it is possible to send a concatenation of at most 10 SMS; the maximum number of chars depends on the <dcs>: 1530 chars if GSM 03.38 default alphabet is used, 1340 chars if 8-bit is used, 670 chars if UCS2 is used.</p>
	AT+CMGS=?	Test command returns the OK result code.
	Note	To avoid malfunctions is suggested to wait for the +CMGS: <mr> or +CMS ERROR: <err> response before issuing further commands.
	Reference	GSM 07.05
(#SMSMODE=1)		
# S M S M O D E = 1	(PDU Mode) AT+CMGS= <length>	<p style="text-align: center;">(PDU Mode)</p> <p>Execution command sends to the network a message.</p> <p>Parameter: <length> - length of the PDU to be sent in bytes (excluding the SMSC address octets). 7..164</p> <p>After command line is terminated with <CR>, the device responds sending a four character sequence prompt:</p>



+CMGW - Write Message To Memory		SELINT 2
M O D E = 0 # S M S M O D E = 0 # S M S M O D E = 0 # S M S M O D E = 0	<p>Parameter:</p> <p><length> - length in bytes of the PDU to be written. 7..164</p> <p><stat> - message status. 0 - new message 1 - read message 2 - stored message not yet sent (default) 3 - stored message already sent</p> <p>The device responds to the command with the prompt '>' and waits for the specified number of bytes.</p> <p>To write the message issue Ctrl-Z char (0x1A hex). To exit without writing the message issue ESC char (0x1B hex).</p> <p>If message is successfully written in the memory, then the result is sent in the format:</p> <p>+CMGW: <index></p> <p>where:</p> <p><index> - message location index in the memory <memw>.</p> <p>If message storing fails for some reason, an error code is reported.</p> <p>Note: care must be taken to ensure that during the command execution, no other SIM interacting commands are issued.</p>	
# S M S M O D E = 0	<p><i>(Text Mode)</i> AT+CMGW[=<da> [,<toda> [,<stat>]]]</p>	<p style="text-align: center;">(Text Mode)</p> <p>Execution command writes in the <memw> memory storage a new message.</p> <p>Parameters:</p> <p><da> - destination address, string type represented in the currently selected character set (see +CSCS).</p> <p><toda> - type of destination address. 129 - number in national format 145 - number in international format (contains the "+")</p> <p><stat> - message status. "REC UNREAD" - new received message unread "REC READ" - received message read "STO UNSENT" - message stored not yet sent (default) "STO SENT" - message stored already sent</p> <p>After command line is terminated with <CR>, the device responds sending a four character sequence prompt:</p>



+CMGW - Write Message To Memory		SELINT 2
or +CMS ERROR: <err> response before issuing further commands.		
(#SMSMODE=1)		
# S M S M O D E = 1	<i>(PDU Mode)</i> AT+CMGW= <length> [,<stat>]	(PDU Mode) Execution command writes in the <memw> memory storage a new message. Parameter: <length> - length in bytes of the PDU to be written. 7..164 <stat> - message status. 0 - new message 1 - read message 2 - stored message not yet sent (default) 3 - stored message already sent The device responds to the command with the prompt '>' and waits for the specified number of bytes. To write the message issue Ctrl-Z char (0x1A hex). To exit without writing the message issue ESC char (0x1B hex). If message is successfully written in the memory, then the result is sent in the format: +CMGW: <index> where: <index> - message location index in the memory <memw> . If message storing fails for some reason, an error code is reported. Note: care must be taken to ensure that during the command execution, no other SIM interacting commands are issued.
# S M S M O D E = 1	<i>(Text Mode)</i> AT+CMGW[=<da> [,<toda> [,<stat>]]]	(Text Mode) Execution command writes in the <memw> memory storage a new message. Parameters: <da> - destination address, string type represented in the currently selected character set (see +CSCS). <toda> - type of destination address. 129 - number in national format 145 - number in international format (contains the "+") <stat> - message status. "REC UNREAD" - new received message unread
# S M S M		



3.5.6 FAX Class 1 AT Commands

3.5.6.1 General Configuration

3.5.6.1.1 Manufacturer ID - +FMI

+FMI - Manufacturer ID		SELINT 0
AT+FMI?	Read command reports the manufacturer ID. The output depends on the choice made through #SELINT command.	
Example	AT+FMI? Telit_Mobile_Terminals OK	
Reference	ITU T.31 and TIA/EIA-578-A specifications	

+FMI - Manufacturer ID		SELINT 1 / 2
AT+FMI?	Read command reports the manufacturer ID. The output depends on the choice made through #SELINT command.	
Example	AT+FMI? Telit OK	
Reference	ITU T.31 and TIA/EIA-578-A specifications	

3.5.6.1.2 Model ID - +FMM

+FMM - Model ID		SELINT 0 / 1 / 2
AT+FMM?	Read command reports the model ID	
Reference	ITU T.31 and TIA/EIA-578-A specifications	

3.5.6.1.3 Revision ID - +FMR

+FMR - Revision ID		SELINT 0 / 1 / 2
AT+FMR?	Read command reports the software revision ID	
Reference	ITU T.31 and TIA/EIA-578-A specifications	

3.5.6.2 Transmission/Reception Control

3.5.6.2.1 Stop Transmission And Pause - +FTS

+FTS - Stop Transmission And Pause		SELINT 0 / 1 / 2
AT+FTS=<time>	Execution command causes the modem to terminate a transmission and wait for <time> 10ms intervals before responding with OK result.	
	Parameter:	



+FTM - Transmit Data		SELINT 2
	<p><mod> - carrier modulation</p> <p>24 - V27ter/2400 bps</p> <p>48 - V27ter/4800 bps</p> <p>72 - V29/7200 bps</p> <p>96 - V29/9600 bps</p>	
AT+FTM=?	<p>Test command returns all supported values of the parameter <mod>.</p> <p>Note: test command result is without command echo.</p>	
Reference	ITU T.31 and TIA/EIA-578-A specifications	

3.5.6.2.4 Receive Data Modulation - +FRM

+FRM - Receive Data Modulation		SELINT 0 / 1
AT+FRM=<mod>	<p>Execution command causes the module to receive facsimile data using the modulation defined by the parameter <mod>.</p> <p>Parameter:</p> <p><mod> - carrier modulation</p> <p>24 - V27ter/2400 bps</p> <p>48 - V27ter/4800 bps</p> <p>72 - V29/7200 bps</p> <p>96 - V29/9600 bps</p>	
AT+FRM=?	<p>Test command returns all supported values of the parameter <mod>.</p> <p>Note: the output is not bracketed and without command echo.</p>	
Reference	ITU T.31 and TIA/EIA-578-A specifications	

+FRM - Receive Data Modulation		SELINT 2
AT+FRM=<mod>	<p>Execution command causes the module to receive facsimile data using the modulation defined by the parameter <mod>.</p> <p>Parameter:</p> <p><mod> - carrier modulation</p> <p>24 - V27ter/2400 bps</p> <p>48 - V27ter/4800 bps</p> <p>72 - V29/7200 bps</p> <p>96 - V29/9600 bps</p>	
AT+FRM=?	<p>Test command returns all supported values of the parameter <mod>.</p> <p>Note: test command result is without command echo.</p>	
Reference	ITU T.31 and TIA/EIA-578-A specifications	

3.5.6.2.5 Transmit Data With HDLC Framing - +FTH

+FTH - Transmit Data With HDLC Framing		SELINT 0 / 1 / 2
AT+FTH=<mod>	Execution command causes the module to transmit facsimile data using	



#CGMM - Model Identification		SELINT 2
AT#CGMM=?	Test command returns the OK result code.	

3.5.7.1.4 Revision Identification - #CGMR

#CGMR - Revision Identification		SELINT 0 / 1
AT#CGMR	Execution command returns device software revision number with command echo.	
AT#CGMR?	Read command has the same effect as the Execution command	

#CGMR - Revision Identification		SELINT 2
AT#CGMR	Execution command returns device software revision number with command echo.	
AT#CGMR=?	Test command returns the OK result code.	

3.5.7.1.5 Product Serial Number Identification - #CGSN

#CGSN - Product Serial Number Identification		SELINT 0 / 1
AT#CGSN	Execution command returns the product serial number, identified as the IMEI of the mobile, with command echo.	
AT#CGSN?	Read command has the same effect as the Execution command	

#CGSN - Product Serial Number Identification		SELINT 2
AT#CGSN	Execution command returns the product serial number, identified as the IMEI of the mobile, with command echo.	
AT#CGSN=?	Test command returns the OK result code.	

3.5.7.1.6 International Mobile Subscriber Identity (IMSI) - #CIMI

#CIMI - International Mobile Subscriber Identity (IMSI)		SELINT 0 / 1
AT#CIMI	Execution command returns the international mobile subscriber identity, identified as the IMSI number, with command echo.	
AT#CIMI?	Read command has the same effect as the Execution command	

#CIMI - International Mobile Subscriber Identity (IMSI)		SELINT 2
AT#CIMI	Execution command returns the international mobile subscriber identity, identified as the IMSI number, with command echo.	
AT#CIMI=?	Test command returns the OK result code.	

3.5.7.1.7 Read ICCID (Integrated Circuit Card Identification) - #CCID

#CCID - Read ICCID		SELINT 2
AT#CCID	Execution command reads on SIM the ICCID (card identification number that provides a unique identification number for the SIM)	
AT#CCID=?	Test command returns the OK result code.	



#CEER – Extended numeric error report		SELINT 2
	229	PDP deactivation requested by NWK
	230	PDP deactivation cause LLC link activation Failed
	231	PDP deactivation cause NWK reactivation with same TI
	232	PDP deactivation cause GMM abort
	233	PDP deactivation cause LLC or SMDCP failure
	234	PDP unsuccessful activation cause GMM error
	235	PDP unsuccessful activation cause NWK reject
	236	PDP unsuccessful activation cause NO NSAPI available
	237	PDP unsuccessful activation cause SM refuse
	238	PDP unsuccessful activation cause MMI ignore
	239	PDP unsuccessful activation cause Nb Max Session Reach
	Other custom values	
	240	FDN is active and number is not in FDN
	241	Call operation not allowed
	252	Call barring on outgoing calls
	253	Call barring on incoming calls
	254	Call impossible
	255	Lower layer failure
AT#CEER=?	Test command returns OK result code.	
Reference	GSM 04.08	

3.5.7.1.10 Change Audio Path - #CAP

#CAP - Change Audio Path	SELINT 0 / 1
AT#CAP[=[<n>]]	<p>Set command switches the active audio path depending on parameter <n></p> <p>Parameter: <n> - audio path</p> <p>0 - audio path follows the AXE input (factory default):</p> <ul style="list-style-type: none"> • if AXE is low, handsfree is enabled; • if AXE is high, internal path is enabled <p>1 - enables handsfree external mic/ear audio path 2 - enables internal mic/ear audio path</p> <p>Note: The audio path are mutually exclusive, enabling one disables the other.</p> <p>Note: when changing the audio path, the volume level is set at the previously stored value for that audio path (see +CLVL).</p> <p>Note: issuing AT#CAP<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT#CAP=<CR> is the same as issuing the command AT#CAP=0<CR>.</p>



#WAKE - Wake From Alarm Mode		SELINT 2
AT#WAKE?	<p>Read command returns the operating status of the device in the format:</p> <p>#WAKE: <status></p> <p>where:</p> <p><status></p> <p>0 - normal operating mode</p> <p>1 - alarm mode or normal operating mode with some alarm activity.</p>	

3.5.7.1.23 Query Temperature Overflow - #QTEMP

#QTEMP - Query Temperature Overflow		SELINT 0 / 1
AT#QTEMP [=<mode>]	<p>Set command has currently no effect. The interpretation of parameter <mode> is currently not implemented.</p> <p>Note: if parameter <mode> is omitted the behaviour of Set command is the same as Read command</p> <p>Note: Only <mode>=0 is accepted.</p>	
AT#QTEMP?	<p>Read command queries the device internal temperature sensor for over temperature and reports the result in the format:</p> <p>#QTEMP: <temp></p> <p>where</p> <p><temp> - over temperature indicator</p> <p>0 - the device temperature is in the <i>working range</i></p> <p>1 - the device temperature is out of the <i>working range</i></p> <p>Note: typical <i>temperature working range</i> is (-10°C..+55°C); anyway you are strongly recommended to consult the "Hardware User Guide" to verify the real temperature working range of your module</p>	
#QTEMP=?	<p>Test command reports supported range of values for parameter <mode>.</p>	
Note	<p>The device should not be operated out of its <i>temperature working range</i>; if temperature is out of range proper functioning of the device is not ensured.</p>	

#QTEMP - Query Temperature Overflow		SELINT 2
AT#QTEMP= [<mode>]	<p>Set command has currently no effect. The interpretation of parameter <mode> is currently not implemented: any value assigned to it will simply have no effect.</p>	
AT#QTEMP?	<p>Read command queries the device internal temperature sensor for over temperature and reports the result in the format:</p> <p>#QTEMP: <temp></p> <p>where</p>	



#QTEMP - Query Temperature Overflow	SELINT 2
	<p><temp> - over temperature indicator 0 - the device temperature is in the <i>working range</i> 1 - the device temperature is out of the <i>working range</i></p> <p>Note: typical <i>temperature working range</i> is (-10°C..+55°C); anyway you are strongly recommended to consult the "Hardware User Guide" to verify the real temperature working range of your module</p>
#QTEMP=?	Test command reports supported range of values for parameter <mode> .
Note	The device should not be operated out of its <i>temperature working range</i> , elsewhere proper functioning of the device is not ensured.

3.5.7.1.24 Temperature Monitor - #TEMPMON

#TEMPMON - Temperature Monitor	SELINT 2
<p>AT#TEMPMON= <mod> [,<urcmode> [,<action> [,<hyst_time> [,<GPIO>]]]]</p>	<p>Set command sets the behaviour of the module internal temperature monitor.</p> <p>Parameters:</p> <p><mod> 0 - sets the command parameters. 1 - triggers the measurement of the module internal temperature, reporting the result in the format:</p> <p>#TEMPMEAS: <level>,<value></p> <p>where: <level> - threshold level -2 - extreme temperature lower bound (see Note) -1 - operating temperature lower bound (see Note) 0 - normal temperature 1 - operating temperature upper bound (see Note) 2 - extreme temperature upper bound (see Note)</p> <p><value> - actual temperature expressed in Celsius degrees.</p> <p>Setting of the following optional parameters has meaning only if <mod>=0</p> <p><urcmode> - URC presentation mode. 0 - it disables the presentation of the temperature monitor URC 1 - it enables the presentation of the temperature monitor URC, whenever the module internal temperature reaches either operating or extreme levels; the unsolicited message is in the format:</p>



	<p>#TEMPMEAS: <level>,<value></p> <p>where: <level> and <value> are as before</p> <p><action> - sum of integers, each representing an action to be done whenever the module internal temperature reaches either operating or extreme levels (default is 0). If <action> is not zero, it is mandatory to set the <hyst_time> parameter too.</p> <p>0..7 - as a sum of:</p> <ul style="list-style-type: none"> 0 - no action 1 - automatic shut-down when the temperature is beyond the extreme bounds 2 - RF TX circuits automatically disabled (using +CFUN=2) when operating temperature bounds are reached. When the temperature is back to normal the module is brought back to the previous state, before RF TX disabled. 4 - the output pin <GPIO> is tied HIGH when operating temperature bounds are reached; when the temperature is back to normal the output pin <GPIO> is tied LOW. If this <action> is required, it is mandatory to set the <GPIO> parameter too. <p><hyst_time> - hysteresis time: all the actions happen only if the extreme or operating bounds are maintained at least for this period. This parameter is needed and required if <action> is not zero.</p> <p>0..255 - time in seconds</p> <p><GPIO> - GPIO number. valid range is "any output pin" (see "Hardware User's Guide"). This parameter is needed and required only if <action>=4 is required.</p> <p>Note: the URC presentation mode <urcmode> is related to the current multiplexed instance only (see +cmux); last <urcmode> settings are saved for every instance as extended profile parameters, thus it is possible to restore them either if the multiplexer control channel is released and set up, back and forth.</p> <p>Note: last <action>, <hyst_time> and <GPIO> settings are saved in NVM too, but they are not related to the current multiplexed instance only (see +cmux).</p>
<p>AT#TEMPMON?</p>	<p>Read command reports the current parameter settings for #TEMPMON command in the format:</p> <p>#TEMPMON: <urcmode>,<action>[,<hyst_time>[,<GPIO>]]</p>
<p>AT#TEMPMON=?</p>	<p>Test command reports the supported range of values for parameters <mod>, <urcmode>, <action>, <hyst_time> and <GPIO></p>
<p>Note</p>	<p>In the following table typical temperature bounds are represented; anyway you are strongly recommended to consult the "Hardware User Guide" to</p>



	<p>verify the real temperature bounds for your module.</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td>Extreme Temperature Lower Bound^(*)</td> <td>-30°C</td> </tr> <tr> <td>Operating Temperature Lower Bound^(*)</td> <td>-10°C</td> </tr> <tr> <td>Operating Temperature</td> <td></td> </tr> <tr> <td>Operating Temperature Upper Bound^(*)</td> <td>+55°C</td> </tr> <tr> <td>Extreme Temperature Upper Bound^(*)</td> <td>+80°C</td> </tr> </table> <p style="text-align: center;">(*) Due to temperature measurement uncertainty there is a tolerance of +/-2°C</p>	Extreme Temperature Lower Bound ^(*)	-30°C	Operating Temperature Lower Bound ^(*)	-10°C	Operating Temperature		Operating Temperature Upper Bound ^(*)	+55°C	Extreme Temperature Upper Bound ^(*)	+80°C
Extreme Temperature Lower Bound ^(*)	-30°C										
Operating Temperature Lower Bound ^(*)	-10°C										
Operating Temperature											
Operating Temperature Upper Bound ^(*)	+55°C										
Extreme Temperature Upper Bound ^(*)	+80°C										

3.5.7.1.25 Set General Purpose Output - #SGPO

#SGPO - Set General Purpose Output	SELINT 0 / 1
AT#SGPO=[<stat>]	<p>Set command sets the value of the general purpose output pin GPIO2.</p> <p>Parameter: <stat> 0 - output pin cleared to 0 (Low) 1 - output pin set to 1 (High)</p> <p>Note: the GPIO2 is an OPEN COLLECTOR output, the command sets the transistor base level, hence the open collector output is negated: AT#SGPO=0 sets the open collector output High AT#SGPO=1 sets the open collector output Low A pull up resistor is required on pin GPIO2.</p> <p>Note: issuing AT#SGPO<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT#SGPO=<CR> is the same as issuing the command AT#SGPO=0<CR>.</p>
AT#SGPO?	<p>Read command reports the #SGPO command setting, hence the opposite status of the open collector pin in the format:</p> <p>#SGPO: <stat>.</p>
AT#SGPO=?	<p>Test command reports the supported range of values of parameter <stat>.</p>
Note	<p>This command is meaningful only for GM862 family</p>

3.5.7.1.26 General Purpose Input - #GGPI

#GGPI - General Purpose Input	SELINT 0 / 1
AT#GGPI=[<dir>]	<p>Set command sets the general purpose input pin GPIO1.</p> <p>Parameter:</p>



#GGPI - General Purpose Input	SELINT 0 / 1
	<p><dir> - auxiliary input GPIO1 setting 0 - the Read command AT#GGPI? reports the logic input level read from GPIO1 pin.</p> <p>Note: The device has an insulated input pin (the input goes the base of an internal decoupling transistor) which can be used as a logic general purpose input. This command sets the read behaviour for this pin, since only direct read report is supported, the issue of this command is not needed. In future uses the behavior of the read input may be more complex.</p> <p>Note: If parameter is omitted then the behaviour of Set command is the same as Read command</p>
AT#GGPI?	<p>Read command reports the read value for the input pin GPIO1, in the format:</p> <p>#GGPI: <dir>,<stat></p> <p>where <dir> - direction setting (see #GGPI=<dir>) <stat> - logic value read from pin GPIO1</p> <p>Note: Since the reading is done after the insulating transistor, the reported value is the opposite of the logic status of the GPIO1 input pin.</p>
AT#GGPI=?	<p>Test command reports supported range of values for parameter <dir>.</p>
Note	<p>This command is meaningful only for GM862 family</p>

3.5.7.1.27 General Purpose Input/Output Pin Control - #GPIO

#GPIO - General Purpose Input/Output Pin Control	SELINT 0 / 1
AT#GPIO[=<pin>, <mode>[,<dir>]]	<p>Execution command sets the value of the general purpose output pin GPIO<pin> according to <dir> and <mode> parameter. Not all configuration for the three parameters are valid.</p> <p>Parameters:</p> <p><pin> - GPIO pin number; supported range is from 1 to a value that depends on the hardware.</p> <p><mode> - its meaning depends on <dir> setting:</p> <ul style="list-style-type: none"> 0 - no meaning if <dir>=0 - INPUT <ul style="list-style-type: none"> - output pin cleared to 0 (Low) if <dir>=1 - OUTPUT - no meaning if <dir>=2 - ALTERNATE FUNCTION 1 - no meaning if <dir>=0 - INPUT <ul style="list-style-type: none"> - output pin set to 1 (High) if <dir>=1 - OUTPUT - no meaning if <dir>=2 - ALTERNATE FUNCTION 2 - Reports the read value from the input pin if <dir>=0 - INPUT <ul style="list-style-type: none"> - Reports the read value from the input pin if <dir>=1 - OUTPUT - Reports a no meaning value if <dir>=2 - ALTERNATE FUNCTION <p><dir> - GPIO pin direction</p>



#GPIO - General Purpose Input/Output Pin Control	SELINT 0 / 1
	<p>0 - pin direction is INPUT 1 - pin direction is OUTPUT 2 - pin direction is ALTERNATE FUNCTION (see Note).</p> <p>Note: when <mode>=2 (and <dir> is omitted) the command reports the direction and value of pin GPIO<pin> in the format:</p> <p>#GPIO: <dir>,<stat> where <dir> - current direction setting for the GPIO<pin> <stat></p> <ul style="list-style-type: none"> • logic value read from pin GPIO<pin> in the case the pin <dir> is set to input; • logic value present in output of the pin GPIO<pin> in the case the pin <dir> is currently set to output; • no meaning value for the pin GPIO<pin> in the case the pin <dir> is set to alternate function. <p>Note: if all parameters are omitted the command reports the read direction and value of all GPIO pin, int the format:</p> <p>#GPIO: <dir>,<stat>[<CR><LF>#GPIO: <dir>,<stat>[...]]</p> <p>Note: "ALTERNATE FUNCTION" value is valid only for following pins:</p> <ul style="list-style-type: none"> • GPIO4 - alternate function is "RF Transmission Control" • GPIO5 - alternate function is "RF Transmission Monitor" • GPIO6 - alternate function is "Alarm Output" (see +CALA) • GPIO7 - alternate function is "Buzzer Output" (see #SRP) <p>Note: while using the pins in the alternate function, the GPIO read/write access to that pin is not accessible and shall be avoided.</p> <div style="border: 1px solid black; padding: 10px; margin: 10px 0;"> <p style="text-align: center;"><i>For GM862 family products only</i></p> <ul style="list-style-type: none"> • GPIO1 is input only and GPIO2 is output only. • since the GPIO1 reading is done after an insulating transistor, the reported value is the opposite of the logic status of the GPIO1 input pin <ol style="list-style-type: none"> GPIO2 is an OPEN COLLECTOR output, the command sets the transistor base level, hence the open collector output is negated </div>
AT#GPIO?	Read command has the same effect as Execution command when all parameters are omitted.
AT#GPIO=?	Test command reports the supported range of values of the command parameters <pin> , <mode> and <dir> .



#E2SMSRI - SMS Ring Indicator		SELINT 0 / 1
	Note: as seen before, the value $\langle n \rangle = 0$ means that the RI pin response to an incoming SM is disabled.	
AT#E2SMSRI=?	Reports the range of supported values for parameter $\langle n \rangle$	

#E2SMSRI - SMS Ring Indicator		SELINT 2
AT#E2SMSRI= [$\langle n \rangle$]	<p>Set command enables/disables the Ring Indicator pin response to an incoming SMS message. If enabled, a negative going pulse is generated on receipt of an incoming SMS message. The duration of this pulse is determined by the value of $\langle n \rangle$.</p> <p>Parameter: $\langle n \rangle$ - RI enabling 0 - disables RI pin response for incoming SMS messages (factory default) 50..1150 - enables RI pin response for incoming SMS messages. The value of $\langle n \rangle$ is the duration in ms of the pulse generated on receipt of an incoming SM.</p> <p>Note: if +CNMI=3,1 command is issued and the module is in a GPRS connection, a 100 ms break signal is sent and a 1 sec. pulse is generated on RI pin, no matter if the RI pin response is either enabled or not.</p>	
AT#E2SMSRI?	<p>Read command reports the duration in ms of the pulse generated on receipt of an incoming SM, in the format:</p> <p>#E2SMSRI: $\langle n \rangle$</p> <p>Note: as seen before, the value $\langle n \rangle = 0$ means that the RI pin response to an incoming SM is disabled.</p>	
AT#E2SMSRI=?	Reports the range of supported values for parameter $\langle n \rangle$	

3.5.7.1.32 Analog/Digital Converter Input - #ADC

#ADC - Analog/Digital Converter Input		SELINT 0 / 1
AT#ADC[= $\langle adc \rangle$, $\langle mode \rangle$ [, $\langle dir \rangle$]]	<p>Execution command reads pin$\langle adc \rangle$ voltage, converted by ADC, and outputs it in the format:</p> <p>#ADC: $\langle value \rangle$</p> <p>where: $\langle value \rangle$ - pin$\langle adc \rangle$ voltage, expressed in mV</p> <p>Parameters: $\langle adc \rangle$ - index of pin 1 - available for GM862-QUAD, GM862-QUAD-PY, GM862-GPS, GE863-QUAD, GE863-PY, GE863-GPS, GE864-QUAD, GE864-PY, GC864-QUAD and GC864-PY</p>	



#ADC - Analog/Digital Converter Input	SELINT 0 / 1
	<p>2 - available only for GE863-QUAD, GE863-PY, GE864-QUAD, GE864-PY, GC864-QUAD and GC864-PY 3 - available only for GE863-QUAD, GE863-PY, GE864-QUAD, GE864-PY, GC864-QUAD and GC864-PY</p> <p><mode> - required action 2 - query ADC value <dir> - direction; its interpretation is currently not implemented 0 - no effect.</p> <p>If all parameters are omitted the command reports all pins voltage, converted by ADC, in the format:</p> <p>#ADC: <value>[<CR><LF>#ADC: <value>[...]]</p> <p>Note: The command returns the last valid measure.</p>
AT#ADC?	Read command has the same effect as Execution command when all parameters are omitted.
AT#ADC=?	Test command reports the supported range of values of the command parameters <adc>, <mode> and <dir>.

#ADC - Read Analog/Digital Converter input	SELINT 2
<p>AT#ADC= [<adc>,<mode> [,<dir>]]</p>	<p>Execution command reads pin<adc> voltage, converted by ADC, and outputs it in the format:</p> <p>#ADC: <value></p> <p>where: <value> - pin<adc> voltage, expressed in mV</p> <p>Parameters: <adc> - index of pin 1 - available for GM862-QUAD, GM862-QUAD-PY, GM862-GPS, GE863-QUAD, GE863-PY, GE863-GPS, GE864-QUAD, GE864-PY, GC864-QUAD and GC864-PY 2 - available only for GE863-QUAD, GE863-PY, GE864-QUAD, GE864-PY, GC864-QUAD and GC864-PY 3 - available only for GE863-QUAD, GE863-PY, GE864-QUAD, GE864-PY, GC864-QUAD and GC864-PY</p> <p><mode> - required action 2 - query ADC value <dir> - direction; its interpretation is currently not implemented 0 - no effect.</p> <p>Note: The command returns the last valid measure.</p>
AT#ADC?	Read command reports all pins voltage, converted by ADC, in the format:



#ADC - Read Analog/Digital Converter input		SELINT 2
	#ADC: <value>[<CR><LF>#ADC: <value>[...]]	
AT#ADC=?	Test command reports the supported range of values of the command parameters <adc>, <mode> and <dir>.	

3.5.7.1.33 Digital/Analog Converter Control - #DAC

#DAC - Digital/Analog Converter Control		SELINT 0 / 1
AT#DAC[= <enable> [,<value>]]	<p>Set command enables/disables the DAC_OUT pin.</p> <p>Parameters:</p> <p><enable> - enables/disables DAC output. 0 - disables pin; it is in high impedance status (factory default) 1 - enables pin; the corresponding output is driven</p> <p><value> - scale factor of the integrated output voltage; it must be present if <enable>=1 0..1023 - 10 bit precision</p> <p>Note: integrated output voltage = MAX_VOLTAGE * value / 1023</p> <p>Note: if all parameters are omitted then the behaviour of Set command is the same as the Read command.</p>	
AT#DAC?	<p>Read command reports whether the DAC_OUT pin is currently enabled or not, along with the integrated output voltage scale factor, in the format:</p> <p>#DAC: <enable>,<value></p>	
AT#DAC=?	<p>Test command reports the range for the parameters <enable> and <value>.</p>	
Example	<p><i>Enable the DAC out and set its integrated output to the 50% of the max value:</i></p> <pre>AT#DAC=1,511 OK</pre> <p><i>Disable the DAC out:</i></p> <pre>AT#DAC=0 OK</pre>	
Note	<p>With this command the DAC frequency is selected internally. D/A converter must not be used during POWERSAVING.</p> <p>DAC_OUT line must be integrated (for example with a low band pass filter) in order to obtain an analog voltage. For a more in depth description of the integration filter refer to the hardware user guide.</p>	

#DAC - Digital/Analog Converter Control	SELINT 2
--	-----------------



#VAUX- Auxiliary Voltage Output Control		SELINT 2
	enabled or not, in the format: #VAUX: <value>	
AT#VAUX=?	Test command reports the supported range of values for parameters <n>, <stat>.	

3.5.7.1.35 Auxiliary Voltage Output Save - #VAUXSAV

#VAUXSAV - Auxiliary Voltage Output Save		SELINT 2
AT#VAUXSAV	Execution command saves the actual state of #VAUX pin to NVM. The state will be reload at power-up.	
AT#VAUXSAV=?	Test command returns the OK result code.	

3.5.7.1.36 V24 Output Pins Configuration - #V24CFG

#V24CFG - V24 Output Pins Configuration		SELINT 2
AT#V24CFG=<pin>, <mode>	Set command sets the AT commands serial port interface output pins mode. Parameters: <pin> - AT commands serial port interface hardware pin: 0 - DCD (Data Carrier Detect) 1 - CTS (Clear To Send) 2 - RI (Ring Indicator) 3 - DSR (Data Set Ready) <mode> - AT commands serial port interface hardware pins mode: 0 - AT commands serial port mode: output pins are controlled by serial port device driver. (default) 1 - GPIO mode: output pins are directly controlled by #V24 command only.	
AT#V24CFG?	Read command returns actual mode for all the pins (either output and input) in the format: #V24CFG: <pin1>,<mode1>[<CR><LF><CR><LF> #V24CFG: <pin2>,<mode2>[...]] Where: <pinn> - AT command serial port interface HW pin <moden> - AT commands serial port interface hardware pin mode	
AT#V24CFG=?	Test command reports supported range of values for parameters <pin> and <mode>.	

3.5.7.1.37 V24 Output Pins Control - #V24

#V24 - V24 Output Pins Control		SELINT 2
AT#V24=<pin> [,<state>]	Set command sets the AT commands serial port interface output pins state. Parameters:	



#MONI - Cell Monitor	SELINT 0 / 1
	<p> <cc> - country code <nc> - network operator code <n> - progressive number of adjacent cell <bsic> - base station identification code <qual> - quality of reception 0..7 <lac> - localization area code <id> - cell identifier <arfcn> - assigned radio channel <dBm> - received signal strength in dBm <timadv> - timing advance </p> <p>Note: TA: <timadv> is reported only for the serving cell.</p> <p>1. If the last setting done by #MONI is 7, the execution command produces a table-like formatted output, as follows:</p> <p>a. First row reports the identifying name of the 'columns' #MONI: Cell BSIC LAC CellId ARFCN Power C1 C2 TA RxQual PLMN<CR><LF></p> <p>b. Second row reports a complete set of GSM-related information for the serving cell: #MONI: S: <bsic> <lac> <id> <arfcn> <dBm> <C1value> <C2value> <timadv> <qual> <netname><CR><LF></p> <p>c. 3rd to 8th rows report a reduced set of GSM-related information for the cells in the neighbours: #MONI: N<n> <bsic> <lac> <id> <arfcn> <dBm> <C1value> <C2value>[<CR><LF>]</p> <p>where: <C1value> - C1 reselection parameter <C2value> - C2 reselection parameter <i>other parameters as before</i></p>
AT#MONI=?	<p>Test command reports the maximum number of cells, in the neighbour of the serving cell, from which we can extract GSM-related informations, along with the ordinal number of the current selected cell, in the format:</p> <p>#MONI: (<MaxCellNo>,<CellSet>)</p> <p>where: <MaxCellNo> - maximum number of cells, in the neighbour of the serving cell, from which we can extract GSM-related informations (for compatibility with previous versions of code this value is always 5). <CellSet> - the last setting done with command #MONI.</p>



#MONI - Cell Monitor	SELINT 2
	<p><i>table-like format</i></p> <pre>at#moni #MONI: Cell BSIC LAC CellId ARFCN Power C1 C2 TA RxQual PLMN #MONI: S 70 55FA 1D23 736 -83dbm 19 33 1 0 I WIND #MONI: N1 75 55FA 1297 983 -78dbm 26 20 #MONI: N2 72 55FA 1289 976 -82dbm 22 16 #MONI: N3 70 55FA 1D15 749 -92dbm 10 18 #MONI: N4 72 55FA 1D0D 751 -92dbm 10 18 #MONI: N5 75 55FA 1296 978 -95dbm 9 3 #MONI: N6 70 55FA 1D77 756 -99dbm 3 11</pre> <p>OK</p>
Note	<p>The refresh time of the measures is preset to 3 sec. The timing advance value is meaningful only during calls or GPRS transfers active.</p>

3.5.7.1.44 Serving Cell Information - #SERVINFO

#SERVINFO - Serving Cell Information	SELINT 0 / 1
AT#SERVINFO	<p>Execution command reports information about serving cell, in the format:</p> <pre>#SERVINFO: <B-ARFCN>,<dBM>,<NetNameAsc>,<NetCode>,<BSIC>,<LAC>,<TA>,<GPRS>[,<PB-ARFCN>],[<NOM>],[<RAC>],[<PAT>]</pre> <p>where:</p> <ul style="list-style-type: none"> <B-ARFCN> - BCCH ARFCN of the serving cell <dBM> - received signal strength in dBm <NetNameAsc> - operator name, quoted string type <NetCode> - country code and operator code, hexadecimal representation <BSIC> - Base Station Identification Code <LAC> - Localization Area Code <TA> - Time Advance: it's available only if a GSM or GPRS is running <GPRS> - GPRS supported in the cell <ul style="list-style-type: none"> 0 - not supported 1 - supported <p>The following information will be present only if GPRS is supported in the cell</p> <ul style="list-style-type: none"> <PB-ARFCN> - PBCCH ARFCN of the serving cell; it'll be printed only if PBCCH is supported by the cell, otherwise the label "hopping" will be printed <NOM> - Network Operation Mode <ul style="list-style-type: none"> .. "I" "II" .. "III" <RAC> - Routing Area ColoUr Code <PAT> - Priority Access Threshold



#ECAM - Extended Call Monitoring	SELINT 0 / 1
	<p>#ECAM: <ccid>,<ccstatus>,<calltype>,, [<number>,<type>]</p> <p>where</p> <p><ccid> - call ID</p> <p><ccstatus> - call status</p> <ul style="list-style-type: none"> 0 - idle 1 - calling (MO) 2 - connecting (MO) 3 - active 4 - hold 5 - waiting (MT) 6 - alerting (MT) 7 - busy <p><calltype> - call type</p> <ul style="list-style-type: none"> 1 - voice 2 - data <p><number> - called number (valid only for <ccstatus>=1)</p> <p><type> - type of <number></p> <ul style="list-style-type: none"> 129 - national number 145 - international number <p>Note: the unsolicited indication is sent along with usual codes (OK, NO CARRIER, BUSY...).</p> <p>Note: issuing AT#ECAM<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT#ECAM=<CR> returns the OK result code.</p>
AT#ECAM?	<p>Read command reports whether the extended call monitoring function is currently enabled or not, in the format:</p> <p>#ECAM: <onoff></p>
AT#ECAM=?	<p>Test command returns the list of supported values for <onoff></p>

#ECAM - Extended Call Monitoring	SELINT 2
<p>AT#ECAM= [<onoff>]</p>	<p>This command enables/disables the call monitoring function in the ME.</p> <p>Parameter:</p> <p><onoff></p> <ul style="list-style-type: none"> 0 - disables call monitoring function (factory default) 1 - enables call monitoring function; the ME informs about call events, such as incoming call, connected, hang up etc. using the following unsolicited indication: <p>#ECAM: <ccid>,<ccstatus>,<calltype>,, [<number>,<type>]</p>



#ECAM - Extended Call Monitoring	SELINT 2
	<p>where</p> <p><ccid> - call ID</p> <p><ccstatus> - call status</p> <ul style="list-style-type: none"> 0 - idle 1 - calling (MO) 2 - connecting (MO) 3 - active 4 - hold 5 - waiting (MT) 6 - alerting (MT) 7 - busy <p><calltype> - call type</p> <ul style="list-style-type: none"> 1 - voice 2 - data <p><number> - called number (valid only for <ccstatus>=1)</p> <p><type> - type of <number></p> <ul style="list-style-type: none"> 129 - national number 145 - international number <p>Note: the unsolicited indication is sent along with usual codes (OK, NO CARRIER, BUSY...).</p>
AT#ECAM?	<p>Read command reports whether the extended call monitoring function is currently enabled or not, in the format:</p> <p>#ECAM: <onoff></p>
AT#ECAM=?	<p>Test command returns the list of supported values for <onoff></p>

3.5.7.1.51 SMS Overflow - #SMOV

#SMOV - SMS Overflow	SELINT 0 / 1
AT#SMOV[=<mode>]	<p>Set command enables/disables the SMS overflow signalling function.</p> <p>Parameter:</p> <p><mode></p> <ul style="list-style-type: none"> 0 - disables SMS overflow signaling function(factory default) 1 - enables SMS overflow signalling function; when the maximum storage capacity has reached, the following network initiated notification is send: <p>#SMOV: <memo></p> <p>Note: issuing AT#SMOV<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT#SMOV=<CR> is the same as issuing the command AT#SMOV=0<CR>.</p>
AT#SMOV?	<p>Read command reports whether the SMS overflow signalling function is</p>



#CODEC - Audio Codec		SELINT 0 / 1
AT#CODEC?	Read command returns current audio codec mode in the format: #CODEC: <codec>	
AT#CODEC=?	Test command returns the range of available values for parameter <codec>	
Example	AT#CODEC=14 OK <i>sets the codec modes HR (4), EFR (2) and AMR-FR (8)</i>	

#CODEC - Audio Codec		SELINT 2
AT#CODEC= [<codec>]	Set command sets the audio codec mode. Parameter: <codec> 0 - all the codec modes are enabled (factory default) 1..31 - sum of integers each representing a specific codec mode: 1 - FR , full rate mode enabled 2 - EFR , enhanced full rate mode enabled 4 - HR , half rate mode enabled 8 - AMR-FR , AMR full rate mode enabled 16 - AMR-HR , AMR half rate mode enabled Note: the full rate mode is added by default to any setting in the SETUP message (as specified in ETSI 04.08). Note: the setting 0 is equivalent to the setting 31. Note: The codec setting is saved in the profile parameters.	
AT#CODEC?	Read command returns current audio codec mode in the format: #CODEC: <codec>	
AT#CODEC=?	Test command returns the range of available values for parameter <codec>	
Example	AT#CODEC=14 OK <i>sets the codec modes HR (4), EFR (2) and AMR-FR (8)</i>	

3.5.7.1.55 Handsfree Echo Canceller - #SHFEC

#SHFEC - Handsfree Echo Canceller		SELINT 0 / 1
AT#SHFEC[= [<mode>]]	Set command enables/disables the echo canceller function on audio handsfree output.	



#HFMICG - Handsfree Microphone Gain		SELINT 0 / 1
	Note: issuing AT#HFMICG=<CR> returns the OK result code.	
AT#HFMICG?	Read command returns the current handsfree microphone input gain, in the format: #HFMICG: <level>	
AT#HFMICG=?	Test command returns the supported range of values of parameter <level> .	

#HFMICG - Handsfree Microphone Gain		SELINT 2
AT#HFMICG=[<level>]	Set command sets the handsfree microphone input gain Parameter: <level> : handsfree microphone input gain 0..7 - handsfree microphone gain (+6dB/step)	
AT#HFMICG?	Read command returns the current handsfree microphone input gain, in the format: #HFMICG: <level>	
AT#HFMICG=?	Test command returns the supported range of values of parameter <level> .	

3.5.7.1.57 Handset Microphone Gain - #HSMICG

#HSMICG - Handset Microphone Gain		SELINT 0 / 1
AT#HSMICG=[<level>]	Set command sets the handset microphone input gain Parameter: <level> : handset microphone input gain 0..7 - handset microphone gain (+6dB/step) Note: issuing AT#HSMICG<CR> is the same as issuing the Read command. Note: issuing AT#HSMICG=<CR> returns the OK result code.	
AT#HSMICG?	Read command returns the current handset microphone input gain, in the format: #HSMICG: <level>	
AT#HSMICG=?	Test command returns the supported range of values of parameter <level> .	

#HSMICG - Handset Microphone Gain		SELINT 2
AT#HSMICG=[<level>]	Set command sets the handset microphone input gain	



#GPPPCFG - PPP-GPRS Parameters Configuration		SELINT 2
	<p>1 - active mode, the module starts autonomously the LCP negotiation immediately after the CONNECT message</p> <p>Note: if <hostIPAddress>="0.0.0.0" (factory default) the Host IP Address assigned to the host application is the previous remote IP Address obtained by the Network.</p>	
AT# GPPPCFG?	<p>Read command reports the current PPP-GPRS connection parameters in the format:</p> <p>#GPPPCFG: <hostIPAddress>,<LCPTimeout>,<PPPmode></p>	
AT# GPPPCFG=?	<p>Test command returns the range of supported values for parameter <LCPTimeout> and <PPPmode>, in the format:</p> <p>#PPPCFG: "",(10-600),(0,1)</p>	

3.5.7.1.81 RTC Status - #RTCSTAT

#RTCSTAT - RTC Status		SELINT 0 / 1
AT#RTCSTAT[=<status>]	<p>Set command resets the RTC status flag.</p> <p>Parameter: <status> 0 - Set RTC Status to RTC HW OK</p> <p>Note: the initial value of RTC status flag is RTC HW Error and it doesn't change until a command AT#RTCSTAT=0 is issued.</p> <p>Note: if a power failure occurs and the buffer battery is down the RTC status flag is set to 1. It doesn't change until command AT#RTCSTAT=0 is issued.</p> <p>Note: if parameter <status> is omitted the behaviour of Set command is the same as Read command.</p>	
AT#RTCSTAT?	<p>Read command reports the current value of RTC status flag, in the format:</p> <p>#RTCSTAT: <status></p>	
AT#RTCSTAT=?	<p>Test command returns the range of supported values for parameter <status></p>	

#RTCSTAT - RTC Status	SELINT 2
-----------------------	----------



#RTCSTAT - RTC Status		SELINT 2
AT#RTCSTAT= [<status>]	<p>Set command resets the RTC status flag.</p> <p>Parameter: <status> 0 - Set RTC Status to RTC HW OK</p> <p>Note: the initial value of RTC status flag is RTC HW Error and it doesn't change until a command AT#RTCSTAT=0 is issued.</p> <p>Note: if a power failure occurs and the buffer battery is down the RTC status flag is set to 1. It doesn't change until command AT#RTCSTAT=0 is issued.</p>	
AT#RTCSTAT?	<p>Read command reports the current value of RTC status flag, in the format:</p> <p>#RTCSTAT: <status></p>	
AT#RTCSTAT=?	<p>Test command returns the range of supported values for parameter <status></p>	

3.5.7.1.82 GSM Antenna Detection - #GSMAD

#GSMAD - GSM Antenna Detection		SELINT 2
AT#GSMAD= <mod>, [<urcmode> [,<interval> [,<detGPIO> [,<repGPIO>]]]]	<p>Set command sets the behaviour of antenna detection algorithm</p> <p>Parameters: <mod> 0 - antenna detection algorithm not active 1 - periodic activation of the antenna detection algorithm; detection is started every <interval> period, using <detGPIO> for detection; if the algorithm detects a change in the antenna status the module is notified by URC #GSMAD (see format below) 2 - instantaneous activation of the antenna detection algorithm; if the algorithm detects a change in the antenna status the module is notified by URC #GSMAD (see format below); this instantaneous activation doesn't affect a periodic activation eventually started before</p> <p>URC format:</p> <p>#GSMAD: <presence></p> <p>where: <presence> 0 - antenna connected. 1 - antenna connector short circuited to ground. 2 - antenna connector short circuited to power. 3 - antenna not detected (open).</p>	



	<p>context</p> <p>0</p> <p><P_type> - protocol type; a string parameter which specifies the type of protocol</p> <p>"IP" - Internet Protocol</p> <p><CSD_num> - phone number of the internet service provider</p> <p>Note: issuing #CGDCONT=0 causes the values for context number 0 to become undefined.</p>
AT#GSMCONT?	<p>Read command returns the current settings for the GSM context, if defined, in the format:</p> <p>+CGDCONT: <cid>,<P_type>,<CSD_num></p>
AT#GSMCONT=?	<p>Test command returns the supported range of values for all the parameters.</p>

3.5.7.1.88 Show Address - #CGPADDR

#CGPADDR - Show Address	SELINT 2
<p>AT#CGPADDR= [<cid>,<cid> [,...]]]</p>	<p>Execution command returns either the IP address for the GSM context (if specified) and/or a list of PDP addresses for the specified PDP context identifiers</p> <p>Parameters:</p> <p><cid> - context identifier</p> <p>0 - specifies the GSM context (see +GSMCONT).</p> <p>1..5 - numeric parameter which specifies a particular PDP context definition (see +CGDCONT command).</p> <p>Note: if no <cid> is specified, the addresses for all defined contexts are returned.</p> <p>Note: issuing the command with more than 6 parameters raises an error.</p> <p>Note: the command returns only one row of information for every specified <cid>, even if the same <cid> is present more than once.</p> <p>The command returns a row of information for every specified <cid> whose context has been already defined. No row is returned for a <cid> whose context has not been defined yet. Response format is:</p> <p>#CGPADDR: <cid>,<address>[<CR><LF> #CGPADDR: <cid>,<address>[...]]]</p> <p>where:</p> <p><cid> - context identifier, as before</p> <p><address> - its meaning depends on the value of <cid></p> <p>a) if <cid> is the (only) GSM context identifier (<cid>=0) it is</p>



	#NWSCANTMR: <tmr>
AT#NWSCANTMR=?	Test command reports the supported range of values for parameter <tmr>
Note	How much time it takes to execute the network scan depends either on how much bands have been selected and on network configuration (mean value is 5 seconds)

3.5.7.2 General Configuration AT Commands - Special Issues

Following commands are available only for specific subsets of products, as it appears in the 'Note'

3.5.7.2.1 External 32kHz Oscillator

#OSC32KHZ - External 32kHz Oscillator		SELINT 2
AT#OSC32KHZ	<p>Execution command reports the presence of an external 32kHz oscillator, in the format:</p> <p>#OSC32KHZ: <stat></p> <p>where:</p> <p><stat></p> <p>0 - external 32kHz oscillator is not present 1 - external 32kHz oscillator is present</p> <p>Note: if the external oscillator is removed while the module is on, the software will take up to 9 seconds to realize its absence.</p> <p>Note: if the external oscillator is connected to the module while it is on, the software will take less than 1 second to realize its presence.</p>	
AT#OSC32KHZ=?	Test command returns the OK result code.	
Note	This command is currently available only for the product GE864-AUTO	

3.5.7.3 Multisocket AT Commands

3.5.7.3.1 Socket Status - #SS

#SS - Socket Status		SELINT 2
AT#SS	<p>Execution command reports the current status of the sockets in the format:</p> <p>#SS: <connId>,<state>,<locIP>,<locPort>,<remIP>,<remPort> [<CR><LF><connId>,<state>,<locIP>,<locPort>,<remIP>,<remPort> [...]]</p> <p>where:</p>	



#SI - Socket Info	SELINT 2
	<p>the value <code><ack_waiting></code> is always 0 for UDP connections.</p> <p>Note: issuing <code>#SI<CR></code> causes getting information about data traffic of all the sockets; the response format is:</p> <p>#SI: <connId>,<sent1>,<received1>,<buff_in1>,<ack_waiting1> <CR><LF></p> <p>...</p> <p>#SI: <connId6>,<sent6>,<received6>,<buff_in6>,<ack_waiting6></p>
AT#SI=?	Test command reports the range for parameter <code><connId></code> .
Example	<pre>AT#SI #SI: 1,123,400,10,50 #SI: 2,0,100,0,0 #SI: 3,589,100,10,100 #SI: 4,0,0,0,0 #SI: 5,0,0,0,0 #SI: 6,0,98,60,0 OK <i>Sockets 1,2,3,6 are opened with some data traffic. For example socket 1 has 123 bytes sent, 400 bytes received, 10 byte waiting to be read and 50 bytes waiting to be acknowledged from the remote side.</i> AT#SI=1 #SI: 1,123,400,10,50 OK <i>We have information only about socket number 1</i></pre>

3.5.7.3.3 Context Activation - #SGACT

#SGACT - Context Activation	SELINT 2
AT#SGACT=<cid>,<stat>[,<userId>,<pwd>]	<p>Execution command is used to activate or deactivate either the GSM context or the specified PDP context.</p> <p>Parameters:</p> <p><cid> - PDP context identifier 0 - specifies the GSM context 1..5 - numeric parameter which specifies a particular PDP context definition</p> <p><stat> 0 - deactivate the context 1 - activate the context</p>



#SCFG - Socket Configuration	SELINT 2
#SCFG: 6,1,300,90,600,50	
OK	

3.5.7.3.6 Socket Configuration Extended - #SCFGEXT

#SCFGEXT - Socket Configuration Extended	SELINT 2
AT#SCFGEXT= <connId> , <srMode> , <dataMode> , <keepalive> [,<unused_A> [,<unused_B>]]	<p>Set command sets the socket configuration extended parameters.</p> <p>Parameters:</p> <p><connId> - socket connection identifier 1..6</p> <p><srMode> - SRing URC mode 0 - normal mode (default): SRING : <connId> where: <connId> - socket connection identifier, as before</p> <p>1 - data amount mode: SRING : <connId>,<recData> where: <connId> - as before <recData> - amount of data received on the socket connection</p> <p>2 - data view mode: SRING : <connId>,<recData>,<data> where: <connId> - <recData> - as before <data> - received data; the presentation format depends on the subparameter <dataMode> value</p> <p><dataMode> - “data view mode” presentation format 0 - data represented as text (default) 1 - data represented as sequence of hexadecimal numbers (from 00 to FF)</p> <p><keepalive> - TCP keepalive timer timeout 0 - TCP keepalive timer is deactivated (default) 1..240 - TCP keepalive timer timeout in minutes</p> <p><unused_A> - currently not used 0 - reserved for future use</p> <p><unused_B> - currently not used 0 - reserved for future use</p> <p>Note: <keepalive> has effect only on TCP connections. Note: these values are automatically saved in NVM.</p>
AT#SCFGEXT?	<p>Read command returns the current socket extended configuration parameters values for all the six sockets, in the format:</p> <p>#SCFGEXT: <connId1>,<srMode1>,<dataMode1>,<keepalive1>,</p>



3.5.7.4 FTP AT Commands

3.5.7.4.1 FTP Time-Out - #FTPTO

#FTPTO - FTP Time-Out		SELINT 0 / 1
AT#FTPTO[= <tout>]	<p>Set command sets the time-out used when opening either the FTP control channel or the FTP traffic channel.</p> <p>Parameter: <tout> - time-out in 100 ms units 100..5000 - hundreds of ms (factory default is 100)</p> <p>Note: The parameter is not saved in NVM.</p> <p>Note: if parameter <tout> is omitted the behaviour of Set command is the same as Read command.</p>	
AT#FTPTO?	<p>Read command returns the current FTP operations time-out, in the format:</p> <p>#FTPTO: <tout></p>	
AT#FTPTO=?	<p>Test command returns the range of supported values for parameter <tout></p>	

#FTPTO - FTP Time-Out		SELINT 2
AT#FTPTO= [<tout>]	<p>Set command sets the time-out used when opening either the FTP control channel or the FTP traffic channel.</p> <p>Parameter: <tout> - time-out in 100 ms units 100..5000 - hundreds of ms (factory default is 100)</p> <p>Note: The parameter is not saved in NVM.</p>	
AT#FTPTO?	<p>Read command returns the current FTP operations time-out, in the format:</p> <p>#FTPTO: <tout></p>	
AT#FTPTO=?	<p>Test command returns the range of supported values for parameter <tout></p>	

3.5.7.4.2 FTP Open - #FTPOPEN

#FTPOPEN - FTP Open		SELINT 0 / 1
AT#FTPOPEN= <server:port>, <username>, <password>, <mode>	<p>Execution command opens an FTP connection toward the FTP server.</p> <p>Parameters: <server:port> - string type, address and port of FTP server (factory default port 21). <username> - string type, authentication user identification string for FTP. <password> - string type, authentication password for FTP. <mode> 0 - active mode (default)</p>	



#FTPOPEN - FTP Open	SELINT 0 / 1
1 - passive mode	
Note: Before opening an FTP connection the GPRS context must have been activated by AT#GPRS=1	

#FTPOPEN - FTP Open	SELINT 2
AT#FTPOPEN= [<server:port>, <username>, <password>, <mode>]	Execution command opens an FTP connection toward the FTP server. Parameters: <server:port> - string type, address and port of FTP server (factory default port 21). <username> - string type, authentication user identification string for FTP. <password> - string type, authentication password for FTP. <mode> 0 - active mode (factory default) 1 - passive mode Note: Before opening an FTP connection either the GSM context must have been activated by AT#SGACT=0,1 or the PDP context #1 must have been activated by AT#SGACT=1,1 or by AT#GPRS=1
AT#FTPOPEN=?	Test command returns the OK result code.

3.5.7.4.3 FTP Close - #FTPCLOSE

#FTPCLOSE - FTP Close	SELINT 0 / 1
AT#FTPCLOSE	Execution command closes an FTP connection.
AT#FTPCLOSE?	Read command behavior is the same as Execution command.

#FTPCLOSE - FTP Close	SELINT 2
AT#FTPCLOSE	Execution command closes an FTP connection.
AT#FTPCLOSE=?	Test command returns the OK result code.

3.5.7.4.4 FTP Put - #FTPPUT

#FTPPUT - FTP Put	SELINT 0 / 1
AT#FTPPUT= <filename>	Execution command, issued during an FTP connection, opens a data connection, in order to transfer a file to the server. If the data connection succeeds, a file with name <filename> and initial size 0 is created on the FTP server, a CONNECT indication is sent and it's possible to transfer the file; otherwise a NO CARRIER indication is sent. Parameter: <filename> - string type, name of the file to create on FTP server.



#FTPGET - FTP Get	SELINT 2
	<p>The file is received on the serial port.</p> <p>Parameter: <filename> - file name, string type.</p> <p>Note: The command causes an ERROR result code to be returned in case no FTP connection has been opened yet.</p> <p>Note: Command closure should always be handled by application. In order to avoid download stall situations a timeout should be implemented by the application.</p>
AT#FTPGET=?	Test command returns the OK result code.

3.5.7.4.6 FTP Type - #FTPTYPE

#FTPTYPE - FTP Type	SELINT 0 / 1
AT#FTPTYPE[=<type>]	<p>Set command, issued during an FTP connection, sets the file transfer type.</p> <p>Parameter: <type> - file transfer type: 0 - binary 1 - ascii</p> <p>Note: The command causes an ERROR result code to be returned if no FTP connection has been opened yet.</p> <p>Note: If the parameter is omitted then the behaviour of Set command is the same of Read command.</p>
#FTPTYPE?	<p>Read command returns the current file transfer type, in the format:</p> <p>#FTPTYPE: <type></p>
#FTPTYPE=?	<p>Test command returns the range of available values for parameter <type>:</p> <p>#FTPTYPE: (0,1)</p>

#FTPTYPE - FTP Type	SELINT 2
AT#FTPTYPE=[<type>]	<p>Set command, issued during an FTP connection, sets the file transfer type.</p> <p>Parameter: <type> - file transfer type: 0 - binary 1 - ascii</p> <p>Note: The command causes an ERROR result code to be returned if no FTP connection has been opened yet.</p>
#FTPTYPE?	Read command returns the current file transfer type, in the format:



#FTPPWD - FTP Print Working Directory		SELINT 0 / 1
	Note: The command causes an ERROR result code to be returned if no FTP connection has been opened yet.	

#FTPPWD - FTP Print Working Directory		SELINT 2
AT#FTPPWD	Execution command, issued during an FTP connection, shows the current working directory on FTP server. Note: The command causes an ERROR result code to be returned if no FTP connection has been opened yet.	
AT#FTPPWD=?	Test command returns the OK result code.	

3.5.7.4.10 FTP Change Working Directory - #FTPCWD

#FTPCWD - FTP Change Working Directory		SELINT 0 / 1
AT#FTPCWD=<dirname>	Execution command, issued during an FTP connection, changes the working directory on FTP server. Parameter: <dirname> - string type, it's the name of the new working directory. Note: The command causes an ERROR result code to be returned if no FTP connection has been opened yet.	

#FTPCWD - FTP Change Working Directory		SELINT 2
AT#FTPCWD=[<dirname>]	Execution command, issued during an FTP connection, changes the working directory on FTP server. Parameter: <dirname> - string type, it's the name of the new working directory. Note: The command causes an ERROR result code to be returned if no FTP connection has been opened yet.	
AT#FTPCWD=?	Test command returns the OK result code.	

3.5.7.4.11 FTP List - #FTPLIST

#FTPLIST - FTP List	SELINT 0 / 1
----------------------------	---------------------



#PASSW - Authentication Password	SELINT 0/1
OK	

#PASSW - Authentication Password	SELINT 2
AT#PASSW=[<pwd>]	<p>Set command sets the user password string to be used during the authentication step.</p> <p>Parameter: <pwd> - string type, it's the authentication password; the max length for this value is the output of Test command, AT#PASSW=? (factory default is the empty string "").</p> <p>Note: this command is not allowed for sockets associated to a GSM context (see #SCFG).</p>
AT#PASSW=?	Test command returns the maximum allowed length of the string parameter <pwd> .
Example	<pre>AT#PASSW="myPassword" OK</pre>

3.5.7.5.3 Packet Size - #PKTSZ

#PKTSZ - Packet Size	SELINT 0 / 1
AT#PKTSZ=[<size>]	<p>Set command sets the default packet size to be used by the TCP/UDP/IP stack for data sending.</p> <p>Parameter: <size> - packet size in bytes 0 - automatically chosen by the device 1..512 - packet size in bytes (factory default is 300)</p> <p>Note: issuing AT#PKTSZ<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT#PKTSZ=<CR> is the same as issuing the command AT#PKTSZ=0<CR>.</p>
AT#PKTSZ?	<p>Read command reports the current packet size value.</p> <p>Note: after issuing command AT#PKTSZ=0, the Read command reports the value automatically chosen by the device.</p>
AT#PKTSZ=?	Test command returns the allowed values for the parameter <size> .
Example	<pre>AT#PKTSZ=100 OK AT#PKTSZ? #PKTSZ: 100 OK AT#PKTSZ=0 OK AT#PKTSZ?</pre>



#PKTSZ - Packet Size	SELINT 0 / 1
#PKTSZ: 300 ->value automatically chosen by device	
OK	

#PKTSZ - Packet Size	SELINT 2
AT#PKTSZ=[<size>]	Set command sets the default packet size to be used by the TCP/UDP/IP stack for data sending. Parameter: <size> - packet size in bytes 0 - automatically chosen by the device 1..1500 - packet size in bytes (factory default is 300) Note: this command is not allowed for sockets associated to a GSM context (see #SCFG).
AT#PKTSZ?	Read command reports the current packet size value. Note: after issuing command AT#PKTSZ=0 , the Read command reports the value automatically chosen by the device.
AT#PKTSZ=?	Test command returns the allowed values for the parameter <size> .
Example	AT#PKTSZ=100 OK AT#PKTSZ? #PKTSZ: 100 OK AT#PKTSZ=0 OK AT#PKTSZ? #PKTSZ: 300 ->value automatically chosen by device OK

3.5.7.5.4 Data Sending Time-Out - #DSTO

#DSTO - Data Sending Time-Out	SELINT 0 / 1
AT#DSTO[=[<tout>]]	Set command sets the maximum time that the module awaits before sending anyway a packet whose size is less than the default one. Parameter: <tout> - packet sending time-out in 100ms units (factory default is 50) 0 - no time-out, wait forever for packets to be completed before send. 1..255 hundreds of ms Note: In order to avoid low performance issues, it is suggested to set the data sending time-out to a value greater than 5.



#SKTOP - Socket Open	SELINT 2
	..GPRS context activation, authentication and socket open.. CONNECT
Note	This command is obsolete. It's suggested to use the couple #SGACT and #SO instead of it.

3.5.7.5.8 Query DNS - #QDNS

#QDNS - Query DNS	SELINT 0 / 1
AT#QDNS= <host name>	<p>Execution command executes a DNS query to solve the host name into an IP address.</p> <p>Parameter: <host name> - host name, string type.</p> <p>If the DNS query is successful then the IP address will be reported in the result code, as follows:</p> <p>#QDNS: <host name>,<IP address></p> <p>where <host name> - string type <IP address> - string type, in the format "xxx.xxx.xxx.xxx"</p> <p>Note: the command has to activate the GPRS context if it was not previously activated. In this case the context is deactivated after the DNS query.</p>
Note	This command requires that the authentication parameters are correctly set and that the GPRS network is present.
Note	Issuing command #QDNS will overwrite <remote addr> setting for command #SKTSET.

#QDNS - Query DNS	SELINT 2
AT#QDNS= [<host name>]	<p>Execution command executes a DNS query to solve the host name into an IP address.</p> <p>Parameter: <host name> - host name, string type.</p> <p>If the DNS query is successful then the IP address will be reported in the result code, as follows:</p> <p>#QDNS: <host name>,<IP address></p> <p>where <host name> - string type</p>



#QDNS - Query DNS	SELINT 2
	<p><IP address> - string type, in the format “xxx.xxx.xxx.xxx”</p> <p>Note: the command has to activate the GPRS context if it was not previously activated. In this case the context is deactivated after the DNS query. It also works with GSM context, but the GSM context has to be activated before.</p>
AT#QDNS=?	Test command returns the OK result code.
Note	This command requires that the authentication parameters are correctly set and that the GPRS network is present (or GSM, if GSM context is used).
Note	Issuing command #QDNS will overwrite <remote addr> setting for command #SKTSET .

3.5.7.5.9 DNS Response Caching - #CACHEDNS

#CACHEDNS – DNS Response Caching	SELINT 2
<p>AT#CACHEDNS= [<mode>]</p>	<p>Set command enables caching a mapping of domain names to IP addresses, as does a resolver library.</p> <p>Parameter: <mode> 0 - caching disabled; it cleans the cache too 1 - caching enabled</p> <p>Note: the validity period of each cached entry (i.e. how long a DNS response remains valid) is determined by a value called the Time To Live (TTL), set by the administrator of the DNS server handing out the response.</p> <p>Note: it is recommended to clean the cache, if command +CCLK has been issued while the DNS Response Caching was enabled.</p>
AT#CACHEDNS?	<p>Read command reports whether the DNS Response Caching is currently enabled or not, in the format:</p> <p>#CACHEDNS: <mode></p>
AT#CACHEDNS=?	<p>Test command returns the currently cached mapping along with the range of available values for parameter <mode>, in the format:</p> <p>#CACHEDNS: [<hostn1>,<IPaddr1>,[...,<hostnn>,<IPaddrn>]](0,1)</p> <p>where: <hostnn> - hostname, string type <IPaddrn> - IP address, string type, in the format “xxx.xxx.xxx.xxx”</p>

3.5.7.5.10 Manual DNS Selection - #DNS



3.5.7.5.12 Socket Parameters Save - #SKTSAV

#SKTSAV - Socket Parameters Save		SELINT 0 / 1
AT#SKTSAV	<p>Execution command stores the current socket parameters in the NVM of the device.</p> <p>The socket parameters to store are:</p> <ul style="list-style-type: none"> - User ID - Password - Packet Size - Socket Inactivity Time-Out - Data Sending Time-Out - Socket Type (UDP/TCP) - Remote Port - Remote Address - TCP Connection Time-Out 	
Example	AT#SKTSAV OK <i>socket parameters have been saved in NVM</i>	
Note	If some parameters are not previously specified then a default value will be stored.	

#SKTSAV - Socket Parameters Save		SELINT 2
AT#SKTSAV	<p>Execution command stores the current socket parameters in the NVM of the device.</p> <p>The socket parameters to store are:</p> <ul style="list-style-type: none"> - User ID - Password - Packet Size - Socket Inactivity Time-Out - Data Sending Time-Out - Socket Type (UDP/TCP) - Remote Port - Remote Address - TCP Connection Time-Out <p>Note: this command is not allowed for sockets associated to a GSM context (see #SCFG).</p>	
AT#SKTSAV=?	Test command returns the OK result code.	
Example	AT#SKTSAV OK <i>socket parameters have been saved in NVM</i>	
Note	If some parameters have not been previously specified then a default value will be stored.	



#SKTL - Socket Listen	SELINT 2
	<p>device.</p> <p>When the connection is established the CONNECT indication is given and the modem goes into data transfer mode.</p> <p>On connection close or when context is closed with #GPRS=0 the socket is closed and no listen is anymore active.</p> <p>If the context is closed by the network while in listening, the socket is closed, no listen is anymore active and an unsolicited code is reported:</p> <p>#SKTL: ABORTED</p> <p>Note: this command is not allowed for sockets associated to a GSM context (see #SCFG).</p>
<p>AT#SKTL?</p>	<p>Read command returns the current socket listening status and the last settings of parameters <input port> and <closure type>, in the format:</p> <p>#SKTL: <status>,<input port>,<closure type></p> <p>Where</p> <p><status> - socket listening status</p> <p>0 - socket not listening</p> <p>1 - socket listening</p>
<p>AT#SKTL=?</p>	<p>Test command returns the allowed values for parameters <mode>, <socket type>, <input port> and <closure type>.</p>
<p>Example</p>	<p><i>Activate GPRS</i></p> <pre>AT#GPRS=1 +IP: ###.###.###.### OK <i>Start listening</i> AT#SKTL=1,0,1024 OK or AT#SKTL=1,0,1024,255 OK <i>Receive connection requests</i> +CONN FROM: 192.164.2.1 CONNECT <i>exchange data with the remote host</i> <i>send escape sequence</i> +++ NO CARRIER <i>Now listen is not anymore active</i></pre>



@SKTL - Socket Listen Improved	SELINT 0 / 1
	<p>When the connection is established the CONNECT indication is given and the modem goes into data transfer mode.</p> <p>On connection close or when context is closed with #GPRS=0 the socket is closed and no listen is anymore active.</p> <p>If the context is closed by the network while in listening, the socket is closed, no listen is anymore active and an unsolicited code is reported:</p> <p style="text-align: center;">@SKTL: ABORTED</p> <p>Note: if all parameters are omitted the command returns the current socket listening status and the last settings of parameters <socket type>, <input port> and <closure type>, in the format:</p> <p>@SKTL: <status>,<socket type>,<input port>,<closure type> Where <status> - socket listening status 0 - socket not listening 1 - socket listening</p>
AT@SKTL?	Read command has the same effect as Execution command when parameters are omitted.
AT@SKTL=?	Test command returns the allowed values for parameters <mode> , <socket type> , <input port> and <closure type> .
Example	<pre> Activate GPRS AT#GPRS=1 +IP: ###.###.###.### OK Start listening AT@SKTL=1,0,1024 OK or AT@SKTL=1,0,1024,255 OK Receive connection requests +CONN FROM: 192.164.2.1 CONNECT exchange data with the remote host send escape sequence +++ NO CARRIER Now listen is not anymore active </pre>



#EUSER - E-mail Authentication User Name		SELINT 0 / 1
	#EUSER: <e-user>	
AT#EUSER=?	Test command returns the maximum allowed length of the string parameter <e-user> .	
Example	AT#EUSER="myE-Name" OK AT#EUSER? #EUSER: "myE-Name" OK	
Note	It is a different user field than the one used for GPRS authentication (see #USERID).	

#EUSER - E-mail Authentication User Name		SELINT 2
AT#EUSER=[<e-user>]	Set command sets the user identification string to be used during the authentication step of the SMTP. Parameter: <e-user> - e-mail authentication User ID, string type. - any string value up to max length reported in the Test command. (factory default is the empty string "") Note: if no authentication is required then the <e-user> parameter shall be empty "".	
AT#EUSER?	Read command reports the current user identification string, in the format: #EUSER: <e-user>	
AT#EUSER=?	Test command returns the maximum allowed length of the string parameter <e-user> .	
Example	AT#EUSER="myE-Name" OK AT#EUSER? #EUSER: "myE-Name" OK	
Note	It is a different user field than the one used for GPRS authentication (see #USERID).	

3.5.7.6.4 E-mail Authentication Password - #EPASSW

#EPASSW - E-mail Authentication Password		SELINT 0 / 1
AT#EPASSW=<e-pwd>	Set command sets the password string to be used during the authentication step of the SMTP. Parameter: <e-pwd> - e-mail authentication password, string type. - any string value up to max length reported in the Test command.	



#EPASSW - E-mail Authentication Password		SELINT 0 / 1
	(factory default is the empty string "") Note: if no authentication is required then the <e-pwd> parameter shall be empty "".	
AT#EPASSW=?	Test command returns the maximum allowed length of the string parameter <e-pwd> .	
Example	AT#USERID="myPassword" OK	
Note	It is a different password field than the one used for GPRS authentication (see #PASSW).	

#EPASSW - E-mail Authentication Password		SELINT 2
AT#EPASSW= [<e-pwd>]	Set command sets the password string to be used during the authentication step of the SMTP. Parameter: <e-pwd> - e-mail authentication password, string type. - any string value up to max length reported in the Test command. (factory default is the empty string "") Note: if no authentication is required then the <e-pwd> parameter shall be empty "".	
AT#EPASSW=?	Test command returns the maximum allowed length of the string parameter <e-pwd> .	
Example	AT#EPASSW="myPassword" OK	
Note	It is a different password field than the one used for GPRS authentication (see #PASSW).	

3.5.7.6.5 E-mail Sending With GPRS Context Activation - #SEMAIL

#SEMAIL - E-mail Sending With GPRS Context Activation		SELINT 0 / 1
AT#SEMAIL=<da>, <subj>,<att> [,<filename>]	Execution command activates a GPRS context, if not previously activated by #EMAILACT , and sends an e-mail message. The GPRS context is deactivated when the e-mail is sent. Parameters: <da> - destination address, string type. <subj> - subject of the message, string type. <att> - attached image flag; if <filename> is present and not empty, <att> is assumed to be always 1, no matter what value it really is. 0 - don't attach any image 1 - attach the last snapshot taken <filename> - attached image file name on remote party (default is "snapshot.jpg")	



#EMAILACT - E-mail GPRS Context Ativation	SELINT 2
	<p>context #1 raises an error.</p> <p>Note: if the PDP context #1 has been activated issuing AT#EMAILACT=1, then</p> <ul style="list-style-type: none"> • if you request to deactivate the PDP context #1 issuing AT#GPRS=0 DTE receives the final result code OK but nothing really happens • if you request to deactivate the PDP context #1 during a call issuing AT#EMAILACT=0 and then, after the call termination, you want to activate the PDP context #1 again through #EMAILACT, you need to issue the following sequence of three commands <pre> AT#EMAILACT=1 OK AT#EMAILACT=0 OK AT#EMAILACT=1 OK </pre> <p><i>(Analogous considerations if you want to request the activation of PDP context #1 issuing AT#GPRS=1, see #GPRS)</i></p> <p>Note: this command is not allowed if GSM context is active (see AT#SGACT=0,1).</p>
AT#EMAILACT?	<p>Read command reports the current status of the GPRS context for the e-mail, in the format:</p> <p>#EMAILACT: <status></p> <p>where:</p> <p><status></p> <ul style="list-style-type: none"> 0 - GPRS context deactivated 1 - GPRS context activated
AT#EMAILACT=?	Test command returns the allowed values for parameter <mode> .
Example	<pre> AT#EMAILACT=1 OK Now GPRS Context has been activated AT# EMAILACT=0 OK Now GPRS context has been deactivated. </pre>
Note	It is strongly recommended to use the same command (e.g. #EMAILACT) to activate the context, deactivate it and interrogate about its status.

3.5.7.6.7 E-mail Sending - #EMAILD



3.5.7.6.10 SMTP Read Message - #EMAILMSG

#EMAILMSG - SMTP Read Message		SELINT 0 / 1
AT#EMAILMSG	Execution command returns the last response from SMTP server.	
AT#EMAILMSG?	Read command has the same behaviour as Execution command.	

#EMAILMSG - SMTP Read Message		SELINT 2
AT#EMAILMSG	Execution command returns the last response from SMTP server.	
AT#EMAILMSG=?	Test command returns the OK result code.	

3.5.7.7 Easy Scan® Extension AT Commands

Note: it is strongly suggested to issue all the Easy Scan® Extension AT commands with **NO SIM** inserted, to avoid a potential conflict with normal module operations, such as “incoming call”, “periodic location update”, “periodic routing area update” and so on.

3.5.7.7.1 Network Survey - #CSURV

#CSURV - Network Survey		SELINT 0 / 1
AT#CSURV [=<s>,<e>]	Execution command allows to perform a quick survey through channels belonging to the band selected by last #BND command issue, starting from channel <s> to channel <e>. If parameters are omitted, a full band scan is performed.	
AT*CSURV [=<s>,<e>] <i>(both syntax are possible)</i>	Parameters: <s> - starting channel <e> - ending channel	
	After issuing the command the device responds with the string: Network survey started...	
	and, after a while, a list of informations, one for each received carrier, is reported, each of them in the format:	
	(For BCCH-Carrier)	
	arfcn: <arfcn> bsic: <bsic> rxLev: <rxLev> ber: <ber> mcc: <mcc> mnc: <mnc> lac: <lac> cellId: <cellId> cellStatus: <cellStatus> numArfcn: <numArfcn> arfcn: [<arfcn1> ..<arfcn64>]] [numChannels: <numChannels> array: [<ba1> ..<ba32>]] [pbcch: <pbcch> [nom: <nom> rac: <rac> spgc: <spgc> pat: <pat> nco: <nco> t3168: <t3168> t3192: <t3192> drxmax: <drxmax> ctrlAck: <ctrlAck> bsCVmax: <bsCVmax> alpha: <alpha> pcMeasCh: <pcMeasCh>]]] 	



#CSURV - Network Survey	SELINT 0 / 1
<p><CR><LF><CR><LF><CR><LF></p> <p>where:</p> <p><arfcn> - C0 carrier assigned radio channel (BCCH - Broadcast Control Channel)</p> <p><bsic> - base station identification code</p> <p><rxLev> - reception level (in dBm)</p> <p><ber> - bit error rate (in %)</p> <p><mcc> - mobile country code</p> <p><mnc> - mobile network code</p> <p><lac> - location area code</p> <p><cellId> - cell identifier</p> <p><cellStatus> - cell status</p> <p>..CELL_SUITABLE - C0 is a suitable cell.</p> <p>CELL_LOW_PRIORITY - the cell is low priority based on the received system information.</p> <p>CELL_FORBIDDEN - the cell is forbidden.</p> <p>CELL_BARRED - the cell is barred based on the received system information.</p> <p>CELL_LOW_LEVEL - the cell <rxLev> is low.</p> <p>CELL_OTHER - none of the above e.g. exclusion timer running, no BCCH available...etc.</p> <p><numArfcn> - number of valid channels in the Cell Channel Description</p> <p><arfcn> - arfcn of a valid channel in the Cell Channel Description (<i>n</i> is in the range 1..<numArfcn>)</p> <p><numChannels> - number of valid channels in the BCCH Allocation list; the output of this information for non-serving cells depends on last #CSURVEXT setting:</p> <ol style="list-style-type: none"> 1. if #CSURVEXT=0 this information is displayed only for serving cell 2. if #CSURVEXT=1 or 2 this information is displayed also for every valid scanned BCCH carrier. <p><ban> - arfcn of a valid channel in the BA list (<i>n</i> is in the range 1..<numChannels>); the output of this information for non-serving cells depends on last #CSURVEXT setting:</p> <ol style="list-style-type: none"> 1. if #CSURVEXT=0 this information is displayed only for serving cell 2. if #CSURVEXT=1 or 2 this information is displayed also for every valid scanned BCCH carrier. <p><i>(The following informations will be printed only if GPRS is supported in the cell)</i></p> <p><pbcch> - packet broadcast control channel</p> <p>0 - pbcch not activated on the cell</p> <p>1 - pbcch activated on the cell</p> <p><nom> - network operation mode</p> <p>1</p>	



#CSURV - Network Survey	SELINT 0 / 1
<p>2 3</p> <p><rac> - routing area code 0..255 -</p> <p><spgc> - SPLIT_PG_CYCLE support ..0 - SPLIT_PG_CYCLE is not supported on CCCH on this cell ..1 - SPLIT_PG_CYCLE is supported on CCCH on this cell</p> <p><pat> - priority access threshold 0 - 3..6 -</p> <p><nco> - network control order 0..2 -</p> <p><t3168> - timer 3168 <t3192> - timer 3192 <drxmax> - discontinuous reception max time (in seconds) <ctrlAck> - packed control ack <bsCVmax> - blocked sequenc countdown max value <alpha> - alpha parameter for power control <pcMeasCh> - type of channel which shall be used for downlink measurements for power control 0 - BCCH 1 - PDCH</p> <p style="text-align: center;">(For non BCCH-Carrier)</p> <p>arfcn: <arfcn> rxLev: <rxLev></p> <p>where: <arfcn> - RF channel <rxLev> - reception level (in dBm)</p> <p>Lastly, the #CSURV output ends in two ways, depending on the last #CSURVF setting:</p> <p style="text-align: center;">if #CSURVF=0 or #CSURVF=1</p> <p>The output ends with the string:</p> <p>Network survey ended</p> <p style="text-align: center;">if #CSURVF=2</p> <p>the output ends with the string:</p> <p>Network survey ended (Carrier: <NoARFCN> BCCh: <NoBCCh>)</p> <p>where <NoARFCN> - number of scanned frequencies <NoBCCH> - number of found BCCh</p>	



#CSURV - Network Survey		SELINT 0 / 1
AT#CSURV?	Read command has the same behaviour as Execution command with parameters omitted.	
AT*CSURV?		
Example	<pre>AT#CSURV Network survey started... arfcn: 48 bsic: 24 rxLev: -52 ber: 0.00 mcc: 610 mnc: 1 lac: 33281 cellId: 3648 cellStatus: CELL_SUITABLE numArfcn: 2 arfcn: 30 48 numChannels: 5 array: 14 19 22 48 82 arfcn: 14 rxLev: 8 Network survey ended OK</pre>	
Note	The command is executed within max. 2 minutes.	

#CSURV - Network Survey		SELINT 2
AT#CSURV[= [<s>,<e>]] AT*CSURV[= [<s>,<e>]] <i>(both syntax are possible; the second syntax is maintained only for backward compatibility and will not be present in future versions)</i>	<p>Execution command allows to perform a quick survey through channels belonging to the band selected by last #BND command issue, starting from channel <s> to channel <e>. Issuing AT#CSURV<CR>, a full band scan is performed.</p> <p>Parameters: <s> - starting channel <e> - ending channel</p> <p>After issuing the command the device responds with the string: Network survey started...</p> <p>and, after a while, a list of informations, one for each received carrier, is reported, each of them in the format:</p> <p style="text-align: center;">(For BCCH-Carrier)</p> <pre>arfcn: <arfcn> bsic: <bsic> rxLev: <rxLev> ber: <ber> mcc: <mcc> mnc: <mnc> lac: <lac> cellId: <cellId> cellStatus: <cellStatus> numArfcn: <numArfcn> arfcn: [<arfcn1> ..[<arfcn64>]] [numChannels: <numChannels> array: [<ba1> ..[<ba32>]] [pbcch: <pbcch> [nom: <nom> rac: <rac> spgc: <spgc> pat: <pat> nco: <nco> t3168: <t3168> t3192: <t3192> drxmax: <drxmax> ctrlAck: <ctrlAck> bsCVmax: <bsCVmax> alpha: <alpha> pcMeasCh: <pcMeasCh>]]]</pre>	



#CSURVC - Network Survey (Numeric Format)	SELINT 0 / 1
<pre data-bbox="448 371 1430 533"><cellStatus>,<numArfcn>[,<arfcn1> ..[<arfcn64>]] [,<numChannels>[,<ba1> ..[<ba32>]]][,<pbccch> [,<nom>,<rac>,<spgc>,<pat>,<nco>,<t3168>,<t3192>,<drxmax>,<ctrlAck>,<bsCVmax>,<alpha>,<pcMeasCh>]]] <CR><LF><CR><LF><CR><LF></pre> <p data-bbox="448 573 539 600">where:</p> <p data-bbox="448 607 1430 667"><arfcn> - C0 carrier assigned radio channel (BCCH - Broadcast Control Channel)</p> <p data-bbox="448 674 975 701"><bsic> - base station identification code</p> <p data-bbox="448 707 906 734"><rxLev> - reception level (in dBm)</p> <p data-bbox="448 741 804 768"><ber> - bit error rate (in %)</p> <p data-bbox="448 775 834 801"><mcc> - mobile country code</p> <p data-bbox="448 808 842 835"><mnc> - mobile network code</p> <p data-bbox="448 842 794 869"><lac> - location area code</p> <p data-bbox="448 875 751 902"><cellId> - cell identifier</p> <p data-bbox="448 909 783 936"><cellStatus> - cell status</p> <p data-bbox="448 943 1031 969">..0 - C0 is a suitable cell (CELL_SUITABLE).</p> <p data-bbox="464 976 1430 1037">1 - the cell is low priority based on the received system information (CELL_LOW_PRIORITY).</p> <p data-bbox="464 1043 1062 1070">2 - the cell is forbidden (CELL_FORBIDDEN).</p> <p data-bbox="464 1077 1430 1137">3 - the cell is barred based on the received system information (CELL_BARRED).</p> <p data-bbox="464 1144 1106 1171">4 - the cell <rxLev> is low (CELL_LOW_LEVEL).</p> <p data-bbox="464 1178 1430 1238">5 - none of the above e.g. exclusion timer running, no BCCH available...etc.. (CELL_OTHER).</p> <p data-bbox="448 1245 1393 1272"><numArfcn> - number of valid channels in the Cell Channel Description</p> <p data-bbox="448 1279 1430 1339"><arfcnn> - arfcn of a valid channel in the Cell Channel Description (<i>n</i> is in the range 1..<numArfcn>)</p> <p data-bbox="448 1346 1430 1440"><numChannels> - number of valid channels in the BCCH Allocation list; the output of this information for non-serving cells depends on last #CSURVEXT setting:</p> <ol data-bbox="587 1447 1430 1574" style="list-style-type: none"> 1. if #CSURVEXT=0 this information is displayed only for serving cell 2. if #CSURVEXT=1 or 2 this information is displayed also for every valid scanned BCCH carrier. <p data-bbox="448 1581 1430 1675"><ban> - arfcn of a valid channel in the BA list (<i>n</i> is in the range 1..<numChannels>); the output of this information for non-serving cells depends on last #CSURVEXT setting:</p> <ol data-bbox="587 1682 1430 1809" style="list-style-type: none"> 1. if #CSURVEXT=0 this information is displayed only for serving cell 2. if #CSURVEXT=1 or 2 this information is displayed also for every valid scanned BCCH carrier. <p data-bbox="448 1816 1430 1877"><i>(The following informations will be printed only if GPRS is supported in the cell)</i></p> <p data-bbox="448 1883 1031 1910"><pbccch> - packet broadcast control channel</p> <p data-bbox="464 1917 906 1944">0 - pbccch not activated on the cell</p>	



#CSURVC - Network Survey (Numeric Format)		SELINT 0 / 1
	14,8 Network survey ended OK	
Note	The command is executed within max. 2 minute. The information provided by #CSURVC is the same as that provided by #CSURV . The difference is that the output of #CSURVC is in numeric format only.	

#CSURVC - Network Survey (Numeric Format)		SELINT 2
<p>AT#CSURVC[=<s>,<e>]]</p> <p>AT*CSURVC[=[<s>,<e>]]</p> <p><i>(both syntax are possible; the second syntax is maintained only for backward compatibility and will not be present in future versions)</i></p>	<p>Execution command allows to perform a quick survey through channels belonging to the band selected by last #BND command issue, starting from channel <s> to channel <e>. Issuing AT#CSURVC<CR>, a full band scan is performed.</p> <p>Parameters: <s> - starting channel <e> - ending channel</p> <p>After issuing the command the device responds with the string: Network survey started...</p> <p>and, after a while, a list of informations, one for each received carrier, is reported, each of them in the format:</p> <p style="text-align: center;">(For BCCH-Carrier)</p> <p><arfcn>,<bsic>,<rxLev>,<ber>,<mcc>,<mnc>,<lac>,<cellId>,<cellStatus>,<numArfcn>[,<arfcn1> ..[<arfcn64>]] [,<numChannels>[,<ba1> ..[<ba32>]][,<pbccch> [,<nom>,<rac>,<spgc>,<pat>,<nco>,<t3168>,<t3192>,<drxmax>,<ctrlAck>,<bsCVmax>,<alpha>,<pcMeasCh>]]] <CR><LF><CR><LF><CR><LF></p> <p>where: <arfcn> - C0 carrier assigned radio channel (BCCH - Broadcast Control Channel) <bsic> - base station identification code; if #CSURVF last setting is 0, <bsic> is a decimal number, else it is a 2-digits octal number <rxLev> - decimal number; it is the reception level (in dBm) <ber> - decimal number; it is the bit error rate (in %) <mcc> - hexadecimal 3-digits number; it is the mobile country code <mnc> - hexadecimal 2-digits number; it is the mobile network code <lac> - location area code; if #CSURVF last setting is 0, <lac> is a decimal</p>	



#CSURVC - Network Survey (Numeric Format)	SELINT 2
	<p>number, else it is a 4-digits hexadecimal number</p> <p><cellId> - cell identifier; if #CSURVF last setting is 0, <cellId> is a decimal number, else it is a 4-digits hexadecimal number</p> <p><cellStatus> - string type; it is the cell status</p> <p>..0 - C0 is a suitable cell (CELL_SUITABLE).</p> <p>1 - the cell is low priority based on the received system information (CELL_LOW_PRIORITY).</p> <p>2 - the cell is forbidden (CELL_FORBIDDEN).</p> <p>3 - the cell is barred based on the received system information (CELL_BARRED).</p> <p>4 - the cell <rxLev> is low (CELL_LOW_LEVEL).</p> <p>5 - none of the above e.g. exclusion timer running, no BCCH available...etc.. (CELL_OTHER).</p> <p><numArfcn> - decimal number; it is the number of valid channels in the Cell Channel Description</p> <p><arfcn> - decimal number; it is the arfcn of a valid channel in the Cell Channel Description (<i>n</i> is in the range 1..<numArfcn>)</p> <p><numChannels> - decimal number; it is the number of valid channels in the BCCH Allocation list; the output of this information for non-serving cells depends on last #CSURVEXT setting:</p> <ol style="list-style-type: none"> 3. if #CSURVEXT=0 this information is displayed only for serving cell 4. if #CSURVEXT=1 or 2 this information is displayed also for every valid scanned BCCH carrier. <p><ban> - decimal number; it is the arfcn of a valid channel in the BA list (<i>n</i> is in the range 1..<numChannels>); the output of this information for non-serving cells depends on last #CSURVEXT setting:</p> <ol style="list-style-type: none"> 1. if #CSURVEXT=0 this information is displayed only for serving cell 2. if #CSURVEXT=1 or 2 this information is displayed also for every valid scanned BCCH carrier. <p><i>(The following informations will be printed only if GPRS is supported in the cell)</i></p> <p><pbccch> - packet broadcast control channel</p> <p>0 - pbccch not activated on the cell</p> <p>1 - pbccch activated on the cell</p> <p><nom> - network operation mode</p> <p>1</p> <p>2</p> <p>3</p> <p><rac> - routing area code</p> <p>0..255 -</p> <p><spgc> - SPLIT_PG_CYCLE support</p> <p>..0 - SPLIT_PG_CYCLE is not supported on CCCH on this cell</p> <p>..1 - SPLIT_PG_CYCLE is supported on CCCH on this cell</p> <p><pat> - priority access threshold</p>



#CSURVC - Network Survey (Numeric Format)	SELINT 2
	<p>0 - 3..6 - <nco> - network control order 0..2 - <t3168> - timer 3168 <t3192> - timer 3192 <drxmax> - discontinuous reception max time (in seconds) <ctrlAck> - packed control ack <bsCVmax> - blocked sequenc countdown max value <alpha> - alpha parameter for power control <pcMeasCh> - type of channel which shall be used for downlink measurements for power control 0 - BCCH 1 - PDCH</p> <p style="text-align: center;">(For non BCCH-Carrier)</p> <p><arfcn>,<rxLev></p> <p>where: <arfcn> - decimal number; it is the RF channel <rxLev> - decimal number; it is the reception level (in dBm)</p> <p>The last information from #CSURVC depends on the last #CSURVF setting:</p> <p style="text-align: center;">#CSURVF=0 or #CSURVF=1</p> <p>The output ends with the string: Network survey ended</p> <p style="text-align: center;">#CSURVF=2</p> <p>the output ends with the string: Network survey ended (Carrier: <NoARFCN> BCCh: <NoBCCh>) where <NoARFCN> - number of scanned frequencies <NoBCCh> - number of found BCCh</p>
Example	<p>AT#CSURVC</p> <p>Network survey started...</p> <p>48,24,-52,0.00,610,1,33281,3648,0,2,30 48,5,14 19 22 48 82</p> <p>14,8</p>



#CSURVU - Network Survey Of User Defined Channels		SELINT 2
<p>[,<ch10>]]]] (both syntax are possible; the second syntax is maintained only for backward compatibility and will not be present in future versions)</p>	<p>Parameters: <chn> - channel number (arfcn)</p>	
<p>Example</p>	<pre>AT#CSURVU=59,110 Network survey started... arfcn: 59 bsic: 16 rxLev: -76 ber: 0.00 mcc: 546 mnc: 1 lac: 54717 cellId: 21093 cellStatus: CELL_SUITABLE numArfcn 2 arfcn: 36 59 arfcn: 110 rxLev: -107 Network survey ended OK</pre>	
<p>Note</p>	<p>The command is executed within max. 2 minute.</p>	

3.5.7.7.4 Network Survey Of User Defined Channels (Numeric Format) - #CSURVUC

#CSURVUC - Network Survey Of User Defined Channels (Numeric Format)		SELINT 0 / 1
<p>AT#CSURVUC=[<ch1>[,<ch2>[,...[,<ch10>]]]]</p> <p>AT*CSURVUC=[<ch1>[,<ch2>[,...[,<ch10>]]]] (both syntax are possible)</p>	<p>Execution command allows to perform a quick survey through the given channels. The range of available channels depends on the last #BND issue.</p> <p>The result format is like command #CSURVC.</p> <p>Parameters: <chn> - channel number (arfcn)</p> <p>Note: issuing AT#CSURVUC=<CR> is the same as issuing the command AT#CSURVUC=0<CR>.</p>	
<p>Example</p>	<pre>AT#CSURVUC=59,110 Network survey started... 59,16,-76,0.00,546,1,54717,21093,0,2,36 59</pre>	



3.5.7.7.5 BCCH Network Survey - #CSURVB

#CSURVB - BCCH Network Survey		SELINT 0 / 1
AT#CSURVB=<n>	<p>Execution command performs a quick network survey through M (maximum number of available frequencies depending on last selected band) channels. The survey stops as soon as <n> BCCH carriers are found.</p> <p>The result format is like command #CSURV.</p> <p>Parameter: <n> - number of desired BCCH carriers 1..M</p>	
AT#CSURVB=?	<p>Test command reports the range of values for parameter <n> in the format:</p> <p>(1-M)</p> <p>where M is the maximum number of available frequencies depending on last selected band.</p>	

#CSURVB - BCCH Network Survey		SELINT 2
AT#CSURVB=[<n>]	<p>Execution command performs a quick network survey through M (maximum number of available frequencies depending on last selected band) channels. The survey stops as soon as <n> BCCH carriers are found.</p> <p>The result format is like command #CSURV.</p> <p>Parameter: <n> - number of desired BCCH carriers 1..M</p>	
AT#CSURVB=?	<p>Test command reports the range of values for parameter <n> in the format:</p> <p>(1-M)</p> <p>where M is the maximum number of available frequencies depending on last selected band.</p>	

3.5.7.7.6 BCCH Network Survey (Numeric Format) - #CSURVBC

#CSURVBC - BCCH Network Survey (Numeric Format)		SELINT 0 / 1
AT#CSURVBC=<n>	<p>Execution command performs a quick network survey through M (maximum number of available frequencies depending on last selected band) channels. The survey stops as soon as <n> BCCH carriers are found.</p> <p>The result is given in numeric format and is like command #CSURVC.</p> <p>Parameter: <n> - number of desired BCCH carriers 1..M</p>	



#CSURVBC - BCCH Network Survey (Numeric Format)		SELINT 0 / 1
AT#CSURVBC=?	<p>Test command reports the range of values for parameter <n> in the format:</p> <p>(1-M)</p> <p>where M is the maximum number of available frequencies depending on last selected band.</p>	

#CSURVBC - BCCH Network Survey (Numeric Format)		SELINT 2
AT#CSURVBC=[<n>]	<p>Execution command performs a quick network survey through M (maximum number of available frequencies depending on last selected band) channels. The survey stops as soon as <n> BCCH carriers are found.</p> <p>The result is given in numeric format and is like command #CSURVC.</p> <p>Parameter: <n> - number of desired BCCH carriers 1..M</p>	
AT#CSURVBC=?	<p>Test command reports the range of values for parameter <n> in the format:</p> <p>(1-M)</p> <p>where M is the maximum number of available frequencies depending on last selected band.</p>	

3.5.7.7.7 Network Survey Format - #CSURVF

#CSURVF - Network Survey Format		SELINT 0 / 1
AT#CSURVF=[<format>]	<p>Set command controls the format of the numbers output by all the Easy Scan®</p> <p>Parameter: <format> - numbers format 0 - Decimal 1 - Hexadecimal values, no text 2 - Hexadecimal values with text</p> <p>Note: issuing AT#CSURVF<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT#CSURVF=<CR> is the same as issuing the command AT#CSURVF=0<CR>.</p>	
AT#CSURVF?	<p>Read command reports the current number format, as follows:</p> <p>#CSURVF: <format></p>	
AT#CSURVF=?	<p>Test command reports the supported range of values for the parameter <format>.</p>	



#CSURVEXT - Extended Network Survey		SELINT 2
	GPRS informations carried by the System Information 13 of the BCCh	
AT#CSURVEXT?	Read command reports whether extended network survey is currently enabled or not, in the format: <value>	
AT#CSURVEXT=?	Test command reports the range of values for parameter <value>.	

3.5.7.7.10 PLMN Network Survey - #CSURVP

#CSURVP - PLMN Network Survey		SELINT 2
AT#CSURVP=<plmn>	Execution command performs a quick network survey through channels. The survey stops as soon as a BCCH carriers belonging to the selected PLMN is found. The result format is like command #CSURV. Parameter: <plmn> - the desired PLMN in numeric format	
AT#CSURVP=?	Test command returns OK	

3.5.7.7.11 PLMN Network Survey (Numeric Format) - #CSURVPC

#CSURVPC - PLMN Network Survey (Numeric Format)		SELINT 2
AT#CSURVPC=<plmn>	Execution command performs a quick network survey through channels. The survey stops as soon as a BCCH carriers belonging to the selected PLMN is found. The result is given in numeric format and is like command #CSURVC. Parameter: <plmn> - the desired PLMN in numeric format	
AT#CSURVPC=?	Test command returns OK	

3.5.7.8 SIM Toolkit AT Commands

3.5.7.8.1 SIM Toolkit Interface Activation - #STIA



#STIA - SIM Toolkit Interface Activation	SELINT 2
<p>AT#STIA= [<mode> [,<timeout>]]</p>	<p>Set command is used to activate the SAT sending of unsolicited indications when a proactive command is received from SIM.</p> <p>Parameters:</p> <p><mode></p> <ul style="list-style-type: none"> 0 - disable SAT (no <timeout> required, if given will be ignored) 1 - enable SAT without unsolicited indication #STN 2 - enable SAT and extended unsolicited indication #STN (see #STGI) 3 - enable SAT and reduced unsolicited indication #STN (see #STGI) <p><timeout> - time-out for user responses</p> <ul style="list-style-type: none"> 1..255 - time-out in minutes (default 10). Any ongoing (but unanswered) proactive command will be aborted automatically after <timeout> minutes. In this case, the terminal response is either "ME currently unable to process command", or if applicable, "No response from user". In addition an unsolicited indication will be sent to the external application: <p>#STN: <cmdTerminateValue></p> <p>where:</p> <p><cmdTerminateValue> is defined as <cmdType> + terminate offset; the terminate offset equals 100.</p> <p>Note: every time the SIM application issues a proactive command that requires user interaction an unsolicited code will be sent, if enabled with #STIA command, as follows:</p> <ul style="list-style-type: none"> • if <mode> parameter of #STIA command has been set to 3 (reduced unsolicited indication) an unsolicited indication will be sent, indicating the type of proactive command issued by the SIM: <p>#STN: <cmdType></p> <ul style="list-style-type: none"> • if <mode> parameter of #STIA command has been set to 2 (extended unsolicited indication) the format of the unsolicited indication depends on the specific command: <p style="text-align: center;"><i>if <cmdType>=1 (REFRESH)</i></p> <p>an unsolicited notification will be sent to the user:</p> <p>#STN: <cmdType>,<refresh type></p> <p>where:</p> <p><refresh type></p> <ul style="list-style-type: none"> 0 - SIM Initialization and Full File Change Notification;



#STIA - SIM Toolkit Interface Activation	SELINT 2
	<p>1 - File Change Notification; 2 - SIM Initialization and File Change Notification; 3 - SIM Initialization; 4 - SIM Reset</p> <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <p>In this case neither #STGI nor #STSR commands are required:</p> <ul style="list-style-type: none"> • AT#STGI is accepted anyway. • AT#STSR=<cmdType>,0 will answer OK but do nothing. </div> <p style="text-align: center;"> <i>if <cmdType>=17 (SEND SS)</i> <i>if <cmdType>=19 (SEND SHORT MESSAGE)</i> <i>if <cmdType>=20 (SEND DTMF)</i> <i>if <cmdType>=32 (PLAY TONE)</i> </p> <p>an unsolicited notification will be sent if allowed by SIM (see GSM 11.14):</p> <p>#STN: <cmdType>[,<text>]</p> <p>where: <text> - (optional) text to be displayed to user</p> <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <p>In these cases neither #STGI nor #STSR commands are required:</p> <ul style="list-style-type: none"> • AT#STGI is accepted anyway. • AT#STSR=<cmdType>,0 will answer OK but do nothing. </div> <p>In case of SEND SHORT MESSAGE (<cmdType>=19) command if sending to network fails an unsolicited notification will be sent</p> <p>#STN: 119</p> <p style="text-align: center;"><i>if <cmdType>=33 (DISPLAY TEXT)</i></p> <p>an unsolicited notification will be sent if allowed by SIM (see GSM 11.14):</p> <p>#STN: <cmdType>,<cmdDetails>[,<text>]</p> <p>where: <cmdDetails> - unsigned Integer used as a bit field. 0..255 - used as a bit field: bit 1: 0 - normal priority 1 - high priority</p>



#STIA - SIM Toolkit Interface Activation	SELINT 2
	<p>bits 2 to 7: reserved for future use bit 8: 0 - clear message after a delay 1 - wait for user to clear message <text> - (optional) text to be displayed to user</p> <div style="border: 1px solid black; padding: 5px;"> <p>In this case:</p> <ol style="list-style-type: none"> if <cmdDetails>/bit8 is 0 neither #STGI nor #STSR commands are required: <ul style="list-style-type: none"> AT#STGI is accepted anyway. AT#STSR=<cmdType>,0 will answer OK but do nothing. If <cmdDetails>/bit8 is 1 #STSR command is required </div> <p style="text-align: center;"><i>if <cmdType>=18 (SEND USSD)</i></p> <p>an unsolicited notification will be sent to the user:</p> <p>#STN: <cmdType>[,<text>]</p> <p>where: <text> - optional text string sent by SIM</p> <div style="border: 1px solid black; padding: 5px;"> <p>In this case:</p> <ul style="list-style-type: none"> AT#STSR=18,20 can be sent to end USSD transaction. AT#STGI is accepted anyway. AT#STSR=<cmdType>,0 will answer OK but do nothing. </div> <p>All other commands:</p> <p>the unsolicited indication will report just the proactive command type:</p> <p>#STN: <cmdType></p> <p>Note: if the call control or SMS control facility in the SIM is activated, when the customer application makes an outgoing call, or sends an SS or USSD, or an SMS, the following #STN unsolicited indication could be sent, according to GSM 11.14, to indicate whether the outgoing call has been accepted, rejected or modified by the SIM, or if the SMS service centre address or destination has been changed:</p> <p>#STN: <cmdTerminateValue>,<Result>[,<TextInfo>[,<Number>[,<MODestAddr>]]]</p>



#STIA - SIM Toolkit Interface Activation		SELINT 2
	SMS messages with command +CNMI .	
AT#STIA=?	Test command returns the range of available values for the parameters <mode> and <timeout> .	
Note	Just one instance at a time, the one which first issued AT#STIA=n (with n different from zero), is allowed to issue SAT commands, and this is valid till the same instance issues AT#STIA=0 . After power cycle another instance can enable SAT.	
Note	A typical SAT session on AT interface starts after an #STN: 37 unsolicited code is received, if enabled(see above). At that point usually an AT#STGI=37 command is issued (see #STGI), and after the SAT main menu has been displayed on TE an AT#STSR=37,0,x command is issued to select an item in the menu (see #STSR).	

3.5.7.8.2 SIM Toolkit Get Information - #STGI

#STGI - SIM Toolkit Get Information		SELINT 2
AT#STGI= [<cmdType>]	<p>#STGI set command is used to request the parameters of a proactive command from the ME.</p> <p>Parameter: <cmdType> - proactive command ID according to GSM 11.14 (decimal); these are only those command types that use the AT interface; SAT commands which are not using the AT interface (not MMI related SAT commands, e.g. PROVIDE LOCAL INFORMATION) are executed without sending any indication to the user</p> <ul style="list-style-type: none"> 1 - REFRESH 16 - SET UP CALL 17 - SEND SS 18 - SEND USSD 19 - SEND SHORT MESSAGE 20 - SEND DTMF 32 - PLAY TONE 33 - DISPLAY TEXT 34 - GET INKEY 35 - GET INPUT 36 - SELECT ITEM 37 - SET UP MENU <p>Requested command parameters are sent using an #STGI indication:</p> <p>#STGI: <parameters></p> <p>where <parameters> depends upon the ongoing proactive command as follows:</p>	



#STGI - SIM Toolkit Get Information	SELINT 2
<p><cmdDetails> - unsigned Integer used as a bit field. 0..255 - used as a bit field: bit 1: 0 - normal priority 1 - high priority bits 2 to 7: reserved for future use bit 8: 0 - clear message after a delay 1 - wait for user to clear message <text> - text to be displayed to user</p> <p style="text-align: center;"><i>if <cmdType>=34 (GET INKEY)</i></p> <p>#STGI: <cmdType>,<commandDetails>,<text></p> <p>where: <commandDetails> - unsigned Integer used as a bit field. 0..255 - used as a bit field: bit 1: 0 - Digits only (0-9, *, # and +) 1 - Alphabet set; bit 2: 0 - SMS default alphabet (GSM character set) 1 - UCS2 alphabet bit 3: 0 - Character sets defined by bit 1 and bit 2 are enabled 1 - Character sets defined by bit 1 and bit 2 are disabled and the "Yes/No" response is requested bits 4 to 7: 0 bit 8: 0 - No help information available 1 - Help information available <text> - String as prompt for text.</p> <p style="text-align: center;"><i>if <cmdType>=35 (GET INPUT)</i></p> <p>#STGI: <cmdType>,<commandDetails>,<text>,<responseMin>,<responseMax>[,<defaultText>]</p> <p>where: <commandDetails> - unsigned Integer used as a bit field. 0..255 - used as a bit field: bit 1: 0 - Digits only (0-9, *, #, and +)</p>	



#JDR - Jammed Detect & Report	SELINT 2
	<p>GPIO2/JDR High - Jammed Condition.</p> <p>2 - enables the Jammed Detect; the Jammed condition is reported with a single unsolicited result code on serial line, in the format:</p> <p>#JDR: <status> where: <status> JAMMED - Jammed condition detected OPERATIVE - Normal Operating condition restored. This code will be shown only after a jammed condition has occurred.</p> <p>3 - enables the Jammed Detect; the MODULE will make both the actions as for <mode>=1 and <mode>=2.</p> <p>4 - enables the Jammed Detect; the Jammed condition is reported with an unsolicited code every 3s on serial line, in the format:</p> <p>#JDR: <status> where: <status> JAMMED - Jammed condition detected OPERATIVE - Normal Operating condition restored. This code will be shown only after a jammed condition has occurred.</p> <p>5 - enables the Jammed Detect; the MODULE will make both the actions as for <mode>=1 and <mode>=4.</p> <p><MNPL> - Maximum Noise Power Level 0..127</p> <p><DCMN> - Disturbed Channel Minimum Number 0..254</p>
AT#JDR?	<p>Read command reports the current behaviour mode, Maximum Noise Power Level and Disturbed Channel Minimum Number, in the format:</p> <p>#JDR: <mode>,<MNPL>,<DCMN></p>
AT#JDR=?	<p>Test command reports the supported range of values for the parameters <mode>,<MNPL> and <DCMN></p>
Example	<pre>AT#JDR=2 OK ...jammer enters in the range... #JDR: JAMMED ...jammer exits the range... #JDR: OPERATIVE</pre>
Note	<p>It is suggested not to change the default setting for Maximum Noise Power Level and Disturbed Channel Minimum Number.</p> <p>If the device is installed in a particular environment where the default values are not satisfactory the two parameters <MNPL> and <DCMN> permit to adapt the detection to all conditions.</p>



#STARTMODESCR - Script Execution Start Mode		SELINT 2
	parameter active script will not be executed (default is 10).	
AT#STARTMODESCR?	Read command reports the current script start mode and the current script start time-out, in the format: #STARTMODESCR= <script_start_mode>,<script_start_timeout>	
AT#STARTMODESCR=?	Test command returns the range of available values for parameters <script_start_mode> and <script_start_timeout> , in the format: #STARTMODESCR: (0,2),(10-60)	

3.5.7.10.4 Execute Active Script - #EXECSCR

#EXECSCR - Execute Active Script		SELINT 0 / 1
AT#EXECSCR	Execution command causes the current script (see #ESCRIP) execution not at startup. This command is useful when the execution at startup has been blocked deliberately and the user wants to control execution start.	
AT#EXECSCR?	Read command has the same behaviour as execution command	
AT#EXECSCR=?	Test command returns OK result code.	

#EXECSCR - Execute Active Script		SELINT 2
AT#EXECSCR	Execution command causes the current script (see #ESCRIP) execution not at startup. This command is useful when the execution at startup has been blocked deliberately and the user wants to control execution start.	
AT#EXECSCR=?	Test command returns OK result code.	

3.5.7.10.5 Read Script - #RSCRIPT

#RSCRIPT - Read Script		SELINT 0 / 1
AT#RSCRIPT= <script_name>	Execution command reports the content of file <script_name> . Parameter: <script_name> - file name, string type (max 16 chars, case sensitive). The device shall prompt a three character sequence <less_than><less_than><less_than> (IRA 60, 60, 60) followed by the file content. Note: if the file <script_name> was saved with the hidden attribute, then an empty file is reported with the OK result code. Note: If the file <script_name> is not present an error code is reported.	
Example	AT#RSCRIPT="First.py " <i>hereafter receive the prompt: depending on your editor</i>	



#LSCRIPT - List Script Names		SELINT 0 / 1
	<p><script-namen> - file name, quoted string type (max 16 chars, case sensitive)</p> <p><size> - size of script in bytes</p> <p><free_NVM> - size of available NVM memory in bytes</p>	
AT#LSCRIPT?	Read command has the same behavior of Execution command.	
Example	<pre>AT#LSCRIPT #LSCRIPT: First.py 51 #LSCRIPT: Second.py 178 #LSCRIPT: Third.py 95 #LSCRIPT: free bytes: 20000 OK</pre>	

#LSCRIPT - List Script Names		SELINT 2
AT#LSCRIPT	<p>Execution command reports either the list of file names for the files currently stored in the Easy Script® related NVM and the available free NVM memory in the format:</p> <p>[#LSCRIPT: <script_name1>,<size1>... [<CR><LF>#LSCRIPT: <script_namen>,<size>]] <CR><LF>#LSCRIPT: free bytes: <free_NVM></p> <p>where:</p> <p><script-namen> - file name, quoted string type (max 16 chars, case sensitive)</p> <p><size> - size of script in bytes</p> <p><free_NVM> - size of available NVM memory in bytes</p>	
AT#LSCRIPT=?	Test command returns OK result code.	
Example	<pre>AT#LSCRIPT #LSCRIPT: "First.py",51 #LSCRIPT: "Second.py",178 #LSCRIPT: "Third.py",95 #LSCRIPT: free bytes: 20000 OK</pre>	

3.5.7.10.7 Delete Script - #DSCRIPT

#DSCRIPT - Delete Script		SELINT 0 / 1
AT#DSCRIPT= <script_name>	<p>Execution command deletes a file from Easy Script® related NVM memory.</p> <p>Parameter:</p> <p><script_name> - name of the file to delete, string type (max 16 chars, case</p>	



#DSCRIPT - Delete Script		SELINT 0 / 1
	sensitive)	
	Note: if the file <script_name> is not present an error code is reported.	
Example	AT#DSCRIPT="Third.py" OK	

#DSCRIPT - Delete Script		SELINT 2
AT#DSCRIPT= [<script_name>]	Execution command deletes a file from Easy Script® related NVM memory.	
	Parameter:	
	<script_name> - name of the file to delete, string type (max 16 chars, case sensitive)	
	Note: if the file <script_name> is not present an error code is reported.	
Example	AT#DSCRIPT="Third.py" OK	

3.5.7.10.8 Reboot - #REBOOT

#REBOOT - Reboot		SELINT 0 / 1
AT#REBOOT	Execution command reboots immediately the unit.	
	It can be used to reboot the system after a remote update of the script in order to have the new one running.	
AT#REBOOT?	Read command has the same behavior of Execution command.	
Example	AT#REBOOT ... Module Reboots ...	
Note	This command does not return result codes.	

#REBOOT - Reboot		SELINT 2
AT#REBOOT	Execution command reboots immediately the unit.	
	It can be used to reboot the system after a remote update of the script in order to have the new one running.	
Example	AT#REBOOT ... Module Reboots ...	
Note	This command does not return result codes.	

3.5.7.10.9 CMUX Interface Enable - #CMUXSCR

#CMUXSCR - CMUX Interface Enable		SELINT 2
AT#CMUXSCR=	Set command enables/disables the GSM 07.10 multiplexing protocol control	



\$GPSP - GPS Controller Power Management		SELINT 0 / 1 / 2
	Note: the current setting is stored through \$GPSSAV	
AT\$GPSP?	Read command reports the current value of the <status> parameter, in the format: \$GPSP: <status>	
AT\$GPSP=?	Test command reports the range of supported values for parameter <status>	
Example	AT\$GPSP=0 OK	

3.5.7.11.2 GPS Reset - \$GPSR

\$GPSR - GPS Reset		SELINT 0 / 1 / 2
AT\$GPSR= <reset_type>	Execution command allows to reset the GPS controller. Parameter: <reset_type> 0 - Hardware reset: the GPS receiver is reset and restarts by using the values stored in the internal memory of the GPS receiver. 1 - Coldstart (No Almanac, No Ephemeris): this option clears all data that is currently stored in the internal memory of the GPS receiver including position, almanac, ephemeris, and time. The stored clock drift however, is retained. It is available in controlled mode only. 2 - Warmstart (No ephemeris): this option clears all initialization data in the GPS receiver and subsequently reloads the data that is currently displayed in the Receiver Initialization Setup screen. The almanac is retained but the ephemeris is cleared. It is available in controlled mode only. 3 - Hotstart (with stored Almanac and Ephemeris): the GPS receiver restarts by using the values stored in the internal memory of the GPS receiver; validated ephemeris and almanac. It is available in controlled mode only.	
AT\$GPSR=?	Test command reports the range of supported values for parameter <reset_type>	
Example	AT\$GPSR=0 OK	

3.5.7.11.3 GPS Device Type Set - \$GPSD

\$GPSD - GPS Device Type Set		SELINT 0 / 1 / 2
AT\$GPSD= <device_type>	Set command defines which GPS device is connected to the module. It dedicates the Serial port #1 of the module (TRACE) to receive the GPS strings from the GPS module. Parameter: <device type>	



\$GPSAP - GPS Antenna Protection		SELINT 0 / 1 / 2
<value>]	<p>current consumption of GPS antenna. The protection disables the GPS antenna supply voltage.</p> <p>Parameters: <set> 0 - deactivate current antenna protection (default) 1 - activate current antenna protection <value> - the antenna current limit value in mA 0..200</p> <p>If parameter <set>=0 parameter <value> has no meaning and can be omitted.</p> <p>Note: the new setting is stored through \$GPSSAV</p>	
AT\$GPSAP?	<p>Read command reports the current activation status of antenna automatic protection and the current antenna limit value, in the format:</p> <p>\$GPSAP: <set>,<value></p>	
AT\$GPSAP=?	<p>Test command reports the range of supported values for parameters <set> and <value></p>	
Example	<pre>AT\$GPSAP=0 OK Note : no SW control on antenna status (HW current limitation only) AT\$GPSAP=1,25 OK activate current antenna protection with related current limit AT\$GPSAP? \$GPSAP:1,50 OK Antenna protection activated with 50mA limit</pre>	
Note	<p>The module is already provided of an Hardware protection for the high current consumption that is automatically activated if the consumption exceeds 50mA</p>	

3.5.7.11.9 GPS NMEA Serial Port Speed - \$GPSS

\$GPSS - GPS Serial Port Speed		SELINT 0 / 1 / 2
AT\$GPSS=<speed>	<p>Set command allows to select the speed of the NMEA serial port.</p> <p>Parameter: <speed> 4800 - (default) 9600</p>	



\$GPSS - GPS Serial Port Speed		SELINT 0 / 1 / 2
	19200 38400 57600	
	Note: the new setting is stored through \$GPSSAV	
AT\$GPSS?	Read command returns the current serial ports speed in the format: \$GPSS: <speed>	
AT\$GPSS=?	Test command returns the available range for <speed>	

3.5.7.11.10 Unsolicited NMEA Data Configuration - \$GPSNMUN

\$GPSNMUN - Unsolicited NMEA Data Configuration		SELINT 0 / 1 / 2
AT\$GPSNMUN= <enable> [,<GGA>,<GLL>, <GSA>,<GSV>, <RMC>,<VTG >]	<p>Set command permits to activate an Unsolicited streaming of GPS data (in NMEA format) through the standard GSM serial port and defines which NMEA sentences will be available</p> <p>Parameters:</p> <p><enable></p> <p>0 - NMEA data stream de-activated (default)</p> <p>1 - NMEA data stream activated with the following unsolicited response syntax: \$GPSNMUN:<CR><NMEA SENTENCE><CR></p> <p>2 - NMEA data stream activated with the following unsolicited response syntax: <NMEA SENTENCE><CR></p> <p>3 - dedicated NMEA data stream; it is not possible to send AT commands; with the escape sequence '+++' the user can return to command mode</p> <p><GGA> - Global Positioning System Fix Data 0 - disable (default) 1 - enable</p> <p><GLL> - Geographical Position - Latitude/Longitude 0 - disable (default) 1 - enable</p> <p><GSA> - GPS DOP and Active Satellites 0 - disable (default) 1 - enable</p> <p><GSV> - GPS Satellites in View 0 - disable (default) 1 - enable</p> <p><RMC> - recommended Minimum Specific GPS Data 0 - disable (default) 1 - enable</p> <p><VTG> - Course Over Ground and Ground Speed 0 - disable (default) 1 - enable</p>	
AT\$GPSNMUN?	Read command returns whether the unsolicited GPS NMEA data streaming	



\$GPSNMUN - Unsolicited NMEA Data Configuration		SELINT 0 / 1 / 2
	is currently enabled or not, along with the NMEA sentences availability status, in the format: \$GPSNMUN:<enable>,<GGA>,<GLL>,<GSA>,<GSV>,<RMC>,<VTG >	
AT\$GPSNMUN=?	Test command returns the supported range of values for parameters <enable>,<GGA>,<GLL>,<GSA>,<GSV>,<RMC>,<VTG>	
Example	<pre>AT\$GPSNMUN=1,0,0,1,0,0,0 OK These sets the GSA as available sentence in the unsolicited message AT\$GPSNMUN=0 OK Turn-off the unsolicited mode AT\$GPSNMUN? \$GPSNMUN: 1,0,0,1,0,0,0 OK Give the current frame selected (GSA) The unsolicited message will be: \$GPSNMUN: \$GPGSA,A,3,23,20,24,07,13,04,02,,,,,,,,,2.4,1.6,1.8*3C</pre>	
Reference	NMEA 01803 Specifications	
Note	<p><i>The command is available in "Controlled Mode" only</i></p> <p><i>The available NMEA Sentences are depending on the GPS receiver used</i></p> <p><i>In GE863-GPS and GM862-GPS the fields PDOP and VDOP are not available</i></p> <p><i>Use NMEA serial port instead if full DOP info are needed</i></p>	

3.5.7.11.11 Get Acquired Position - \$GPSACP

\$GPSACP - Get Acquired Position		SELINT 0 / 1 / 2
AT\$GPSACP	<p>Execution command returns information about the last GPS position in the format:</p> <p>\$GPSACP: <UTC>,<latitude>,<longitude>,<hdop>,<altitude>,<fix>,<cog>,<spkm>,<spkn>,<date>,<nsat></p> <p>where: <UTC> - UTC time (hhmmss.sss) referred to GGA sentence <latitude> - format is ddmm.mmmm N/S (referred to GGA sentence) where: dd - degrees 00..90</p>	



#RSEN – Remote SIM Enable	SELINT 2
	<p><i>If the ME support the Easy Script Extension® and <scriptmode> is 1</i></p> <p><muxch> - MDM interface number in scripts; mandatory if <mode>=1 1 - MDM interface 2 - MDM2 interface</p> <p><beacon> - retransmission timer of SAP Connection Request 0 - only one transmission (default) 1..100 - timer interval in seconds.</p> <p><scriptmode> - script mode enable; setting this subparameter has a meaning only if the ME supports the Easy Script® Extension 0 - disable script mode (see subparameter <muxch>) 1 - enable script mode (see subparameter <muxch>)</p> <p>Note: enabling the Remote SIM feature when the SIM is already inserted causes the module to:</p> <ul style="list-style-type: none"> • de-register from the actual network • de-initialize the current SIM. <p>Note: issuing the command on a not multiplexed interface (see +CMUX) cause an ERROR to be raised in all the situations except when:</p> <ul style="list-style-type: none"> • the ME supports the Easy Script Extension® and • <scriptmode> is 1 <p>Note: if the Remote SIM feature has been activated the SAP connection status is signalled with the following URC:</p> <p>#RSEN: <conn> where <conn> - connection status 0 - disconnected 1 - connected</p>
AT#RSEN?	<p>Read command returns the SAP connection status in the format:</p> <p>#RSEN: <conn> where <conn> - connection status, as before</p>
AT#RSEN=?	<p>Test command reports the range of values for all the parameters.</p>



3.5.7.13 Telefonica OpenGate M2M AT Commands Set

For more detailed information about the AT commands dedicated for Telefonica Open Gate M2M protocol handling please consult the OpenGate M2M Protocol User Guide.



4 List of acronyms

ARFCN	Absolute Radio Frequency Channel Number
AT	Attention command
BA	BCCH Allocation
BCCH	Broadcast Control Channel
CA	Cell Allocation
CBM	Cell Broadcast Message
CBS	Cell Broadcast Service
CCM	Current Call Meter
CLIR	Calling Line Identification Restriction
CTS	Clear To Send
CUG	Closed User Group
DCD	Data Carrier Detect
DCE	Data Communication Equipment
DCS	Digital Cellular System
DGPS	Differential GPS, the use of GPS measurements, which are differentially corrected
DNS	Domain Name System
DSR	Data Set Ready
DTE	Data Terminal Equipment
DTMF	Dual Tone Multi Frequency
DTR	Data Terminal Ready
GGA	GPS Fix data
GLL	Geographic Position – Latitude/Longitude
GLONASS	Global positioning system maintained by the Russian Space Forces
GMT	Greenwich Mean Time
GNSS	Any single or combined satellite navigation system (GPS, GLONASS and combined GPS/GLONASS)
GPRS	Global Packet Radio Service
GPS	Global Positioning System
GSA	GPS DOP and Active satellites
GSM	Global System Mobile
GSV	GPS satellites in view
HDLC	High Level Data Link Control
HDOP	Horizontal Dilution of Precision
IMEI	International Mobile Equipment Identity
IMSI	International Mobile Subscriber Identity
IP	Internet Protocol
IRA	International Reference Alphabet
IWF	Interworking Function
MO	Mobile Originated



AT Commands Reference Guide
80000ST10025a Rev. 5 - 09/07/08

			#TTY	#CPUMODE	#GSMCONT	
			#CGPADDR	#NWSCANTMR	#OSC32KHZ	
			#CACHEDNS	#DNS	#ICMP	
			#TCPMAXDAT	#TCPREASS	#SSCTRACE	

